Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bell+Howell 2889

Bell+Howell Spin Power Strip Tower Surge Protector User Manual

Model: 2889 | Brand: Bell+Howell

Introduction

The Bell+Howell Spin Power Strip Tower is designed to provide a centralized and protected power solution for multiple electronic devices. It combines the functionality of a surge protector with a multi-port charging station, featuring a unique rotating design and integrated device holders for enhanced convenience and organization.

Key Features

- **Advanced Charging Hub:** Equipped with Rapid Smart Charging Technology for fast charging of mobile phones, smartphones, tablets, power tools, and various other devices.
- **Power Surge Protection:** Features 4 AC power outlets and 6 USB ports with a built-in surge suppressor to protect connected devices from voltage spikes.
- **360° Rotation Design:** The tower's swivel base allows for convenient access to all outlets and USB ports from any angle.
- **Tangle-Free Retractable Cord:** Includes a 40-inch retractable cord for easy reach and neat storage, preventing tangles and damage.
- **Integrated Device Organizer:** A built-in shelf securely holds up to 3 phones or tablets while they charge, contributing to a tidy workspace.

Setup

1. **Unpack the Device:** Carefully remove the Bell+Howell Spin Power Strip Tower from its packaging.
2. **Choose a Location:** Select a stable, flat surface near a wall outlet, ensuring adequate space for the tower and connected devices.
3. **Extend the Power Cord:** Gently pull the 40-inch retractable power cord from the base of the unit until the desired length is achieved. Avoid pulling excessively to prevent damage to the retraction mechanism.
4. **Connect to Power:** Plug the power cord into a standard 120V AC wall outlet.
5. **Activate Power:** Locate the main power switch on the side of the tower and press it to the "ON" position. A red indicator light will illuminate, confirming power is supplied.



Figure 1: The Bell+Howell Spin Power Strip Tower, showcasing its compact design and packaging. The image highlights the product's features including 4 power outlets, 6 USB ports, 360-degree rotation, and a 40-inch retractable cord.

Operating Instructions

Connecting Devices

1. **AC Outlets:** Plug your electronic devices directly into any of the 4 AC outlets located around the tower. The 360° rotating base

allows you to easily position the tower for convenient access to any outlet.

2. **USB Ports:** Connect your USB-powered devices (e.g., smartphones, tablets) to any of the 6 USB ports. The Rapid Smart Charging Technology will automatically detect and deliver the optimal charging current for your device.

Using the Device Holder

- The top of the power strip tower features a built-in shelf designed to securely hold up to 3 phones or tablets while they are charging. This helps keep your charging area organized and clutter-free.
- Simply place your device into the designated slots on the top of the tower. Ensure the charging cable is connected to one of the USB ports or an AC adapter plugged into an outlet.



Figure 2: The Bell+Howell Spin Power Strip Tower shown in a typical usage scenario, with multiple devices connected and charging. This illustrates the product's ability to manage various power needs simultaneously while keeping devices organized.

Maintenance

- **Cleaning:** Disconnect the power strip from the wall outlet before cleaning. Use a soft, dry cloth to wipe down the exterior. Do not use liquid cleaners or abrasive materials.
- **Cord Management:** When not in use, gently push the power cord back into the base for neat storage. Avoid forcing the cord or pulling it out at an extreme angle.
- **Storage:** Store the power strip in a cool, dry place away from direct sunlight and moisture when not in use for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
No power to outlets/USB ports.	Main power switch is off. Power cord not fully plugged in. Wall outlet has no power. Overload protection tripped.	Ensure the main power switch is ON. Check that the power cord is securely plugged into the wall outlet. Test the wall outlet with another device. Unplug some devices and reset the overload protector (if applicable, usually a small button).

Problem	Possible Cause	Solution
Devices not charging quickly.	Device requires higher current than available. Faulty USB cable.	Ensure your device is compatible with the USB port's output. Try a different USB cable.
Cord not retracting properly.	Cord is tangled or obstructed.	Gently guide the cord back into the base, ensuring no kinks or obstructions. Do not force it.

Specifications

- **Model Number:** 2889
- **Product Dimensions:** 6.5 x 5.4 x 0.04 inches
- **Item Weight:** 1.87 pounds
- **Total Power Outlets:** 4 AC Outlets
- **USB Ports:** 6 USB Ports
- **Cord Length:** 40 inches (retractable)
- **Voltage:** 240 Volts (Note: Standard US outlets are 120V. This might be a general specification or peak rating. Users should verify compatibility with local power supply.)
- **Special Features:** Built-in Phone Shelf, 10 Devices at Once, 360 Degree Turn, Rapid Smart Charging Technology, Surge Protection.

Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the contact details provided on the product packaging or visit the official Bell+Howell website. Keep your purchase receipt for warranty claims.
Protection plans are available for purchase separately to extend coverage beyond the manufacturer's warranty. Please check the product listing or contact your retailer for details on available protection plans.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B084H2QNWN

More documents and user manuals: **https://manuals.plus/**