

Vremi VRM050695N

Vremi 6,250 BTU Portable Air Conditioner User Manual

Model: VRM050695N | Brand: Vremi

1. INTRODUCTION AND PRODUCT OVERVIEW

This manual provides detailed instructions for the safe and efficient operation, installation, and maintenance of your Vremi 6,250 BTU Portable Air Conditioner. Designed for rooms up to 250 square feet, this unit offers powerful cooling, fan, and dehumidifying functions to enhance your indoor comfort.



Figure 1: Vremi Portable Air Conditioner and Remote Control

2. IMPORTANT SAFETY INFORMATION

Please read all safety warnings and instructions carefully before using this appliance to prevent personal injury or property damage. Keep this manual for future reference.

- Ensure the unit is placed on a flat, stable surface to prevent tipping.
- Do not operate the unit with a damaged cord or plug.
- Always unplug the unit before cleaning or performing any maintenance.
- Maintain adequate clearance around the unit for proper airflow (at least 20 inches from walls or furniture).
- Do not block air outlets or inlets.
- This appliance is for indoor use only.
- Do not use in wet areas such as bathrooms or laundry rooms.

3. SETUP AND INSTALLATION

The Vremi Portable Air Conditioner is designed for easy setup. Follow these steps for proper installation:

1. **Unpack the Unit:** Carefully remove the air conditioner and all accessories from the packaging. Allow the unit to stand upright for at least 24 hours before operation to allow the refrigerant to settle.
2. **Attach Exhaust Hose:** Connect the exhaust hose to the rear outlet of the air conditioner. Ensure it is securely twisted into place.
3. **Install Window Vent Kit:** Assemble the window slider kit according to your window's dimensions. Insert the exhaust hose adapter into the opening of the window kit.
4. **Position the Unit:** Place the air conditioner near a window, ensuring the exhaust hose can reach the window kit without kinks or sharp bends.
5. **Plug In:** Connect the power cord to a grounded electrical outlet (115 Volts).



Figure 2: Unit Placement and Exhaust Hose Connection



Figure 3: Window Kit Installation

4. OPERATING MODES

Your Vremi Portable Air Conditioner features multiple operating modes for versatile climate control. Use the control panel on top of the unit or the included remote control to select your desired mode.

4 Operating Modes.



Cool
10,000 BTU



Fan
Up To
880 r/min



Dry
63 Pints
Per Day



Sleep
Only 51 dB



**Built-In Remote
Control Storage**



Figure 4: Available Operating Modes

- **Cool Mode:** Provides powerful cooling with 6,250 BTU (ASHRAE) capacity. Adjust the temperature using the up/down arrows on the control panel or remote.
- **Fan Mode:** Circulates air without cooling. Ideal for improving air circulation. Features multiple fan speeds (up to 880 r/min).
- **Dry Mode (Dehumidifier):** Removes excess moisture from the air, collecting up to 63 pints per day.
- **Sleep Mode:** Operates quietly at 51 dB for undisturbed rest. The unit will automatically adjust the temperature for optimal sleep comfort.
- **Timer Function:** Set the unit to turn on or off automatically with the 1-24 hour timer.
- **Swing Mode:** Activate the swing mode to maximize air flow and mimic a natural breeze.

Beat The Heat!


Automatic 1–24 Hour Timer
Let's You Stay Cool And In Control



Figure 5: Timer and Quiet Operation Features

Cool Breeze!

Activate Swing Mode To
Maximize Air Flow And
Mimic A Natural Breeze



On A Roll!

Built-In Castors
And Handles For
Easy Movement
Between Rooms

Figure 6: Swing Mode and Portability Features

5. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your air conditioner.

- **Cleaning the Air Filter:** The unit features a washable air filter. It is recommended to clean the filter weekly under running water. Ensure the filter is completely dry before reinserting it into the unit.
- **Draining Water:** In high humidity conditions, the internal water tank may fill up. The unit will indicate when it needs to be drained. Refer to the specific draining instructions in the full PDF manual for your model.
- **Exterior Cleaning:** Wipe the exterior of the unit with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.



Figure 7: Cleaning the Reusable Air Filter

6. TROUBLESHOOTING

If you encounter issues with your Vremi Portable Air Conditioner, consult the table below for common problems and solutions.

Problem	Possible Cause	Solution
Unit does not turn on.	No power, full water tank, timer active.	Check power connection, drain water tank, deactivate timer.
Unit is not cooling effectively.	Dirty air filter, blocked air intake/outlet, room size too large, open windows/doors.	Clean air filter, clear obstructions, ensure room size is within specifications (up to 250 sq ft), close all windows and doors.
Unit is noisy.	Unit not on a level surface, internal components vibrating.	Ensure unit is on a flat surface. Some operational noise is normal.
Water leakage.	Drain plug not properly sealed, unit tilted, water tank full.	Check drain plug, ensure unit is level, drain water tank.

For more complex issues, please refer to the full user manual or contact Vremi customer support.

7. SPECIFICATIONS

- **Brand Name:** Vremi
- **Model Info:** VRM050695N
- **Cooling Capacity:** 6,250 BTU (ASHRAE) / 0.83 Tons
- **Recommended Coverage Area:** Up to 250 Square Feet
- **Item Weight:** 66.8 pounds
- **Product Dimensions:** 12.2 x 16.5 x 27.6 inches (D x W x H)
- **Noise Level:** 51 dB
- **Voltage:** 115 Volts
- **Wattage:** 1095 watts
- **Refrigerant:** R410A
- **Special Features:** Multiple operating modes, Washable air filter



Figure 8: Product Dimensions and Key Specifications




Figure 9: Recommended Coverage Area by BTU

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Vremi website or contact their customer service directly. You may also find additional support resources on the product's Amazon listing page.

Customer Support Link: [Vremi Customer Support](#)