Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iHome IHCT539N-WM

iHome 2-Port USB Wall Charger (Model: IHCT539N-WM)

Instruction Manual

Product Overview

The iHome 2-Port USB Wall Charger is a compact and efficient power adapter designed to charge multiple devices simultaneously. Its flat profile and foldable prongs make it ideal for use in tight spaces and for travel. This charger features two USB-A ports, including a dedicated 2.4A port for rapid charging.



Image: iHome 2-Port USB Wall Charger plugged into an outlet, charging a laptop and a smartphone.

Setup

1. **Unfold Prongs:** Gently pull out the foldable prongs from the charger body until they lock into place.
2. **Plug into Outlet:** Insert the charger into a standard AC wall outlet. The flat design allows it to fit snugly, even behind furniture.
3. **Connect Devices:** Plug your USB charging cables into the available USB ports on the bottom of the charger.



Image: iHome 2-Port USB Wall Charger with its foldable prongs extended, ready for use.

Operating Instructions

The iHome 2-Port USB Wall Charger is designed for simple plug-and-play operation. Once plugged into an AC outlet, it is ready to charge your devices.

- **Standard Charging:** Use any of the USB-A ports for standard charging of your smartphones, tablets, and other USB-powered devices.
- **Rapid Charging:** For devices that support faster charging, utilize the dedicated 2.4A USB port (often indicated by a blue interior or specific labeling) to achieve quicker charge times.
- **Simultaneous Charging:** You can charge two devices at the same time using both USB ports. The charger intelligently distributes power to connected devices.



Image: iHome 2-Port USB Wall Charger with two devices connected, illustrating simultaneous charging.

Video: Demonstrating the iHome AC Pro 3.4 Amp 2-Port USB Wall Charger with its flat foldable plug and charging capabilities.

Maintenance

To ensure the longevity and optimal performance of your iHome USB Wall Charger, follow these simple maintenance guidelines:

- **Cleaning:** Always unplug the charger from the wall outlet before cleaning. Use a soft, dry cloth to wipe the exterior. Avoid using liquid cleaners or abrasive materials.
- **Storage:** When not in use or for travel, fold the prongs back into the charger body to protect them and prevent damage to other items. Store in a cool, dry place.
- **Handling:** Avoid dropping the charger or subjecting it to strong impacts. Do not attempt to disassemble or repair the unit yourself.

Troubleshooting

If you encounter issues with your iHome 2-Port USB Wall Charger, please refer to the following common solutions:

Problem	Possible Cause	Solution
Device not charging	Charger not properly plugged in; faulty cable; faulty device.	Ensure the charger is securely plugged into a live outlet. Try a different USB cable. Test the device with another charger.
Slow charging	Device not compatible with rapid charging; cable quality; multiple devices drawing power.	Ensure your device supports rapid charging and use the 2.4A port. Use a high-quality USB cable. Try charging one device at a time.
Charger feels warm	Normal operation during charging.	A slight warmth is normal. If it becomes excessively hot, unplug immediately and contact customer support.

Specifications

- **Model Number:** IHCT539N-WM
- **Package Dimensions:** 3.74 x 3.15 x 1.02 inches
- **Item Weight:** 2.46 ounces
- **Input Voltage:** 120 Volts
- **Amperage:** 3.4 Amps (Total)
- **Total USB Ports:** 2 (1x Standard USB-A, 1x 2.4A Rapid Charge USB-A)
- **Compatible Devices:** iPhone, Samsung, Google Pixel, and other USB-powered devices.
- **Special Feature:** Fast Charging, Foldable Prongs, Flat Wall Plug

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official iHome website. You may also contact iHome customer service directly for assistance with product-related inquiries.

© 2024 iHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B084H4YBH8

More documents and user manuals: **https://manuals.plus/**