

[Manuals.plus](#) /

› [Metaltex](#) /

› Metaltex Under-shelf Basket (Model 363040) Instruction Manual

Metaltex 363040

Metaltex Under-shelf Basket (Model 363040) - Instruction Manual

Optimize your storage space with ease.

INTRODUCTION

Thank you for choosing the Metaltex Under-shelf Basket. This product is designed to help you maximize storage efficiency in your kitchen, pantry, or other areas by utilizing unused space beneath shelves. Made from durable metal, it offers a practical and robust storage solution.

Please read this manual carefully before installation and use to ensure proper handling and longevity of your product.

SAFETY INFORMATION

- Ensure the shelf you intend to use is sturdy and capable of supporting the weight of the basket and its contents.
- Do not overload the basket. Distribute weight evenly.
- Keep fingers clear when sliding the basket onto the shelf to avoid pinching.
- This product is for indoor use only.

PRODUCT OVERVIEW

The Metaltex Under-shelf Basket (Model 363040) is a versatile storage accessory. Its design allows it to easily slide onto existing shelves, creating instant additional storage space without the need for tools or permanent fixtures.




Figure 1: Metaltex Under-shelf Basket, Model 363040. This image shows the complete under-shelf basket in black, highlighting its wire mesh construction and the hooks designed to slide onto a shelf.

Key Features:

- **Material:** Durable Metal
- **Color:** Black
- **Dimensions:** Approximately 40 cm (Length) x 26 cm (Width) x 14 cm (Height)
- **Weight:** 360 grams
- **Assembly:** No assembly required
- **Special Feature:** Portable design for easy relocation




Figure 2: Detailed dimensions of the Metaltex Under-shelf Basket. The image illustrates the length (40cm), width (26cm), and height (14cm) of the basket, providing clear measurements for compatibility with various shelves.

SETUP AND INSTALLATION

The Metaltex Under-shelf Basket requires no assembly. Installation is quick and straightforward.

1. **Identify Suitable Shelf:** Choose a shelf that is stable and has sufficient clearance beneath it for the basket and its contents. The basket is designed to fit shelves with a thickness of up to approximately 2.5 cm (1 inch).
2. **Slide On:** Gently slide the two hooks of the basket onto the underside of your chosen shelf. Ensure the basket is fully seated and stable before placing items inside.
3. **Verify Stability:** Lightly tug on the basket to confirm it is securely attached and does not wobble.



Figure 3: An example of the Metaltex Under-shelf Basket installed beneath a wooden shelf, holding neatly folded fabric items. This demonstrates the basket's practical application in utilizing vertical space.



Figure 4: Multiple Metaltex Under-shelf Baskets installed side-by-side under different shelves, showcasing their versatility for organizing various items like plates and cups. This illustrates how multiple units can be used to create extensive storage.

Installation Video:

Your browser does not support the video tag.

Video 1: Official Metaltex installation and usage demonstration for the Kanguro under-shelf basket. This video provides a visual guide on how to easily slide the basket onto a shelf and demonstrates its use for storing various household items.

OPERATING INSTRUCTIONS

Once installed, the under-shelf basket is ready for use. Simply place items into the basket. It is ideal for storing lightweight items such as:

- Kitchen towels or dishcloths
- Small plates or bowls
- Spices or small food packages

- Office supplies
- Cleaning products

Ensure items are placed securely and do not protrude excessively, which could affect stability or obstruct movement.

MAINTENANCE AND CARE

To maintain the appearance and functionality of your Metaltex Under-shelf Basket:

- **Cleaning:** Wipe clean with a damp cloth and mild detergent. Dry thoroughly immediately after cleaning to prevent water spots or potential rust, although the metal is treated for durability.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, scourers, or harsh chemicals, as these can damage the finish.
- **Inspection:** Periodically check the basket for any signs of wear or damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Basket does not fit on shelf.	Shelf is too thick.	Ensure your shelf thickness is within the compatible range (approx. 2.5 cm / 1 inch). Try a different shelf.
Basket wobbles or feels unstable.	Not fully seated on the shelf; shelf is too thin or uneven; overloaded.	Push the basket fully onto the shelf. Ensure the shelf is level and sturdy. Reduce the weight of items in the basket.
Items fall out of the basket.	Basket overloaded; items are too small or irregularly shaped.	Do not overload. Place smaller items in containers within the basket if necessary.

SPECIFICATIONS

- Model Number:** 363040
- Dimensions (L x W x H):** 40 cm x 26 cm x 14 cm (approximately 15.75 in x 10.24 in x 5.51 in)
- Weight:** 360 grams (approximately 0.79 lbs)
- Material:** Metal
- Color:** Black
- Assembly Required:** No
- Special Feature:** Portable
- Shelf Compatibility:** Fits shelves up to approximately 2.5 cm (1 inch) thick.

WARRANTY INFORMATION

Metaltex offers a **5-year warranty** on this product. This warranty covers manufacturing defects and material flaws under normal household use. Please retain your proof of purchase for any warranty claims. For full warranty terms and conditions, please refer to the official Metaltex website or contact customer support.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues with your Metaltex Under-shelf Basket, please visit the official Metaltex website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official website.

You can also visit the [Metaltex Store on Amazon](#) for more information and products.

