Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Smartwares /
- Smartwares IDE-60047 Black Textile Ceiling Light User Manual

Smartwares IDE-60047

Smartwares IDE-60047 Black Textile Ceiling Light User Manual

Model: IDE-60047 | Brand: Smartwares

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Smartwares IDE-60047 Black Textile Ceiling Light. Please read this manual carefully before installation and retain it for future reference. This ceiling light features a 60 cm diameter textile shade and is designed for indoor use, providing ambient lighting with four E27 bulb sockets.




Image 1.1: The Smartwares IDE-60047 Black Textile Ceiling Light.

2. SAFETY INFORMATION

- Always disconnect the power supply before installation, maintenance, or bulb replacement.
- Installation should be performed by a qualified electrician if you are unsure about electrical wiring.
- Ensure the mounting surface can support the weight of the fixture.
- Do not exceed the maximum wattage of 18W per bulb socket.
- This product is designed for indoor use only (IP20 rating). Do not expose to moisture or extreme temperatures.
- · Keep packaging materials away from children.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Smartwares IDE-60047 Ceiling Light (Textile Shade and Mounting Base)
- User Manual

Note: Light bulbs are not included and must be purchased separately.

4. Installation Instructions

Follow these steps for proper installation of your ceiling light:

1. Preparation: Turn off the main power supply at the circuit breaker before starting any electrical work.

2. Mounting the Base Plate:

Position the mounting base against the ceiling at your desired location. Mark the drilling points. Drill holes and insert appropriate wall plugs (if necessary). Secure the mounting base to the ceiling using screws. Ensure it is firmly attached.



Image 4.1: Internal view of the ceiling light's mounting base with E27 sockets.

3. Wiring:

Connect the household electrical wires to the terminals on the ceiling light's mounting base. Ensure correct polarity (Live, Neutral, Earth). The connection box may require careful opening to access the terminals. Secure all connections.

4. Attaching the Textile Shade:

Carefully align the textile shade with the mounting base. The shade is designed to fit over the base and secure into place. Ensure it is evenly seated and stable.

5. Installing Bulbs:

Screw four E27 base bulbs (max 18W each, LED compatible) into the sockets. Do not overtighten.

6. Final Check: Once all steps are complete, restore power at the circuit breaker. Test the light fixture.

For alternative installation as a pendant light, the Smartwares 10.005.71 or 6000.518 suspension kit (sold separately) is required.




Image 4.2: The ceiling light can be adapted for pendant installation with an optional kit.

5. OPERATING INSTRUCTIONS

The Smartwares IDE-60047 ceiling light operates via a standard wall switch connected to your household electrical circuit. It is compatible with E27 LED bulbs up to 18W per socket.

- Power On/Off: Use the wall switch to turn the light on or off.
- **Dimmable Functionality:** While the fixture itself is not inherently dimmable, it is compatible with dimmable E27 LED bulbs. To utilize dimming, you must install dimmable bulbs and connect the fixture to a compatible dimmer switch (not included) in your electrical system.

6. MAINTENANCE

- **Cleaning:** Disconnect power before cleaning. Wipe the textile shade and plastic diffuser with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Disconnect power. Allow bulbs to cool completely. Unscrew old bulbs and replace with new E27 bulbs, ensuring they do not exceed 18W.

7. TROUBLESHOOTING

• Light does not turn on:

Check the power supply at the circuit breaker. Ensure bulbs are correctly installed and not faulty. Verify all electrical connections are secure.

· Light flickers:

Ensure bulbs are fully screwed in. If using LED bulbs, confirm they are compatible with the fixture and your electrical system. If using a dimmer, ensure both the bulbs and dimmer switch are compatible with each other. A loose connection can also cause flickering.

• Difficulty attaching the shade:

Ensure the shade is correctly aligned with the mounting guides on the base. Apply gentle, even pressure. Do not force the shade, as this may damage the textile or frame.

8. SPECIFICATIONS

Feature	Specification
Brand	Smartwares
Model Number	IDE-60047
Dimensions (L x W x H)	60 x 60 x 10.3 cm
Weight	2.26 Kilograms
Color	Black
Material	Textile (shade), Plastic (base)
Number of Bulbs	4
Socket Type	E27
Max Wattage per Bulb	18 Watts (LED compatible)
Voltage	240 Volts
IP Rating	IP20 (Indoor use only)

Feature	Specification
Energy Label	А
Special Features	Dimmable (with compatible bulbs/switch)




Image 8.1: Product dimensions: 60 cm diameter, 10 cm height.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the point of purchase or contact Smartwares customer service. Keep your proof of purchase for warranty claims.

Related Documents - IDE-60047



Smartwares DIC-23112 Wi-Fi Video Doorbell Manual and Setup Guide

Comprehensive guide for installing, setting up, and using the Smartwares DIC-23112 Wi-Fi Video Doorbell with the Smartwares View app. Includes troubleshooting and product specifications.



Smartwares CMS-30300 Wireless Camera Set Instruction Manual

Comprehensive guide for the Smartwares CMS-30300 Wireless Camera Set, covering installation, setup, system configuration, menu options, and mobile app integration for home security monitoring.



Smartwares FGA-1304 Carbon Monoxide Detector User Manual

Comprehensive user manual for the Smartwares FGA-1304 Carbon Monoxide Detector, covering installation, operation, safety, and maintenance to ensure home safety against carbon monoxide poisoning.

