

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Rowenta](#) /

› [Rowenta Perfect Steam Pro Iron DG8624 User Manual](#)

Rowenta DG8624

Rowenta Perfect Steam Pro Iron User Manual

Model: DG8624 | Brand: Rowenta

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your Rowenta Perfect Steam Pro Iron. Keep this manual for future reference.

- Always plug the appliance into a grounded outlet.
- Do not leave the iron unattended while it is connected to the power supply.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Keep the iron and its cord out of reach of children less than 8 years when it is switched on or cooling down.
- The soleplate and steam unit can become extremely hot and cause burns. Handle with care.
- Use only tap water. Do not use distilled, demineralized, or chemically descaled water, as this can damage the appliance.

PRODUCT OVERVIEW

The Rowenta Perfect Steam Pro Iron is a high-performance steam station designed for professional-level ironing results at home. It features a unique built-in boiler technology for powerful steam output, a large removable water tank for extended ironing sessions, and a Microsteam soleplate for efficient wrinkle removal.



Image: The Rowenta Perfect Steam Pro Iron, showcasing its sleek design and powerful steam.

Key Features:

- **Expert Results:** Unbelievable steam output with unique built-in boiler technology.
- **Faster Wrinkle Removal:** High-pressure steam and 400-hole Microsteam Soleplate.
- **Extended Use:** 1.1L removable water tank for uninterrupted ironing sessions.
- **Lightweight & Maneuverable:** Smooth gliding and easy handling.
- **Durable Design:** Leakproof design with a calc collector for lasting performance.

SETUP AND FIRST USE

1. Unpacking:

Carefully remove all packaging materials and labels from the iron and steam station.

2. Filling the Water Tank:

1. Ensure the appliance is unplugged and cool.

2. Remove the 1.1L water tank from the base unit.
3. Fill the tank with regular tap water up to the 'MAX' line. Do not overfill.
4. Replace the water tank securely into the base unit.



Image: The removable 1.1L water tank being handled, ready for filling.

3. Powering On:

Plug the power cord into a suitable grounded electrical outlet. The indicator light will illuminate.

4. Initial Heat-Up:

Allow the iron to heat up for approximately 2 minutes until the ready indicator light stops blinking and remains solid. This indicates the iron has reached the optimal temperature for steam generation.

OPERATING INSTRUCTIONS

1. Ironing with Steam:

1. Place the garment on your ironing board.
2. Select the appropriate fabric setting using the digital controls on the base unit.
3. Press the steam trigger located on the iron's handle to release steam as you iron.



Image: A user demonstrating the smooth gliding of the iron over fabric.

2. Steam Boost Function:

For stubborn creases, press the steam boost button (if available on your model) to deliver an extra burst of powerful steam. This is particularly effective for heavy fabrics.

3. Vertical Steaming:

The iron can be used for vertical steaming of hanging garments, curtains, or drapes. Hold the iron vertically a few inches from the fabric and press the steam trigger.

4. Fabric Compatibility:

The Microsteam 400 soleplate ensures precise and even steam distribution, making it suitable for a wide range of fabrics. Always check garment care labels before ironing.

MORE STEAM FOR FAST IRONING

Precise and wide steam distribution



Image: Detailed view of the Microsteam soleplate, highlighting its numerous steam holes.

Product Overview Video:

Your browser does not support the video tag.

Video: A brief overview of the Rowenta Perfect Steam Pro Iron's features and operation.

MAINTENANCE

1. Emptying the Water Tank:

After each use, unplug the iron and allow it to cool completely. Remove the water tank and empty any remaining water. This prevents mineral buildup.

2. Cleaning the Soleplate:

If the soleplate becomes dirty, clean it with a damp cloth and a non-abrasive cleaner designed for iron soleplates. Do not use abrasive pads or metallic objects.

3. Calc Collector Maintenance:

The integrated calc collector helps to capture mineral deposits. Regularly remove and clean the calc collector to maintain optimal steam performance and prolong the life of your iron. Refer to the official PDF manual for detailed instructions on how to remove and clean the calc collector.



Image: The calc collector, a key component for long-lasting quality, shown with collected residue.

4. Storage:

Once cooled and emptied, store the iron and steam station in a safe, dry place, away from direct sunlight and moisture. Ensure the cord is neatly wrapped.

TROUBLESHOOTING

If you encounter issues with your Rowenta Perfect Steam Pro Iron, please consult the following common problems and solutions before contacting customer support.

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No steam or insufficient steam.	Water tank empty; calc collector clogged; iron not hot enough.	Refill water tank; clean calc collector; allow iron to fully heat up.
Water leaking from soleplate.	Temperature too low for steam; overfilled tank.	Increase temperature setting; do not overfill tank.
Iron not heating up.	Not plugged in; power outlet issue.	Check power connection; try a different outlet.

For more detailed troubleshooting steps and solutions, please refer to the comprehensive [official user manual \(PDF\)](#).

SPECIFICATIONS

Feature	Detail
Brand	Rowenta
Model Name	DG8624U1
Power	1800 Watts
Water Tank Capacity	1.1 Liters (Removable)
Steam Boost	Up to 430g/min
Soleplate Material	Stainless Steel Microsteam 400HS
Special Feature	Programmable, Calc Collector
Product Dimensions	18.11"L x 11.81"W
Item Weight	15.2 ounces (approx. 430 Grams)
Color	Blue



Image: Product dimensions for the Rowenta Perfect Steam Pro Iron.

WARRANTY AND SUPPORT

Rowenta products are designed for durability and performance. For information regarding your product's warranty, please refer to the warranty card included in your product packaging or visit the official Rowenta website.

Additional protection plans may be available for purchase:

- 3-Year Protection Plan
- 4-Year Protection Plan
- Complete Protect (monthly plan)

For customer support, spare parts, or service inquiries, please contact Rowenta customer service or visit their official website. You can also download the full [User Manual \(PDF\)](#) for comprehensive details.