DigiPower DP-VL50

DigiPower GoViral - InstaFame - Super Compact 50 LED Video Light

Model: DP-VL50 | Brand: DigiPower

Introduction

The DigiPower InstaFame Super Compact 50 LED Video Light is designed to enhance your photos and videos by providing adjustable illumination. This compact and portable lighting solution is suitable for various content creation needs, including vlogging, photography, and online meetings. It features adjustable brightness and color temperature options to adapt to different environments.



Image: The DigiPower InstaFame 50 LED Video Light, showcasing its compact design and LED panel.

Key Features

- **Compact and Portable:** Designed for on-the-go use, eliminating the need for heavy lighting equipment.
- **50 LED Illumination:** Provides ample lighting for professional-quality results.
- **3-Level Adjustable Brightness:** Manually adjust light intensity to suit surrounding conditions.
- **3 Color Diffusers:** Includes diffusers to set the LED light's hue to warm, cool, or neutral temperatures.
- **Universal Compatibility:** Comes with a smartphone/camera holder and cold-shoe mount for use with DSLRs, mirrorless cameras, cellphones, and tripods.
- **Rechargeable Battery:** Built-in 500mAh battery provides up to 1 hour of use on the highest brightness setting. Charges via Micro USB.




Image: Visual representation of key features including 3 brightness settings, 50 LEDs, 1 hour continuous use, 500mAh rechargeable battery, and smartphone mount.

Package Contents

Verify that all items listed below are included in your package:

- 1 x DigiPower InstaFame 50 LED Video Light
- 3 x Color Diffusers (Warm, Cool, Neutral)
- 1 x Shoe Adaptor
- 1 x Micro USB Charging Cable
- 1 x Smart Phone Holder



Image: All components included in the box: LED Light, 3x Color Diffusers, Shoe Adaptor, Charging Cable, and Smart Phone Holder.

Setup

1. Charging the LED Light

Before first use, fully charge the LED video light. Connect the supplied Micro USB cable to the light's Micro USB Port and the other end to a compatible USB power source (e.g., computer USB port, USB wall adapter). The LED Power Indicator will show charging status.

2. Attaching to Devices

The InstaFame LED light can be attached to various devices:

- **To a Camera (DSLR/Mirrorless):** Use the included Shoe Adaptor. Attach the adaptor to the cold-shoe mount on your camera, then slide the LED light onto the adaptor.
- **To a Smartphone:** Attach the Smart Phone Holder to your smartphone. The holder has a cold-shoe mount where you can slide the LED light. The smartphone adapter also features an additional shoe mount for attaching a

microphone simultaneously.

- **To a Tripod:** The LED light features a universal 1/4-inch tripod mount at its base, allowing direct attachment to most tripods or light stands.



Image: Diagram showing the Micro USB Port and Universal tripod 1/4 mount, along with examples of the light mounted on a smartphone and a camera.

Operating Instructions

1. Power On/Off

Locate the Power On/Off Button on the side of the LED light. Press and hold the button for a few seconds to turn the light on or off.

2. Adjusting Brightness

Once powered on, short press the Power On/Off Button to cycle through the three available brightness levels. Select the level that best suits your lighting needs.

3. Using Color Diffusers

The InstaFame LED light comes with three color diffusers (warm, cool, neutral) to modify the light's color temperature. To use a diffuser, gently slide it into the slots on the front of the LED light until it clicks into place. Remove by sliding it out.




Image: Close-up view of the LED Power Indicator and Power On/Off Button, along with the three color diffusers.



Image: An individual using the DigiPower InstaFame LED light mounted on a camera to enhance photos and videos in a low-light setting.

Maintenance

Cleaning

Wipe the LED light and accessories with a soft, dry cloth. Do not use abrasive cleaners or solvents. Keep the device free from dust and moisture.

Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Recharge the device regularly, even if not in use for extended periods. Store in a cool, dry place.

Troubleshooting

- **Light does not turn on:**

- Ensure the battery is charged. Connect the light to a power source using the Micro USB cable.
- Press and hold the Power On/Off Button for a few seconds to ensure it's properly activated.

- **Light is dim or flickers:**
  - The battery may be low. Recharge the device.
  - Ensure no obstructions are covering the LED panel.
- **Cannot attach to camera/phone:**
  - Ensure you are using the correct adaptor (Shoe Adaptor for camera, Smart Phone Holder for phone).
  - Verify that the mounts are clean and free of debris.

Specifications

Model Number	DP-VL50
Dimensions	6.77 x 4.92 x 1.88 inches
Weight	4.5 ounces
LED Count	50 LEDs
Power Output	3.5W
Luminosity	350 Lumens
Battery Type	Built-in 500mAh Lithium Polymer
Battery Life (Max Brightness)	Up to 1 hour
Charging Interface	Micro USB
Connectivity Technology	USB
Flash Modes Description	Adjustable brightness and color temperature




Image: Technical drawing illustrating the dimensions of the DigiPower InstaFame LED light.

© 2024 DigiPower. All rights reserved.
For support, please visit the official DigiPower website or contact customer service.