

Mainstay Classic 4 Drawer Dresser

Mainstays Classic 4 Drawer Dresser User Manual

Model: Classic 4 Drawer Dresser

Brand: Mainstay

INTRODUCTION

Thank you for choosing the Mainstays Classic 4 Drawer Dresser. This manual provides essential information for the safe assembly, proper use, and maintenance of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.




Image: Front view of the Mainstays Classic 4 Drawer Dresser in Espresso finish, showcasing its four spacious drawers and minimalist design.

SAFETY INFORMATION

Your safety and the safety of others are very important. Please follow all safety instructions to prevent injury and damage.

- **Assembly:** Two adults are recommended for assembly to ensure stability and prevent injury.
- **Wall Anchor Kit:** A wall anchor kit is included to secure the dresser to the wall. It is crucial to install this kit to prevent tipping, especially in households with children. Follow the instructions provided with the anchor kit carefully.
- **Weight Limits:** Do not exceed the recommended weight limits. The top surface can hold up to 50 lbs. Each drawer can hold up to 25 lbs. Overloading can cause structural damage or tipping.
- **Placement:** Place the dresser on a flat, level surface.
- **Children:** Do not allow children to climb on or play with the dresser.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- Dresser panels (top, bottom, sides, back)
- Drawer components (fronts, backs, sides, bottoms)
- Drawer slides (metal)
- Drawer pulls/handles
- Assembly hardware (screws, dowels, cam locks, etc.)
- Wall anchor kit
- Instruction manual

Note: Specific quantities and types of hardware may vary. Refer to the detailed parts list included in your product packaging.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of this dresser requires approximately 2 hours with two adults. Ensure you have adequate space and the necessary tools before starting.

Tools Required (Not Included):

- Phillips head screwdriver
- Hammer

Assembly Steps:

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a soft, clean surface to prevent scratches. Identify each part using the labels and the parts list in your packaging.
2. **Assemble the Main Frame:** Follow the diagrams in your product packaging to connect the side panels, top panel, and bottom panel using the provided hardware (dowels, cam locks, screws). Ensure all connections are secure.
3. **Install Drawer Slides:** Attach the metal drawer slides to the inner sides of the dresser frame according to the instructions. Pay close attention to the orientation of the slides.
4. **Assemble Drawers:** For each of the four drawers, assemble the front, back, and side panels. Insert the drawer bottom into the grooves. Attach the remaining drawer slide components to the sides of each drawer.
5. **Attach Drawer Pulls:** Secure the drawer pulls to the front of each assembled drawer.
6. **Insert Drawers:** Carefully slide each assembled drawer into its corresponding slot in the dresser.

frame. Ensure they operate smoothly.

7. **Install Back Panel:** Secure the back panel to the dresser frame using the small nails or screws provided.
8. **Install Wall Anchor Kit:** This is a critical safety step. Position the dresser in its desired location. Attach one end of the wall anchor strap to the back of the dresser and the other end to a wall stud using the provided hardware. Ensure the dresser is securely anchored to prevent tipping.



Image: The Mainstays Classic 4 Drawer Dresser positioned in a bedroom, demonstrating its functional integration into a living space.

OPERATING INSTRUCTIONS

The Mainstays Classic 4 Drawer Dresser is designed for storing clothing, linens, and other household items.

- **Drawer Use:** Gently pull and push drawers to open and close. Avoid forcing drawers, as this can damage the slides.
- **Weight Distribution:** Distribute weight evenly within each drawer. Do not place heavy items primarily at the front of the drawer, as this can cause instability.
- **Top Surface:** The top surface can be used for decorative items or lightweight storage, not exceeding

50 lbs.

- **Stability:** Always ensure the dresser is securely anchored to the wall, especially when drawers are open. Opening multiple drawers simultaneously can affect stability.

MAINTENANCE

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, which can damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent staining or damage to the laminated particleboard.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Drawer Slides:** If drawers become stiff, a small amount of silicone-based lubricant can be applied to the metal slides.

TROUBLESHOOTING

If you encounter issues with your dresser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Drawers do not align or close smoothly.	Incorrectly installed drawer slides. Uneven assembly of the dresser frame. Overloaded drawers.	Review assembly instructions for drawer slide orientation and attachment. Check that the dresser frame is square and all fasteners are tight. Reduce weight in drawers to below 25 lbs.
Dresser feels wobbly or unstable.	Loose fasteners. Not placed on a level surface. Wall anchor kit not installed or improperly installed.	Tighten all assembly screws. Move dresser to a level surface or use shims. Ensure the wall anchor kit is correctly installed into a wall stud.
Parts damaged during assembly.	Excessive force used. Incorrect tool usage.	Contact customer support for replacement parts. Always follow assembly instructions carefully and use appropriate tools.

SPECIFICATIONS

Brand	Mainstay
Model	Classic 4 Drawer Dresser
Finish	Espresso (Laminated Particleboard)
Number of Drawers	4

Assembled Dimensions (H x W x D)	40.16" x 27.72" x 15.67"
Top Surface Weight Capacity	50 lbs.
Each Drawer Weight Capacity	25 lbs.
Assembly Required	Yes (2 adults recommended)
Care Instructions	Wipe with Dry Cloth
ASIN	B084L1MQLH
UPC	746705660278, 746705679898, 367877924908









Image: Diagram illustrating the dimensions of the Mainstays Classic 4 Drawer Dresser: 40.16 inches high, 27.72 inches wide, and 15.67 inches deep.

WARRANTY AND SUPPORT

For warranty information, replacement parts, or further assistance, please refer to the contact details provided in your product packaging or visit the official Mainstay website. Please have your model number (Classic 4 Drawer Dresser) and ASIN (B084L1MQLH) ready when contacting support.

Related Documents - Classic 4 Drawer Dresser

<div>Installation & Assembly</div> <div></div> <div>Wood Large 6 Drawer Double Dresser</div>	<div>Wood Large 6 Drawer Double Dresser Installation and Assembly Guide</div> <div>Detailed installation and assembly instructions for the Wood Large 6 Drawer Double Dresser, including parts list, step-by-step guides, and safety warnings. Provided by Lark Manor.</div>
<div>Owner Manual</div> <div></div>	<div>Owner Manual - DSCC1405 Dresser Assembly and Care</div> <div>Detailed owner manual for the DSCC1405 dresser, including assembly instructions, maintenance tips, warnings, and warranty information. Features parts list, hardware list, and step-by-step guidance.</div>
<div>Assembly Instruction</div> <div></div> <div>9-DRAWER DRESSER</div>	<div>Latitude Run® 9-Drawer Dresser Assembly Instructions</div> <div>Comprehensive assembly guide for the Latitude Run® 9-Drawer Dresser (model gfay2484), providing step-by-step instructions, parts identification, hardware list, and safety warnings for proper installation.</div>
<div>Installation & Assembly</div> <div></div> <div>If you have any advice or problem, please contact us</div>	<div>Charlton Home 31.4" W 6-Drawer Dresser Assembly Instructions</div> <div>Detailed assembly instructions for the Charlton Home 31.4" W 6-Drawer Dresser, including a comprehensive parts list, hardware guide, and step-by-step assembly procedures.</div>
<div>INSTALLATION MANUAL</div> <div></div> <div>1-8</div>	<div>Ebern Designs Dresser Installation Manual</div> <div>Comprehensive installation guide for the Ebern Designs dresser, featuring step-by-step assembly instructions, a detailed parts list, safety warnings, and warranty information.</div>
<div></div> <div>INSTRUCTION MANUAL Email: service@delarkhome.com</div>	<div>Delarkhome Fluted 6-Drawer Dresser Assembly Instructions</div> <div>Detailed assembly instructions for the Delarkhome 138.4cm wide, 80.8cm high, 39.7cm deep fluted 6-drawer dresser. This guide provides a comprehensive parts list, hardware identification, and step-by-step assembly procedures to ensure a successful build. Includes safety warnings and assembly tips.</div>

