

[manuals.plus](#) /

› [RCA](#) /

› **RCA RFR786-BLACK 7.5 cu. ft. Retro Black Refrigerator with Freezer User Manual**

RCA RFR786-BLACK

RCA RFR786-BLACK 7.5 cu. ft. Retro Black Refrigerator with Freezer User Manual

Model: RFR786-BLACK (HBFR786BLACK6COM)

1. IMPORTANT SAFETY INFORMATION

Before operating this appliance, please read all instructions thoroughly to ensure safe and efficient use. Retain this manual for future reference.

- Ensure the refrigerator is placed on a level surface to prevent instability. Adjustable legs are provided for this purpose.
- Allow the appliance to stand upright for at least 24 hours before plugging it in, especially if it has been tilted during transport. This allows refrigerants to settle.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings clear of obstruction.

2. PRODUCT OVERVIEW

The RCA RFR786-BLACK is a 7.5 cubic foot top-freezer refrigerator designed for efficient food storage. It features adjustable shelves, door bins, and a dedicated crisper for fruits and vegetables.






Figure 1: Front view of the RCA RFR786-BLACK Refrigerator.



Figure 2: Interior layout of the refrigerator, displaying adjustable glass shelves, door bins, and a crisper drawer.

3. SETUP

3.1 Unpacking

Carefully remove all packaging materials. Ensure all components, including the refrigerator unit and any internal accessories (shelves, bins), are present and undamaged. The included components are the refrigerator unit itself.

3.2 Placement

Position the refrigerator on a firm, level floor. Use the adjustable leveling legs at the bottom of the unit to ensure stability and proper door alignment. Allow adequate space around the unit for proper ventilation, typically 4 inches from walls and 12 inches from the ceiling.

3.3 Door Reversal

The refrigerator features a reversible door design, allowing the door swing to be changed from right to left, or vice versa, to suit your kitchen layout. Refer to the detailed diagram in the full product manual for specific instructions on reversing the door hinges.

3.4 Initial Power-On

After placement and leveling, wait at least 24 hours before plugging the refrigerator into a grounded electrical outlet. This waiting period allows the compressor oils and refrigerants to settle, preventing potential damage. Once plugged in, the internal lighting will activate, and the cooling system will begin operation.

4. OPERATING INSTRUCTIONS

4.1 Temperature Control

The refrigerator is equipped with controls to regulate the temperature in both the fresh food and freezer sections. Locate the thermostat dial inside the fresh food compartment. Adjust the dial to your desired cooling level. A setting of '4' is often recommended for general use, but this can be adjusted based on ambient temperature and food load.

4.2 Food Storage

- Adjustable Shelves:** The glass shelves can be repositioned to accommodate items of various heights. Lift and slide the shelves to adjust their placement.
- Door Bins:** Storage bins located on the inside of the door are ideal for smaller items, bottles, and condiments.
- Crisper Bins:** The transparent crisper drawer at the bottom of the fresh food compartment is designed to maintain optimal humidity for fruits and vegetables, preserving their freshness.
- Freezer Compartment:** The freezer includes a full-width, fixed wire shelf and a door bin for organized storage of frozen foods.

4.3 Internal Lighting

The refrigerator features bright incandescent lighting in both the fresh food and freezer compartments, ensuring visibility of stored items. The light activates automatically when the door is opened.

5. MAINTENANCE

5.1 Cleaning

Regular cleaning helps maintain hygiene and efficiency. Unplug the refrigerator before cleaning. Wipe down interior surfaces with a mild detergent and warm water. The spill-proof glass shelves are designed to contain spills, simplifying cleanup. Avoid abrasive cleaners or sharp objects that could damage surfaces.

5.2 Defrosting

This refrigerator features a manual defrost mode for the freezer compartment. When ice buildup becomes excessive (approximately 1/4 inch thick), unplug the unit and allow the ice to melt naturally. Place towels at the bottom to absorb water. Do not use sharp objects to chip away ice, as this can damage the cooling elements.

6. TROUBLESHOOTING

If you encounter issues with your refrigerator, consult the following table before contacting service.

Problem	Possible Cause	Solution
Refrigerator does not operate	No power to the unit; unit not properly settled after transport.	Check power cord connection and circuit breaker. Ensure unit has been upright for 24 hours before plugging in.
Excessive ice buildup in refrigerator section	Thermostat set too cold; door not sealing properly; frequent door openings.	Adjust thermostat to a warmer setting. Check door gasket for proper seal. Reduce frequency of door openings.
Unusual noises	Unit not level; items vibrating inside.	Adjust leveling legs to ensure stability. Rearrange items inside to prevent contact with walls or other items.
Food not cooling sufficiently	Door left open; thermostat set too warm; excessive food load.	Ensure door is closed completely. Adjust thermostat to a colder setting. Avoid overloading the refrigerator.

7. SPECIFICATIONS

Feature	Specification
Brand	RCA
Model Info	HBFR786BLACK6COM
Item Weight	60 pounds
Product Dimensions	23 x 23 x 55 inches (D x W x H)
Capacity	7.5 Cubic Feet
Annual Energy Consumption	5 Kilowatt Hours
Installation Type	Countertop
Form Factor	Compact, Freezer Top
Special Features	Adjustable Shelves
Color	Black
Voltage	110
Defrost System	Automatic (Refrigerator), Manual (Freezer)
Door Hinges	Right (Reversible)
Shelf Type	Glass

Feature	Specification
Number of Shelves	3
Certification	ETL
Material Type	Plastic
Number Of Doors	2


8. WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including coverage duration and claim procedures. For customer support, please visit the official RCA website or contact their customer service line. Information regarding extended protection plans may also be available from your retailer.

© 2025 RCA. All rights reserved.

Related Documents - RFR786-BLACK

	<p><u>RCA RFR176-C-BLACK Retro 1.6 Cu. Ft. Refrigerator User Manual</u> Official user manual for the RCA RFR176-C-BLACK Retro 1.6 Cu. Ft. Refrigerator. Includes installation, operation, safety, care, and troubleshooting guides.</p>
	<p>User Manual of Product 1: RCA RFR786-BLACK Retro 1.6 Cu. Ft. Refrigerator User Manual ETL Certified Model: RFR786-BLACK</p> <p>User Manual of Product 2: BLACK+DECKER EM720CB7 Digital Microwave Oven with Turntable, 700W, 0.7 Cu. Ft, Child Safety Lock, 1000W, Stainless Steel, 0.7 Cu.Ft</p> <p><u>BLACK+DECKER EM720CB7 Digital Microwave Oven User Manual</u> Comprehensive user manual for the BLACK+DECKER EM720CB7 digital microwave oven, covering safety precautions, specifications, operation, maintenance, troubleshooting, and warranty information. Also includes details for the RCA RFR741-BLACK refrigerator.</p>

 <p>132x192mm</p>	<p><u>RCA RFR1085/RFR1085-BLACK Refrigerator/Freezer User Manual</u></p> <p>User manual for the RCA RFR1085/RFR1085-BLACK 10.0 cu ft refrigerator/freezer, covering safety instructions, operation, cleaning, maintenance, and troubleshooting.</p>
	<p><u>Fisher & Paykel RF610ANUB5 Freestanding French Door Refrigerator Freezer 90cm 569L Ice & Water - Quick Reference Guide</u></p> <p>Quick reference guide for the Fisher & Paykel RF610ANUB5 Freestanding French Door Refrigerator Freezer. Details features like ActiveSmart™ Foodcare, humidity control, ultra-slim water dispenser, spacious storage, dimensions, specifications, and warranty.</p>
	<p><u>Fisher & Paykel 569L Series 7 French Door Refrigerator Freezer with Ice & Water - Quick Reference Guide</u></p> <p>Quick reference guide for the Fisher & Paykel 569L Series 7 French Door Refrigerator Freezer, featuring ActiveSmart™ Foodcare, slimline water dispenser, internal ice maker, and detailed specifications. Includes dimensions, capacity, energy consumption, and warranty information.</p>
	<p><u>RCA RF454-BLACK Chest Freezer User Manual</u></p> <p>Comprehensive user manual for the RCA RF454-BLACK chest freezer, covering safety instructions, installation, operation, maintenance, and troubleshooting.</p>