

[Manuals.plus](#) /

› [Walker's](#) /

› Walker's Flexible Bluetooth Neckband Headset (GWP-RP-BT) User Manual

Walker's GWP-RP-BT

Walker's Flexible Bluetooth Neckband Headset (GWP-RP-BT) User Manual

Model: GWP-RP-BT

INTRODUCTION

The Walker's Flexible Bluetooth Neckband Headset provides passive hearing protection with a Noise Reduction Rating (NRR) of 30, combined with Bluetooth connectivity for audio streaming and call management. This headset features high dynamic range speakers and durable aluminum earbuds designed for comfort and functionality in various environments. The neckband design ensures secure wear, and the earbuds connect magnetically when not in use.

PACKAGE CONTENTS

Verify that all items are present in your package:

- Flexible Bluetooth Neckband Headset
- 3 Pairs of Foam Ear Tips (Small, Medium, Large)
- 12-inch USB Charging Cable
- EVA Storage Case



Image: All components included in the Walker's Flexible Bluetooth Neckband Headset package.

PRODUCT OVERVIEW

The headset consists of a flexible neckband, two earbuds, and an integrated control panel. The neckband is designed to rest comfortably around your neck, providing stability for the earbuds.

Neckband and Earbuds



Image: Full view of the Walker's Flexible Bluetooth Neckband Headset, illustrating the neckband and attached earbuds. The earbuds are made from durable aluminum and feature foam tips for passive noise reduction. They are designed to magnetically connect to each other when not in use, preventing tangling and ensuring secure storage around your neck.



Image: Close-up of the earbuds with foam tips, demonstrating their design and magnetic connection capability.

Control Panel

The control panel, located on the neckband, allows for power management, volume adjustment, music control, and call handling.





Image: Detailed view of the control panel, showing the various buttons for operation.

SETUP

Charging the Headset

1. Locate the USB charging port on the control panel.
2. Connect the supplied 12-inch USB charging cable to the headset's charging port.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., computer USB port, USB wall adapter).
4. The LED indicator on the control panel will illuminate during charging and change color or turn off when fully charged.
5. A full charge takes approximately 4 hours.

Fitting the Earbuds

Proper fit is crucial for both comfort and effective passive noise reduction.

1. Select the appropriate size of foam ear tips (Small, Medium, or Large) from the three pairs provided.
2. Gently compress the foam ear tip before inserting it into your ear canal.
3. Hold the earbud in place for a few seconds while the foam expands to create a seal.
4. Ensure a snug and comfortable fit to maximize the 30 NRR passive hearing protection.

Bluetooth Pairing

To connect your headset to a Bluetooth-enabled device:

1. Ensure the headset is charged and powered off.
2. Press and hold the multi-function button (often the power button) on the control panel until the LED indicator flashes rapidly, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), navigate to the Bluetooth settings and enable Bluetooth.
4. Search for available devices. The headset should appear as "Walker's GWP-RP-BT" or similar.
5. Select the headset from the list to initiate pairing.
6. Once paired, the LED indicator will typically show a solid blue light or flash slowly.
7. The headset will automatically attempt to reconnect to the last paired device when powered on.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Press and hold the multi-function button for approximately 3 seconds until the LED indicator lights up and you hear an audible prompt.
- **Power Off:** Press and hold the multi-function button for approximately 3-5 seconds until the LED indicator turns off and you hear an audible prompt.

Music Playback

- **Play/Pause:** Press the multi-function button once.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.

Call Management

- **Answer Call:** Press the multi-function button once.

- **End Call:** Press the multi-function button once during a call.
- **Reject Call:** Press and hold the multi-function button for approximately 2 seconds.
- **Redial Last Number:** Double-press the multi-function button.

MAINTENANCE

Cleaning

- Wipe the neckband and control panel with a soft, dry cloth.
- Remove ear tips and clean them with a mild soap solution and water. Ensure they are completely dry before reattaching.
- Do not immerse the headset in water as it is not water resistant.

Storage

- When not in use, store the headset in the provided EVA carrying case to protect it from dust, debris, and physical damage.
- Avoid storing in extreme temperatures or direct sunlight.

TROUBLESHOOTING

- **Headset does not power on:** Ensure the battery is charged. Connect the USB charging cable and allow it to charge for at least 30 minutes before attempting to power on again.
- **No sound:** Check that the headset is properly paired with your device. Increase the volume on both the headset and your connected device. Ensure the earbuds are correctly seated in your ears.
- **Cannot pair with device:** Make sure the headset is in pairing mode (rapidly flashing LED). Turn off and on your device's Bluetooth. Move the headset closer to your device (within 10 meters). If previously paired, try unpairing and re-pairing the device.
- **Poor sound quality:** Ensure the earbuds are clean and properly fitted. Check for interference from other wireless devices.
- **Short battery life:** Ensure the headset is fully charged before use. Battery life can vary based on usage (e.g., continuous Bluetooth streaming uses more power).

SPECIFICATIONS

Feature	Detail
Model Number	GWP-RP-BT
Noise Reduction Rating (NRR)	30 dB (Passive Noise Cancellation)
Connectivity	Bluetooth 5.0 (Wireless)
Bluetooth Range	Up to 10 meters
Battery Life	15 hours (total), 4 hours (Bluetooth streaming)
Battery Charge Time	4 hours

Audio Driver Type	Dynamic Driver
Frequency Range	20 Hz - 20,000 Hz
Impedance	30 ohm
Earbud Material	Durable Aluminum
Carrying Case Material	EVA foam
Water Resistance	Not Water Resistant
Product Dimensions	6.1 x 1.5 x 4.5 inches
Item Weight	3.84 ounces

WARRANTY INFORMATION

This Walker's Flexible Bluetooth Neckband Headset is covered by a **1 Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. For specific terms and conditions, please refer to the warranty documentation included with your product or contact Walker's customer support.

SUPPORT

For further assistance, technical support, or warranty claims, please contact Walker's customer service. Refer to the official Walker's website or product packaging for the most current contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question