Gorilla Carts 4GCG-NF

Gorilla Carts Heavy-Duty Dump Cart User Manual

Model: 4GCG-NF

Introduction

Welcome to the user manual for your Gorilla Carts Heavy-Duty Dump Cart. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new cart. Please read this manual thoroughly before use and retain it for future reference.

The Gorilla Carts 4 cu. ft. Poly Garden Dump Cart is designed for various outdoor projects, offering a 600 lb capacity and durable no-flat tires. Its patented quick-release dumping system simplifies material handling, making it ideal for gardening, yard work, and farming tasks.



Figure 1: Gorilla Carts Heavy-Duty Dump Cart (Model 4GCG-NF)

Safety Information

Always observe basic safety precautions when using this product to reduce the risk of injury or damage.

- **Read the Manual:** Familiarize yourself with all instructions and warnings before operation.
- **Weight Capacity:** Do not exceed the maximum load capacity of 600 pounds (272 kg). Overloading can cause damage to the cart and potential injury.
- **Secure Loads:** Ensure all loads are stable and centered in the cart bed to prevent tipping during transport or dumping.
- **Terrain:** Use on relatively level ground. Avoid steep inclines or uneven terrain that could cause the cart to tip.
- **Children and Pets:** Keep children and pets away from the cart during operation and storage. This is not a toy.
- **Maintenance:** Regularly inspect the cart for loose fasteners, damaged parts, or worn tires. Replace or repair as

needed before use.

- **Dumping:** When using the quick-release dump feature, ensure the area is clear and stable. Maintain a firm grip on the handle.

Setup and Assembly

The Gorilla Carts Heavy-Duty Dump Cart requires assembly. Follow these steps carefully. It is recommended to have a second person assist with assembly.

Tools Required:

- Adjustable Wrench or Socket Set (13mm recommended)
- Rubber Mallet (optional, for axle caps)

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify all components are present against the parts list (refer to the included assembly diagram).
2. **Attach Front Axle Assembly:** Secure the front axle assembly to the cart frame using the provided bolts and nuts. Ensure all connections are tight.
3. **Attach Rear Axle Assembly:** Secure the rear axle assembly to the cart frame.
4. **Install Wheels:** Slide the no-flat tires onto the axles. Secure them with the washers and cotter pins, or axle caps as per the assembly instructions.
5. **Assemble Handle:** Connect the handle components and attach the assembled handle to the front axle assembly. Ensure the quick-release mechanism operates smoothly.
6. **Attach Poly Bed:** Place the poly bed onto the assembled frame and secure it using the designated fasteners.
7. **Final Check:** Double-check all bolts, nuts, and fasteners to ensure they are securely tightened before first use.



Figure 2: Cart Dimensions and Components (for assembly reference)

Operating Instructions

This section details the proper use of your Gorilla Carts Heavy-Duty Dump Cart.

Loading the Cart:

- Distribute the load evenly across the poly bed to maintain balance and stability.
- Do not exceed the 600 lb (272 kg) weight capacity.
- For bulky items, ensure they are securely placed and will not shift during transport.



Figure 3: Balanced Hauling with the Dump Cart

Transporting Materials:

- Use the handle to pull or push the cart. The unique design allows for easy maneuverability.
- Navigate slowly over uneven terrain to prevent tipping.
- Avoid sudden stops or turns, especially with heavy loads.



Figure 4: Maneuverability - Push or Pull Design

Dumping Mechanism:

The cart features a patented quick-release dumping system for effortless unloading.

1. **Position the Cart:** Move the cart to the desired dumping location.
2. **Engage Release:** Locate the yellow quick-release handle near the front of the cart. Pull the handle upwards to disengage the locking mechanism.
3. **Tilt and Dump:** While holding the release handle, lift the main handle and tilt the poly bed forward. The cart's design allows the bed to tilt into an upended position while maintaining balance.
4. **Return to Position:** Once unloaded, lower the poly bed back into its horizontal position until the quick-release mechanism locks into place. Ensure it is securely latched before moving the cart.



Figure 5: Patented Quick-Release Dumping System in action

Maintenance

Regular maintenance will extend the life of your Gorilla Carts Dump Cart.

- **Cleaning:** The poly bed is easy to clean. Rinse with water after each use, especially when hauling dirt, fertilizer, or other corrosive materials.
- **Inspection:** Periodically check all bolts, nuts, and fasteners for tightness. Tighten any loose hardware.
- **Lubrication:** Apply a light lubricant to moving parts, such as the quick-release mechanism and axle points, annually or as needed to ensure smooth operation.
- **Tires:** The 10-inch no-flat foam-filled tires are maintenance-free and do not require inflation. Inspect them for any signs of damage or excessive wear.
- **Storage:** Store the cart in a dry, covered area to protect it from extreme weather conditions and prolong its lifespan.



Figure 6: Durable and Weather-Resistant Construction

Troubleshooting

This section addresses common issues you might encounter with your dump cart.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Cart is difficult to pull or push.	◦ Overloaded. ◦ Uneven load distribution. ◦ Loose wheel fasteners. ◦ Debris in wheel axles.	◦ Reduce load to within 600 lb capacity. ◦ Distribute load evenly. ◦ Check and tighten all wheel fasteners. ◦ Clean any debris from around the axles.
Dumping mechanism sticks or is hard to engage.	◦ Lack of lubrication. ◦ Debris in the mechanism. ◦ Bent or damaged components.	◦ Apply a light lubricant to the quick-release mechanism. ◦ Clean any debris from the mechanism. ◦ Inspect for damage; contact customer support if components are bent.
Cart feels unstable or wobbly.	◦ Loose frame bolts. ◦ Uneven ground. ◦ Damaged wheel or axle.	◦ Check and tighten all frame and axle bolts. ◦ Operate on level ground where possible. ◦ Inspect wheels and axles for damage; replace if necessary.

Specifications

Detailed specifications for the Gorilla Carts Heavy-Duty Dump Cart (Model 4GCG-NF).

Model Number: 4GCG-NF

Product Dimensions (L x W x H): 40" x 22" x 8" (Bed dimensions)

Capacity: 4 Cubic Feet

Weight Limit: 600 Pounds (272 kg)

Item Weight: 33.4 Pounds (15.15 kg)

Bed Material: Maintenance-Free Poly

Frame Material: Alloy Steel

Tire Type: 10-inch No-Flat Foam-Filled (Tubeless)

Number of Wheels: 4

Assembly Required: Yes

UPC: 722571013318



Figure 7: Key Specifications Visualized

Warranty and Support

Your Gorilla Carts Heavy-Duty Dump Cart is backed by a **1-year limited warranty**.

This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, abuse, accidents, modifications, or improper maintenance.

For warranty claims, replacement parts, or technical assistance, please contact Gorilla Carts customer support. Refer to the official Gorilla Carts website for the most current contact information.

Online Resources:

- Official Gorilla Carts Store: Visit Store
- User Manual (PDF): Download PDF

© 2025 Gorilla Carts. All rights reserved.
This manual is for informational purposes only. Gorilla Carts reserves the right to make changes to products and specifications at any time without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question