

Hasbro F1119

STAR WARS The Child Animatronic Edition F1119 Instruction Manual

PRODUCT OVERVIEW

The STAR WARS The Child Animatronic Edition is a 7.2-inch-tall interactive toy designed to bring the beloved character to life. This figure features over 25 sound and motion combinations, responding to touch and interaction. Its head moves up and down, ears move back and forth, and eyes open and close, mimicking the character's expressions and actions from the series.



Figure of The Child Animatronic Edition with eyes open, showcasing its detailed design and fabric robe.

SETUP

1. Unboxing

Carefully remove The Child Animatronic Edition from its packaging. Ensure all components are present.



The Child Animatronic Edition displayed in its original packaging.

2. Battery Installation

1. Locate the battery compartment on the underside of the figure.
2. Using a Phillips head screwdriver, open the battery compartment cover.
3. Insert 3 AAA batteries, ensuring correct polarity (+/-). The batteries are included with the product.
4. Replace the battery compartment cover and secure it with the screw.

OPERATING INSTRUCTIONS

The Child Animatronic Edition offers various interactive modes and responses.

1. Activating Sounds and Motions

- **Touch Activation:** Gently touch the top of The Child's head to activate over 25 sound and motion combinations. These include happy and excited sounds, giggles, and babbles. The figure's head will move up and down, ears will move back and forth, and eyes will open and close in response.
- **Force Activation:** When interacting, The Child may close its eyes, raise its arm, and sigh, simulating the use of the Force.



A child interacting with The Child Animatronic Edition by touching its head.



The Child Animatronic Edition demonstrating a Force-like action with closed eyes and raised arm.

2. Positional Responses

- The figure responds differently based on its orientation. Lay it on its back or belly to observe varied sounds and movements.



The Child Animatronic Edition with its ears in motion, demonstrating one of its animatronic features.

3. Official Product Video

Your browser does not support the video tag.

An official video demonstrating the various sounds and motions of the STAR WARS The Child Animatronic Edition.

MAINTENANCE

1. Cleaning

To clean the figure, gently wipe the surface with a soft, damp cloth. Do not immerse the toy in water or use harsh cleaning agents.

2. Storage

Store the toy in a cool, dry place away from direct sunlight and extreme temperatures to preserve its electronic components and materials.

TROUBLESHOOTING

No Sound or Motion

- Ensure the batteries are correctly installed with the proper polarity.
- Replace old batteries with fresh AAA batteries.
- Check if the power switch (located on the battery compartment) is in the 'ON' position.

SPECIFICATIONS

- **Model Number:** F1119

- **Dimensions:** 8.27 x 3.15 x 8.27 inches
- **Weight:** 14.29 ounces
- **Batteries:** 3 AAA batteries (included)
- **Recommended Age:** 4 years and up
- **Release Date:** October 29, 2020





SAFETY INFORMATION


WARNING: This product may contain sharp points, small parts that are choking hazards, and other elements that are not suitable for children under 3 years of age.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Hasbro website.

Related Documents - F1119

	<p>furReal Flyalots Flitter My Alicorn Toy Instructions</p> <p>Official instructions for the furReal Flyalots Flitter My Alicorn interactive toy from Hasbro. Learn how to operate the toy and its features.</p>
	<p>Darth Vader Lightsaber Forge Toy - FCC Compliance and Battery Safety Information</p> <p>Official FCC compliance statement and multilingual battery safety instructions for the Hasbro Darth Vader Lightsaber Forge toy. Includes model numbers and brand information.</p>
	<p>Star Wars Mission Fleet Expedition Class The Mandalorian The Child Speeder Assembly Instructions</p> <p>Official assembly instructions for the Star Wars Mission Fleet Expedition Class The Mandalorian The Child Battle for the Bounty figures and vehicle, including safety warnings and manufacturer details from Hasbro.</p>
	<p>Star Wars Lightsaber Forge Obi-Wan Kenobi Toy Instructions</p> <p>Assembly and usage instructions for the Star Wars Lightsaber Forge Obi-Wan Kenobi toy. Learn how to combine and extend the lightsaber components.</p>



[Star Wars The Black Series Obi-Wan Kenobi Force FX Elite Lightsaber - Assembly and Operation Guide](#)

Detailed instructions for assembling and operating the Star Wars The Black Series Obi-Wan Kenobi Force FX Elite Lightsaber, including descriptions of its light and sound effects, and compliance information.



[Star Wars R2-D2 Interactive Astromech Droid Operation Manual](#)

Official operation manual for the Hasbro Star Wars R2-D2 interactive astromech droid. Covers assembly, battery installation, voice commands, companion mode, game modes, command mode, troubleshooting, and technical specifications for ages 8+.