MOFII gertqe-460

MOFII Wireless Keyboard and Mouse Combo User Manual

Model: gertqe-460

Brand: MOFII

Product Overview

The MOFII Wireless Keyboard and Mouse Combo (Model: gertqe-460) offers a convenient and stylish solution for your computing needs. This 2.4G USB multi-color set features a full-size keyboard with retro round keycaps and an optical mouse, designed for comfortable and efficient use with various devices.



Image: The MOFII Pink-Mixed Wireless Keyboard and Mouse Combo, showcasing the full-size keyboard with round, multi-colored keycaps and the matching optical mouse.

Key Features:

- **Easy 2.4G Wireless Connection:** Utilizes a single 2.4G Nano Receiver for a stable and straightforward connection to your devices.
- **Retro Round Keycaps:** Features aesthetically pleasing round keys in a multi-color design, providing a unique visual and tactile experience.
- **Intelligent Power Saving:** Equipped with a smart power-saving chip and three power-saving modes, allowing the keyboard and mouse to operate for extended periods on 2 AA batteries (included).
- **Wide Compatibility:** Compatible with Windows (7/8/10), XP, Mac, Macbook Vista, and other systems with a USB port.
- **Full-Size Layout:** The keyboard features a full-size layout, including a numeric keypad, to meet all your typing requirements.

Setup Guide

1. Unboxing and Component Check:

Carefully remove all components from the packaging. Ensure you have the following items:

- MOFII Wireless Keyboard
- MOFII Optical Mouse
- 2.4G USB Nano Receiver (typically stored in the mouse battery compartment)
- 2 x AA Batteries (pre-installed or included separately)

2. Battery Installation:

The combo requires 2 AA batteries. If not pre-installed, open the battery compartment on the underside of both the keyboard and the mouse. Insert the AA batteries, ensuring correct polarity (+/-). Close the battery compartments securely.

3. Connecting the USB Nano Receiver:

Locate the 2.4G USB Nano Receiver. It is often stored in a small slot within the mouse battery compartment for convenience during transport. Remove the receiver.

Image: A close-up of the compact USB Nano Receiver, which enables wireless connectivity for both the keyboard and mouse.

Plug the USB Nano Receiver into an available USB port on your computer (desktop PC, laptop, etc.).

4. Powering On:

Turn on the power switch for both the keyboard and the mouse. The power switch for the mouse is typically on its underside. The keyboard usually activates automatically once batteries are inserted and the receiver is connected. Your computer should automatically detect and install the necessary drivers. This is usually a plug-and-play process, and no additional software installation is required.

Operating Instructions

Keyboard Usage:

The MOFII keyboard features a standard full-size layout with a numeric keypad for efficient data entry. The round keycaps provide a comfortable typing experience.



Image: A detailed view of the MOFII keyboard's round, multi-colored keycaps, highlighting their unique design and layout.

Function Keys (Fn Combinations):

Some keys have dual functions, accessible by pressing the**Fn** key simultaneously with the desired function key (F1-F12). Refer to the icons on the keys for specific functions such as media control, volume adjustment, and more.

Mouse Usage:

The optical mouse provides precise tracking and comfortable grip. It features standard left-click, right-click, and scroll wheel functions.



Image: A close-up shot showing the MOFII optical mouse positioned next to the keyboard, emphasizing their coordinated design.

Power Saving Modes:

To conserve battery life, the combo is designed with intelligent power-saving features. If inactive for a period, the devices will enter a sleep mode. To wake them up, simply press any key on the keyboard or move/click the mouse.

Your browser does not support the video tag.

Video: An official product video from TzBBL showcasing the MOFII 104 Wireless Keyboard and Mouse Combo, demonstrating its design and various color options. This video is 43 seconds long.

Maintenance

Cleaning:

- Use a soft, dry, lint-free cloth to wipe down the surfaces of the keyboard and mouse.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.

- Do not spray cleaners directly onto the devices.
- For cleaning between keycaps, use compressed air to remove dust and debris.

Battery Replacement:

When the devices stop responding or show signs of low power, it's time to replace the batteries. Open the battery compartment on the underside of the keyboard and mouse, remove the old AA batteries, and insert new ones, observing correct polarity. Dispose of old batteries responsibly.

Storage:

When not in use for extended periods, it is recommended to turn off the power switch on both the keyboard and mouse to further conserve battery life. Store the devices in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Device Not Responding:

- **Check Batteries:** Ensure batteries are correctly installed and have sufficient charge. Replace if necessary.
- **Power Switch:** Verify that the power switches on both the keyboard and mouse are in the "ON" position.
- **USB Receiver:** Ensure the 2.4G USB Nano Receiver is securely plugged into a working USB port on your computer. Try a different USB port.
- **Distance:** Make sure the keyboard and mouse are within the effective operating range (typically up to 10 meters) of the USB receiver.
- **Interference:** Move the devices away from other wireless devices or large metal objects that might cause interference.

Lag or Intermittent Connection:

- **Battery Level:** Low battery can cause performance issues. Replace batteries.
- **USB Port:** Try plugging the USB receiver into a different USB port, preferably a direct port on the computer rather than a USB hub.
- **Interference:** Reduce potential interference from other 2.4GHz devices (e.g., Wi-Fi routers, cordless phones).

Keys Not Registering / Mouse Not Tracking:

- **Clean Devices:** Dust or debris under keys or obstructing the mouse's optical sensor can cause issues. Clean thoroughly.
- **Surface (Mouse):** Ensure the mouse is used on a suitable, non-reflective surface.
- **Re-pair (if applicable):** While typically plug-and-play, some wireless devices have a re-pairing button. Consult the manufacturer's website if issues persist.

Technical Specifications



Image: A diagram illustrating the dimensions of the MOFII keyboard and mouse, including length, width, and height measurements.

Feature	Detail
Brand	MOFII
Model Number	gertqe-460
Color	Pink-Mixed
Connectivity Technology	2.4G Wireless (USB Nano Receiver)
Special Feature	Round Keycaps
Compatible Devices	Windows 7/8/10, Mac, XP, Macbook Vista (systems with USB port)
Keyboard Layout	Full Size with Numeric Keypad

Feature	Detail
Power Source	2 x AA Batteries (included)
Item Weight	2.82 ounces (approx. 80 grams)
Package Dimensions	21.5 x 5.75 x 1.89 inches (approx. 54.6 x 14.6 x 4.8 cm)

Warranty Information

For specific warranty details regarding your MOFII Wireless Keyboard and Mouse Combo, please refer to the warranty card included in your product packaging or visit the official MOFII website. Standard warranties typically cover manufacturing defects for a specified period from the date of purchase.

Customer Support

If you encounter any issues or have questions about your MOFII Wireless Keyboard and Mouse Combo that are not covered in this manual, please contact MOFII customer support. You can typically find contact information (email, phone, or support portal) on the official MOFII website or through the retailer where you purchased the product.
For additional resources and product information, you may visit theMOFII Store on Amazon.

© 2024 MOFII. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question