

Paw Patrol 6059994

Paw Patrol Dino Rescue Zuma and Brontosaurus Pack Instruction Manual

1. INTRODUCTION

This manual provides instructions for the Paw Patrol Dino Rescue Zuma and Brontosaurus Pack. This action figure set includes a Zuma figure, a large-scale Brontosaurus dinosaur, and a mystery mini dinosaur figure. Please read these instructions carefully before use to ensure proper operation and enjoyment.

2. WHAT'S IN THE BOX

Carefully unpack all contents and ensure all items are present:

- 1 x Zuma Figure
- 1 x Brontosaurus Dinosaur Figure
- 1 x Mystery Dino Figure



Image 2.1: Contents of the Paw Patrol Dino Rescue Zuma and Brontosaurus Pack as seen in the box.

3. SETUP

No assembly is required for this product. Simply remove the figures from their packaging to begin play.

4. OPERATING INSTRUCTIONS

4.1 Zuma Figure

The Zuma figure features a working tool that pops out from his backpack.

1. Locate the badge button on Zuma's uniform.
2. Press the badge button firmly to activate the backpack tool, causing it to transform and pop open.



Image 4.1: Zuma figure with his backpack tool. The Brontosaurus is shown next to him.

4.2 Brontosaurus Dinosaur Figure

The large-scale Brontosaurus figure has a movable neck feature.

1. Gently hold the Brontosaurus figure.
2. Push the Brontosaurus' tail back and forth to make its neck move up and down.



Image 4.2: Side view of the Zuma figure and the Brontosaurus, highlighting the tail and neck mechanism.

4.3 Mystery Dino Figure

The pack includes a surprise mystery mini dinosaur figure.

1. Open the designated compartment or packaging within the main box to reveal the mystery dino figure.
2. The mystery dino figure is ready for immediate play.



Image 4.3: Example of various mystery mini dinosaur figures that may be included.

5. MAINTENANCE

To keep your Paw Patrol Dino Rescue figures in good condition:

- **Cleaning:** Wipe figures with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store figures in a cool, dry place away from direct sunlight to prevent fading or material degradation.

6. TROUBLESHOOTING

If you encounter any issues with your figures, refer to the following common solutions:

Problem	Possible Cause / Solution
Zuma's backpack tool does not pop open.	Ensure the badge button is pressed firmly and completely. Check for any small obstructions around the mechanism.
Brontosaurus neck does not move.	Confirm that the tail is being pushed back and forth with sufficient movement. The mechanism requires a full range of motion.

7. SPECIFICATIONS

- **Product Dimensions:** 2.56 x 7.13 x 5.63 inches
- **Item Weight:** 4.9 ounces
- **Item Model Number:** 6059994
- **Manufacturer Recommended Age:** 36 months - 9 years
- **Manufacturer:** Spin Master
- **ASIN:** B084R2V7JD

8. WARRANTY AND SUPPORT

This product is covered by the Spin Master Care Commitment. For details regarding warranty, returns, or customer support, please refer to the information provided with your purchase or visit the official Spin Master website.