Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XPG SUMMONER4C-BKCWW

XPG Summoner RGB Keyboard Series User Manual

Model: SUMMONER4C-BKCWW | Brand: XPG

Introduction

The XPG Summoner RGB Keyboard Series is a high-performance mechanical keyboard designed for gaming and everyday use. It features durable Cherry MX key switches, customizable RGB backlighting, and convenient media controls. This manual provides detailed instructions for setting up, operating, and maintaining your XPG Summoner keyboard.

Package Contents

- XPG Summoner RGB Keyboard
- Detachable Magnetic Wrist Rest
- Additional Keycaps (red, 8 pieces)
- Keycap Puller
- Quick Start Guide



Image: Contents of the XPG Summoner RGB Keyboard package, showing the keyboard, detachable wrist rest, user manual, and a set of red replacement keycaps with a keycap puller.

Setup

1. **Connect the Keyboard:** Plug the USB connector of the XPG Summoner keyboard into an available USB port on your computer. The keyboard is plug-and-play and should be recognized automatically by your operating system.
2. **Attach the Wrist Rest:** Align the magnetic wrist rest with the front edge of the keyboard. The magnets will secure it in place, providing ergonomic support during use.
3. **Install XPG Prime Software (Optional):** For advanced customization of macros, game profiles, and RGB lighting effects, download and install the XPG Prime software from the official XPG website.
4. **USB Passthrough:** The keyboard features a convenient USB passthrough port. Connect USB drives or wireless dongles to this port for quick access.



Image: A close-up view of the XPG Summoner keyboard's side, highlighting the USB passthrough port for connecting additional devices.

Operating Instructions

Key Features and Functions

- **Cherry MX Mechanical Switches:** The keyboard is equipped with Cherry MX Blue mechanical switches, providing tactile feedback and an audible click for each keystroke.



Image: A detailed view of the XPG Summoner keyboard's keys, showcasing the Cherry MX Blue mechanical switches with their distinct blue backlighting.

- **RGB Backlighting:** The keyboard features per-key RGB backlighting with 7 preset modes. These modes can be customized further using the XPG Prime software.



Image: The XPG Summoner RGB Keyboard illuminated with a spectrum of colors, demonstrating its customizable backlighting capabilities.

- **Media Control Wheel:** An intuitive media control wheel allows for easy and quick volume adjustment.
- **Macro Keys:** Record complex sequences and assign them to designated macro keys for quick execution.
- **100% Anti-Ghosting:** Ensures all key presses are registered accurately, even during rapid, simultaneous keystrokes.

Function Key Combinations (FN + Key)

Combination	Function
FN + F1	My Computer
FN + F2	Search
FN + F3	Calculator
FN + F4	Media Player
FN + F5	Previous Track
FN + F6	Next Track
FN + F7	Play/Pause
FN + F8	Stop
FN + F9	Mute
FN + F10	Volume Down
FN + F11	Volume Up
FN + F12	Lock Keyboard
FN + Windows Key	Toggle Game Mode (disables Windows key)
FN + Insert	Toggle RGB Lighting Modes
FN + Up/Down Arrow	Adjust Brightness
FN + Left/Right Arrow	Adjust Lighting Speed/Direction

Maintenance

- **Cleaning:** Regularly clean the keyboard with a soft, dry cloth. For deeper cleaning, use compressed air to remove dust and debris from between the keycaps. Avoid using harsh chemicals or abrasive materials.
- **Keycap Removal:** If necessary, use the provided keycap puller to carefully remove keycaps for cleaning or replacement. Pull straight up to avoid damaging the switch.
- **Storage:** When not in use for extended periods, store the keyboard in a clean, dry environment away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Solution
Keyboard not responding.	◦ Ensure the USB cable is securely connected to the computer. ◦ Try connecting the keyboard to a different USB port. ◦ Restart your computer. ◦ Check if the keyboard is locked (FN + F12).
RGB lighting not working or incorrect.	◦ Press FN + Insert to cycle through lighting modes. ◦ Ensure XPG Prime software is installed and updated. ◦ Check lighting settings within the XPG Prime software.
Keys not registering or ghosting.	◦ Clean under the affected keycaps. ◦ Ensure the keyboard is connected directly to the computer, not through a faulty USB hub.
XPG Prime software issues.	◦ Ensure your operating system is up to date. ◦ Reinstall the XPG Prime software from the official XPG website. ◦ Check for software updates within the application.

Specifications

- **Model:** SUMMONER4C-BKCWW
- **Dimensions:** 9 x 20 x 3 inches
- **Weight:** 3.44 pounds
- **Key Switches:** Cherry MX Blue Mechanical
- **Backlighting:** Per-Key RGB
- **Connectivity:** USB
- **Features:** Magnetic Wrist Rest, USB Passthrough, Media Control Wheel, 100% Anti-Ghosting
- **Manufacturer:** Adata

Warranty and Support

For warranty information and technical support, please visit the official XPG website or contact XPG customer service. Keep your purchase receipt for warranty claims.
Official XPG Website: www.xpg.com

Product Video

Your browser does not support the video tag.

Video: An official product video showcasing the features and design of the XPG Summoner RGB Keyboard, including its Cherry MX switches, RGB lighting, and ergonomic wrist rest.

© 2024 XPG. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B084S16JG1

More documents and user manuals: **https://manuals.plus/**