

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Mothercare](#) /

› [Mothercare NC061 2-in-1 Bottle Warmer and Sterilizer Instruction Manual](#)

Mothercare NC061

Mothercare NC061 2-in-1 Bottle Warmer and Sterilizer Instruction Manual

Model: NC061

1. INTRODUCTION

Thank you for choosing the Mothercare NC061 2-in-1 Bottle Warmer and Sterilizer. This appliance is designed to quickly and easily warm your baby's milk or food and also provides a convenient sterilizing function for single bottles. Please read this instruction manual carefully before use and keep it for future reference.

2. SAFETY INFORMATION

- Always keep the appliance out of reach of children.
- Do not immerse the main unit in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Unplug the appliance from the mains socket when not in use and before cleaning.
- Do not operate the appliance if it has a damaged cord or plug, or if it malfunctions or has been damaged in any way.
- Use only accessories recommended by the manufacturer.
- Hot steam is released during operation. Exercise caution to avoid burns.
- Always check the temperature of the milk or food before feeding your baby.
- This appliance is for household use only.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all items are present and in good condition. The package should contain:

- 1 x Mothercare 2-in-1 Bottle Warmer and Sterilizer Main Unit
- 1 x Bottle Basket for safe and easy handling
- 1 x Measuring Cup
- 1 x Tongs

- 1 x Sterilizer Lid/Cover



Image: All included components of the Mothercare Bottle Warmer Set.

4. PRODUCT OVERVIEW

Familiarize yourself with the different parts of your Mothercare 2-in-1 Bottle Warmer and Sterilizer.



Image: Main unit of the Mothercare Bottle Warmer.

- **Main Unit:** The base unit containing the heating element and control panel.
- **Control Panel:** Features buttons for power, mode selection, and temperature adjustment, along with a digital display.
- **Heating Chamber:** The internal area where bottles or food jars are placed for warming or sterilizing.
- **Bottle Basket:** Used to safely place and remove bottles or food jars from the heating chamber.
- **Sterilizer Lid:** Placed over the main unit for the sterilizing function.

5. SETUP

1. **Unpack:** Remove all components from the packaging.
2. **Clean:** Before first use, clean all parts that will come into contact with milk or food according to the "Cleaning and Maintenance" section.
3. **Placement:** Place the main unit on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources.

4. **Connect:** Plug the power cord into a suitable electrical outlet. The appliance is now ready for use.

6. OPERATING INSTRUCTIONS

6.1. Warming Milk or Food

1. Place the bottle or food jar into the bottle basket.
2. Pour the appropriate amount of clean water into the heating chamber. Refer to the measuring cup for guidance. The water level should be below the rim of the bottle/jar and cover the milk/food level.
3. Place the bottle basket with the bottle/jar into the heating chamber.
4. Press the power button to turn on the appliance.
5. Select the warming mode (e.g., milk warming or food warming) using the mode button. The appliance is designed to heat to approximately 37 degrees Celsius for milk.
6. The appliance will begin heating. A light indicator or display will show the progress.
7. Once warming is complete (approximately 8 minutes for milk, depending on volume and starting temperature), carefully remove the bottle basket using the tongs provided.
8. Always shake the bottle gently to distribute heat evenly and check the temperature of the milk or food on your wrist before feeding your baby.

6.2. Sterilizing a Single Bottle

This function is suitable for sterilizing a single baby bottle and its components.

1. Ensure the bottle and its components (teat, ring, cap) are thoroughly cleaned before sterilizing.
2. Place the disassembled bottle components into the bottle basket.
3. Pour approximately 100ml of clean water into the heating chamber using the measuring cup.
4. Place the bottle basket with components into the heating chamber.
5. Place the sterilizer lid securely over the main unit.
6. Press the power button and select the sterilizing mode.
7. The appliance will generate steam to sterilize the items. This process typically takes a few minutes.
8. Once the cycle is complete, the appliance will switch off or indicate completion. Allow the unit to cool down before opening the lid.
9. Carefully remove the sterilized items using the tongs to avoid contamination and burns.

7. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and hygiene.

- **Before Cleaning:** Always unplug the appliance and allow it to cool down completely.
- **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
- **Heating Chamber:** After each use, empty any remaining water. To remove mineral deposits (limescale), mix 50ml of white vinegar with 100ml of cold water and pour into the heating chamber. Let it stand for 30 minutes, then pour out the solution. Rinse thoroughly with clean water. Do not scrub with abrasive materials.
- **Accessories:** The bottle basket, measuring cup, tongs, and sterilizer lid can be washed in warm soapy water and rinsed thoroughly, or placed in the top rack of a dishwasher.

- **Storage:** Store the clean and dry appliance in a cool, dry place, out of reach of children.

8. TROUBLESHOOTING

- **Appliance does not turn on:**
 - Check if the power cord is securely plugged into the wall outlet and the appliance.
 - Ensure the wall outlet is functioning correctly by testing it with another appliance.
- **Milk/Food not warming sufficiently:**
 - Ensure enough water has been added to the heating chamber.
 - Verify that the correct warming mode has been selected.
 - The starting temperature of the milk/food and the volume can affect warming time. Allow more time for larger volumes or colder starting temperatures.
- **Sterilization cycle seems too short/long:**
 - Ensure the correct amount of water (approx. 100ml) is used for sterilization.
 - Make sure the sterilizer lid is properly seated.
- **Limescale buildup:**
 - Refer to the "Cleaning and Maintenance" section for descaling instructions. Regular descaling is important, especially in hard water areas.

9. SPECIFICATIONS

Model Number	NC061
Material	Other (typically food-grade plastic)
Product Dimensions (LxWxH)	17.3 x 13.2 x 13.2 cm
Item Weight	949 g
Batteries Required	No
Portability	Yes
Included Components	Bottle Warmer Set (Main Unit, Bottle Basket, Measuring Cup, Tongs, Sterilizer Lid)

10. WARRANTY AND SUPPORT

Mothercare products are manufactured to high-quality standards. For information regarding warranty, returns, or technical support, please refer to the warranty card included with your purchase or visit the official Mothercare website. You may also contact Mothercare customer service directly for assistance.

For more information, visit the [Mothercare Store on Amazon](#).



