Altec Lansing IMW580L-BLK

Altec Lansing LifeJacket Jolt - Waterproof Bluetooth Speaker User Manual

Your guide to setting up, operating, and maintaining your Altec Lansing LifeJacket Jolt speaker.

1. GETTING STARTED

This section will guide you through the initial steps to get your LifeJacket Jolt speaker ready for use.

1.1 What's in the Box?

- Altec Lansing LifeJacket Jolt Speaker
- USB Charging Cable
- Quick Start Guide (refer to this manual for detailed instructions)

1.2 Product Overview

Familiarize yourself with the various components and controls of your speaker.



Figure 1: Front view of the LifeJacket Jolt speaker, highlighting the speaker grilles and Altec Lansing logo.



Figure 2: Top view of the LifeJacket Jolt speaker, displaying the power button, Bluetooth pairing button, volume controls, and the Qi wireless charging pad.

Power Button: Press and hold to turn the speaker on or off.

Bluetooth Pairing Button: Press to enter Bluetooth pairing mode.

Volume Up/Down Buttons: Adjust the audio volume.

Qi Wireless Charging Pad: Place compatible devices here for wireless charging.

USB Charging Port: Located under a protective flap, used for charging the speaker and for wired device charging.

Auxiliary Input: For connecting devices via a 3.5mm audio cable.

2. SETUP

2.1 Charging the Speaker

Before first use, fully charge your LifeJacket Jolt speaker. A full charge provides up to 30 hours of playtime.

- 1. Locate the USB charging port on the speaker, usually under a protective rubber flap.
- 2. Connect the supplied USB charging cable to the speaker's USB port.
- 3. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.
- 4. The charging indicator light will show the charging status. Once fully charged, the light will change or turn off.

The speaker also features a Qi Wireless Charging Pad on top, allowing you to charge compatible smartphones by simply placing them on the pad while the speaker is powered on.



Figure 3: The LifeJacket Jolt speaker demonstrating Qi wireless charging for a smartphone.

2.2 Pairing with Bluetooth

Follow these steps to connect your speaker to a Bluetooth-enabled device.

- 1. Power on the LifeJacket Jolt speaker by pressing and holding the Power button.
- 2. The speaker will automatically enter Bluetooth pairing mode, indicated by a flashing Bluetooth indicator light.
- 3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
- 4. Select "LifeJacket Jolt" from the list of found devices.
- 5. Once connected, the Bluetooth indicator light on the speaker will become solid, and you will hear an audible confirmation.

Your speaker is now ready to play audio wirelessly.

3. OPERATING INSTRUCTIONS

3.1 Basic Controls

Button/Function	Action	Description
Power	Press and Hold	Turns the speaker On/Off.
Bluetooth	Press	Enters Bluetooth pairing mode.
Volume +	Press	Increases volume.
Volume -	Press	Decreases volume.
Play/Pause	Press	Plays or pauses current audio.
Track Skip (Forward)	Double Press (Play/Pause)	Skips to the next track.

Button/Function	Action	Description
Track Skip (Backward)	Triple Press (Play/Pause)	Skips to the previous track.

3.2 Voice Assistant Integration

The LifeJacket Jolt speaker supports voice assistant commands through your connected device.

- Ensure your speaker is connected to your smartphone via Bluetooth.
- Press the dedicated Voice Assistant button (often indicated by a microphone icon) on the speaker.
- Your device's voice assistant (Siri, Google Assistant, etc.) will activate, and you can speak your command through the speaker's microphone.




Figure 4: Activating the voice assistant feature on the LifeJacket Jolt speaker.

Note: There are no official product videos from the seller demonstrating the voice assistant feature. The available videos are from influencers and are not included as per instructions.

3.3 Lighting Modes

The LifeJacket Jolt features multi-color LED lights that can be customized.

- Press the Light Mode button (often indicated by a light bulb icon) to cycle through different lighting effects.
- Available modes may include solid colors, pulsing to the beat of the music, or a rotating color display.



Figure 5: The LifeJacket Jolt speaker with its LED lights active.

3.4 Waterproof and Durability Features

The LifeJacket Jolt is designed for rugged use, featuring an IP67 rating.

- **IP67 Rated:** This means the speaker is waterproof, dirtproof, and snowproof. It can be submerged in water up to 1 meter for 30 minutes.
- Floatable: The speaker is designed to float, making it ideal for use near water.
- Shockproof: Its durable construction protects against drops and impacts.



Figure 6: The LifeJacket Jolt speaker demonstrating its floatable design in water.



Figure 7: The LifeJacket Jolt speaker on a sandy beach with waves, showcasing its waterproof capabilities.

4. MAINTENANCE

Proper care will extend the life of your speaker.

4.1 Cleaning

- Before cleaning, ensure the charging port flap is securely closed.
- Use a soft, damp cloth to wipe down the exterior of the speaker.
- For stubborn dirt, a mild soap solution can be used, followed by rinsing with clean water.
- Do not use abrasive cleaners or solvents.
- Allow the speaker to air dry completely before use or storage.

4.2 Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery to approximately 50% to maintain battery health.

5. TROUBLESHOOTING

Refer to this table for common issues and their solutions.

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker using the supplied USB cable.

Problem	Possible Cause	Solution
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode (flashing light). Turn device Bluetooth off/on. Move device closer to speaker (within 10 meters).
No sound or low volume.	Volume too low on speaker or device; incorrect audio source.	Increase volume on both speaker and connected device. Ensure correct input (Bluetooth or Aux) is selected.
Qi wireless charging not working.	Device not Qi-compatible; device not properly aligned; speaker not powered on.	Verify device supports Qi wireless charging. Reposition device on the charging pad. Ensure speaker is powered on.
Sound distortion.	Volume too high; weak Bluetooth signal.	Reduce volume on speaker and/or device. Move connected device closer to the speaker.

6. SPECIFICATIONS

Feature	Detail
Model Name	Portable Rugged Bluetooth Speaker
Model Number	IMW580L-BLK
Speaker Type	Outdoor
Connectivity Technology	Auxiliary, Bluetooth, USB
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters (33 feet)
Speaker Maximum Output Power	16 Watts
Water Resistance Level	IP67 (Waterproof, Dirtproof, Snowproof)
Battery Life (Playtime)	Up to 30 Hours
Power Source	Battery Powered (1 Lithium Ion battery included)
Product Dimensions	8.6"D x 4.1"W x 4.6"H
Item Weight	2.29 pounds
Special Features	Qi Wireless Charging, Voice Assistant Integration, Multi-color LED Lights, Floatable

7. WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official Altec Lansing website or contact their customer service.

- Official User Guide (PDF): Download PDF
- Online Support: Visit the Altec Lansing Store on Amazon for product information and support resources.

Related Documents



Altec Lansing LifeJacket XL Jolt IMW790 Quick Start Guide

Concise guide to setting up and using the Altec Lansing LifeJacket XL Jolt IMW790 rugged Bluetooth speaker, covering pairing, charging, house party mode, and music controls.



Altec Lansing Mini Lifejacket Jolt IMW479L Quick Start Guide

Quick start guide for the Altec Lansing Mini Lifejacket Jolt IMW479L rugged Bluetooth speaker with lights, covering setup, charging, pairing, music control, and call handling.



Altec Lansing Mini Lifejacket Jolt with Lights Rugged Bluetooth Speaker Quick Start Guide

Quick start guide for the Altec Lansing Mini Lifejacket Jolt IMW479L rugged Bluetooth speaker with lights, covering setup, charging, Bluetooth pairing, House Party Mode, light modes, voice assistant activation, music control, Bluetooth reset, and call handling.



Altec Lansing Mini Lifejacket Jolt IMW479 Rugged Bluetooth Speaker Quick Start Guide

This quick start guide provides essential instructions for the Altec Lansing Mini Lifejacket Jolt IMW479 Rugged Bluetooth Speaker, including how to charge, power on, pair via Bluetooth, use House Party Mode, control music, answer calls, and activate voice assistants like Siri or Google Assistant.