

[Manuals.plus](#) /

› [Power Rangers](#) /

› Power Rangers Mighty Morphin Triceratops and Sabertooth Tiger Dinozord Action Figures Instruction Manual

Power Rangers E9539

Power Rangers Mighty Morphin Triceratops and Sabertooth Tiger Dinozord Action Figures Instruction Manual

Brand: Power Rangers | Model: E9539

1. PRODUCT OVERVIEW

This product includes two Power Rangers Dinozord action figures: the Triceratops Dinozord and the Sabertooth Tiger Dinozord. These figures are designed to represent the Zords of the Mighty Morphin Blue and Yellow Rangers. They can be played with individually or combined with other Dinozord figures (sold separately) to form the Dino Megazord.



Image 1.1: The Triceratops Dinozord (blue) and Sabertooth Tiger Dinozord (yellow) figures.

Key Features:

- Figures inspired by the Blue Ranger and Yellow Ranger Zords from the classic Mighty Morphin Power Rangers television series.
- Designed for individual play or combination with other Dinozord figures to construct the Dino Megazord.

2. PACKAGE CONTENTS

Please ensure all items listed below are present in your package:

- 1 x Triceratops Dinozord figure
- 1 x Sabertooth Tiger Dinozord figure
- 1 x Instruction sheet (this document)

3. SETUP AND ASSEMBLY

The Triceratops and Sabertooth Tiger Dinozords can be combined with other Dinozord figures (sold separately) to form the larger Dino Megazord. Follow the instructions provided on the included instruction sheet for specific combination steps. Ensure all connection points align correctly for secure assembly.



Image 3.1: Example of Dinozord figures illustrating potential connection points for Megazord formation.



Image 3.2: Representation of the fully assembled Dino Megazord, which requires additional figures.

4. OPERATION AND PLAY

These action figures are designed for imaginative play. Children can pose the figures and recreate scenes from the Power Rangers series or invent new adventures. The figures feature manual operation, meaning no batteries are required. Encourage storytelling and creative scenarios during play.

5. MAINTENANCE AND CARE

- **Cleaning:** Wipe figures with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store figures in a cool, dry place away from direct sunlight to prevent material degradation or color fading.
- **Handling:** Avoid excessive force when posing or combining figures to prevent damage to joints or connection points.

6. TROUBLESHOOTING

- **Parts not fitting:** Ensure you are following the assembly instructions carefully. Check for any obstructions or misalignments. Do not force parts together.
- **Loose joints:** Over time, joints may become slightly loose with extensive play. This is typical wear and tear for action figures.
- If you encounter any issues not covered here, please refer to the support section.

7. SPECIFICATIONS

Attribute	Detail
Brand	Power Rangers
Model Number	E9539
Manufacturer	Hasbro
Material	Plastic, Metal
Item Dimensions (L x W x H)	8.5" x 2.25" x 8.25"
Number of Pieces	2 (Triceratops and Sabertooth Tiger Dinozords)

Minimum Age Recommendation	4 Years
Operation Mode	Manual

8. SAFETY INFORMATION

- **Age Recommendation:** This product is suitable for children aged 4 years and up.
- **Small Parts:** While these figures are generally large, always supervise young children during play, especially if combined with other smaller toy components.
- **Choking Hazard:** Keep packaging materials away from children to prevent suffocation.
- Do not modify or disassemble the figures beyond their intended combination features.

9. WARRANTY AND SUPPORT

For warranty information or product support, please contact Hasbro customer service. Details can typically be found on the product packaging or the official Hasbro website. Please retain your proof of purchase for any warranty claims.

Online Support: Visit the official Power Rangers or Hasbro website for FAQs and additional support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

