

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [WowWee](#) /

› [WowWee MiP Arcade Interactive Self-Balancing Robot Instruction Manual](#)

WowWee 842

MiP Arcade Interactive Self-Balancing Robot

MODEL: 842 | BRAND: WOWWEE

Introduction

The MiP Arcade is an interactive self-balancing robot designed for entertainment and engagement. It offers a variety of play modes, including app-enabled and screenless games, remote control functionality, dancing, and multiplayer options. This manual provides essential information for setting up, operating, and maintaining your MiP Arcade robot.

What's in the Box

- MiP Arcade Robot
- Tray Attachment
- Basketball Hoop Attachment
- 3 MiP Arcade Basketballs
- 4 AA Batteries (included)

Setup

Before operating your MiP Arcade robot, ensure batteries are correctly installed.

Battery Installation

1. Locate the battery compartment on the underside of the MiP Arcade robot.
2. Using a small Phillips head screwdriver, unscrew the battery compartment cover.
3. Insert 4 AA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

Initial Power-On: Once batteries are installed, turn on the robot using the power switch. The robot will self-balance and prepare for interaction.

Your browser does not support the video tag.

Video: Official product video demonstrating MiP Arcade's features, including self-balancing, gesture control, and app integration.

Operating Instructions

Basic Movement & Self-Balancing

The MiP Arcade robot is designed to self-balance on its two wheels. It can move forward, backward, and turn. Its arms are articulated and can be moved manually or as part of programmed actions.



Image: The MiP Arcade robot in its upright, self-balancing position, showcasing its design.

GestureSense Technology

The robot responds to hand gestures. Move your hand in front of its sensors to trigger various movements and reactions. Experiment with different gestures to discover all its interactive capabilities.

App Control

Download the official MiP Arcade App (available for iOS and Android) to unlock additional features and control options. The app allows for precise remote control driving, access to various game modes, and customization of the robot's personality and expressions.

Game Modes

MiP Arcade offers a diverse range of games for both solo and multiplayer fun.

App-Enabled Games

- **Brain Train Games:** Test your mind, memory, and reflexes with games like Reaction Game, Padlock, Color Match, and Shake Shake.
- **Multiplayer Games:** Challenge friends and family in competitive modes such as Basketball Versus.
- **RC Modes:** Control the robot's movements and actions directly from the app.

Screenless Games

The robot also features built-in games that can be played without the need for the app, offering immediate fun and interaction.



Image: A child interacting with the MiP Arcade robot using the basketball hoop attachment, demonstrating a game mode.

Attachments

Enhance your play experience with the included attachments.

- **Tray Attachment:** Securely attach the tray to the robot to have it carry small objects or participate in games like 'Pancake Stack'.
- **Basketball Hoop Attachment:** Connect the basketball hoop to the robot for interactive basketball games using the included mini basketballs.

Maintenance

To ensure the longevity and optimal performance of your MiP Arcade robot, follow these maintenance guidelines:

- Keep the robot clean by wiping it with a dry, soft cloth. Avoid using harsh chemicals or abrasive materials.
- Store the robot in a cool, dry place away from direct sunlight and extreme temperatures.
- Remove batteries if the robot will not be used for an extended period to prevent leakage.
- Regularly check the wheels and joints for any debris or obstructions that might hinder movement.

Troubleshooting

If you encounter issues with your MiP Arcade robot, consider the following general troubleshooting steps:

- **Robot not responding:** Ensure batteries are fresh and correctly installed. Try turning the robot off and on again.
- **App connectivity issues:** Make sure Bluetooth is enabled on your device and the robot is within range. Restart both the app and the robot.
- **Movement problems:** Check the wheels for any obstructions. Ensure the robot is on a flat, smooth surface for optimal self-balancing.

For persistent issues, refer to the official WowWee support resources.

Specifications

Feature	Detail
Brand Name	WowWee
Model Name	MiP Arcade™
Model Number	842
Toy Figure Type	Interactive Gaming Figure
Character	Robot
Age Range Description	Adult (Manufacturer Minimum Age: 72 months)
Item Dimensions L x W x H	6.3"L x 3.25"W x 7.7"H
Item Weight	2 Pounds
Material Type	Plastic
Power Source	Battery (4 AA batteries included)
Operation Mode	Manual, Automatic

Number of Players

Multiple Players




Image: Visual representation of the MiP Arcade robot's dimensions.

Warranty & Support

The manufacturer states that there is **No Warranty** for this product. For further support or inquiries, please visit the official WowWee website or contact their customer service.

