

[Manuals.plus](#) /

› [KitchenAid](#) /

› KitchenAid K150 Blender Instruction Manual (Model KSB1332Y)

KitchenAid KSB1332Y

KitchenAid K150 Blender Instruction Manual

Model: KSB1332Y

Brand: KitchenAid

1. INTRODUCTION

The KitchenAid K150 3-Speed Ice Crushing Blender is designed to provide optimal blending performance for a variety of ingredients, including ice. This manual provides essential information for the safe and efficient operation, maintenance, and care of your blender. Please read all instructions carefully before first use.





Image: The KitchenAid K150 Blender in Black Matte, showcasing its design and a full jar of ingredients ready for blending.

2. KEY FEATURES

- **Ice Crushing Capability:** Designed to crush ice in less than 10 seconds for smoothies and other frozen drinks.
- **3 Speed Options + Ice-Crush Setting:** Offers versatile blending for various ingredients and desired consistencies.
- **Dual-Purpose Personal Blender Jars:** Includes two personal jars that can be used for blending and then converted into on-the-go containers.
- **Unique Asymmetric Blade:** Blends food at four distinct angles, pulling ingredients into the center for efficient crushing.

- **Soft Start Feature:** The motor automatically starts at a slower speed to pull ingredients into the blade, then quickly increases to the selected speed to prevent splatter.
- **Intelli-Speed Motor Control:** Automatically senses contents and maintains optimal speed to power through all ingredients.

3. COMPONENTS

- Blender Base (Motor Housing)
- 48-oz Blender Jar with Lid
- 2 Dual-Purpose Personal Blender Jars
- Blade Assembly (integrated into jars)



Image: The KitchenAid K150 Blender base with the main 48-oz jar and two personal blender jars, highlighting the included accessories.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the blender jar(s), lid(s), and personal jar blade assembly in warm, soapy water before

first use. Rinse thoroughly and dry. The blender base should be wiped with a damp cloth.

3. **Placement:** Place the blender base on a clean, dry, and level surface.
4. **Assemble Jar:** Ensure the blade assembly is securely attached to the bottom of the blender jar or personal jar.
5. **Position Jar:** Place the assembled blender jar onto the blender base, ensuring it is seated correctly.
6. **Plug In:** Plug the blender into a grounded electrical outlet.

5. OPERATING INSTRUCTIONS

The KitchenAid K150 Blender features a simple control dial for easy operation.



Image: A detailed view of the blender's control dial, showing the various speed settings and the dedicated ice crush function.

1. **Add Ingredients:** Place your ingredients into the blender jar. Do not overfill past the maximum fill line. For best results, add liquids first, then soft ingredients, followed by hard ingredients and ice.
2. **Secure Lid:** Place the lid firmly onto the blender jar. Ensure the lid is properly sealed. The removable ingredient cap can be used to add ingredients during blending.
3. **Select Speed:** Turn the control dial to your desired speed setting (1, 2, or 3) or to the 'P/Ice Crush' setting for crushing ice. The Soft Start feature will gradually increase speed to prevent splatter.
4. **Blend:** Allow the blender to operate until the desired consistency is achieved. The Intelli-Speed motor control will adjust power to maintain optimal blending.
5. **Stop:** Turn the control dial back to '0' to stop the blender.
6. **Pour:** Remove the lid and carefully pour your blended mixture.

Using Personal Blender Jars:

For individual servings, use the personal blender jars. Fill the personal jar with ingredients, attach the blade assembly, invert, and place onto the blender base. Blend as desired, then remove, replace the blade assembly with the travel lid, and enjoy.

Your browser does not support the video tag.

Video: Official KitchenAid KSB1332Y Product Video demonstrating the blender's features and blending capabilities.

6. MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and performance of your KitchenAid K150 Blender.

1. **Unplug:** Always unplug the blender from the electrical outlet before cleaning.
2. **Blender Jars and Lids:** The 48-oz blender jar, personal blender jars, and their lids are dishwasher safe (top rack recommended). Alternatively, wash them in warm, soapy water, rinse thoroughly, and dry.
3. **Blender Base:** Wipe the blender base with a damp cloth. Do not immerse the base in water or other liquids.
4. **Storage:** Store the blender with the jar assembled on the base or store components separately in a dry place.

7. TROUBLESHOOTING

If you encounter issues with your blender, refer to the following common solutions:

- **Blender does not turn on:** Ensure the blender is properly plugged into a working electrical outlet. Check if the blender jar is correctly seated on the base.
- **Ingredients are not blending smoothly:** Add more liquid to the mixture. Use the pulse function or increase the speed setting. Ensure the lid is securely in place.
- **Motor stops during operation:** The blender may be overloaded. Turn off the blender, unplug it, remove some ingredients, and allow the motor to cool for a few minutes before restarting.
- **Loud noise or unusual odor:** Turn off and unplug the blender immediately. Check for any foreign objects in the jar or damage to the blades. If the issue persists, contact customer support.

8. SPECIFICATIONS

Specification	Detail
Brand	KitchenAid
Model Number	KSB1332Y
Color	Black Matte
Capacity	48-oz (main jar)
Product Dimensions	8.5"D x 7.1"W x 14.8"H
Item Weight	7 Pounds
Power Source	Corded Electric
Wattage	650 watts
Number of Speeds	3 + Ice Crush
Voltage	120V
Material	Stainless Steel (blades)
Material Type Free	BPA Free
Dishwasher Safe	No (Base), Yes (Jars/Lids)

9. WARRANTY AND SUPPORT

Your KitchenAid K150 Blender (Model KSB1332Y) comes with a **1-year limited warranty** from the date of purchase, covering defects in material or workmanship under normal household use.

For warranty claims, technical assistance, or to purchase replacement parts, please contact KitchenAid Customer Service:

- **Website:** www.kitchenaid.com
- **Phone:** Refer to your regional KitchenAid support contact information.

Please retain your proof of purchase for warranty purposes.