



[Manuals.plus](#) /

› [Atomi Smart](#) /

› Atomi Smart Bluetooth Water Resistant Shower Speaker User Manual

Atomi Smart Atomi

Atomi Smart Bluetooth Water Resistant Shower Speaker User Manual

INTRODUCTION

Thank you for choosing the Atomi Smart Bluetooth Water Resistant Shower Speaker. This manual provides detailed instructions for the setup, operation, and maintenance of your new speaker. Designed for versatility, this rechargeable speaker features a water-resistant design and a removable suction cup, making it ideal for use in various environments, including showers, bathrooms, and outdoor settings.

atomi™



bluetooth shower speaker

WATER RESISTANT PORTABLE SPEAKER



WATER RESISTANT
Protects from
water and dust



BUILT-IN MIC
Answer incoming
calls hands-free



LISTEN TO MUSIC
Listen to your favorite
music wirelessly



SECURE SUCTION
No fall double
locking suction cup

Image: Atomi Smart Bluetooth Water Resistant Shower Speaker, showcasing its compact design and control buttons.

SETUP

1. Charging the Speaker

Before initial use, fully charge your Atomi Smart Shower Speaker. Connect the provided charging cable to the speaker's charging port and to a USB power source. The charging indicator light will illuminate during charging and turn off once fully charged.

2. Bluetooth Pairing

1. Ensure the speaker is fully charged.
2. Press and hold the Power button on the speaker until you hear an audible prompt and the Bluetooth indicator light

begins to flash, indicating it is in pairing mode.

3. On your mobile device (smartphone, tablet, etc.), navigate to the Bluetooth settings.
4. Search for available devices and select "Atomi Speaker" (or similar name) from the list.
5. Once paired, you will hear a confirmation tone, and the Bluetooth indicator light will stop flashing and remain solid.

3. Mounting the Speaker

The Atomi Smart Shower Speaker comes with a removable suction cup for convenient mounting. To attach, ensure the surface is clean, smooth, and dry. Press the suction cup firmly against the desired surface (e.g., shower wall, tile) until it adheres securely. To remove, gently pull the edge of the suction cup to release the seal.

OPERATING INSTRUCTIONS

1. Power On/Off

- **To Power On:** Press and hold the Power button until the indicator light illuminates and you hear a power-on sound.
- **To Power Off:** Press and hold the Power button until the indicator light turns off and you hear a power-off sound.

2. Music Playback

- **Play/Pause:** Press the Play/Pause button once to play or pause the current track.
- **Next Track:** Press and hold the '+' button to skip to the next track.
- **Previous Track:** Press and hold the '-' button to go to the previous track.
- **Volume Up:** Press the '+' button briefly to increase the volume.
- **Volume Down:** Press the '-' button briefly to decrease the volume.

3. Call Handling

- **Answer/End Call:** Press the Phone button once to answer an incoming call or end an ongoing call.
- **Reject Call:** Press and hold the Phone button to reject an incoming call.

MAINTENANCE

1. Cleaning

Due to its water-resistant design, the speaker can be gently wiped with a damp cloth to remove dirt or soap residue. Do not use harsh chemicals or abrasive cleaners, as these may damage the speaker's finish or water-resistant seals. Ensure the charging port cover is securely closed before cleaning or exposing to water.

2. Battery Care

- Avoid fully discharging the battery frequently to prolong its lifespan.
- Store the speaker in a cool, dry place when not in use for extended periods.
- Recharge the speaker periodically if stored for a long time to prevent deep discharge.

TROUBLESHOOTING

- **Speaker won't turn on:** Ensure the battery is charged. Connect the speaker to a power source and try again.
- **Cannot pair via Bluetooth:**
 - Make sure the speaker is in pairing mode (flashing indicator light).

- Ensure your device's Bluetooth is enabled and within range (up to 10 meters).
 - Try forgetting the device on your phone's Bluetooth settings and re-pairing.
 - Restart both the speaker and your Bluetooth device.
- **No sound or low volume:**
 - Check the volume levels on both the speaker and your connected device.
 - Ensure the speaker is properly paired and connected.
 - Try playing a different audio source.
 - **Suction cup not sticking:** Ensure the surface is clean, smooth, and dry. Avoid porous or textured surfaces.

SPECIFICATIONS

| | |
|-------------------------------------|--|
| Brand | Atomi Smart |
| Model Name | Atomi |
| Connectivity Technology | Bluetooth |
| Wireless Technology | Bluetooth |
| Bluetooth Range | 10 Meters |
| Speaker Maximum Output Power | 3 Watts |
| Audio Output Mode | Stereo |
| Speaker Type | Outdoor |
| Water Resistance | Water Resistant (Is Waterproof: True) |
| Power Source | Battery Powered |
| Number of Batteries | 1 A batteries required (included) |
| Control Method | Touch, Button |
| Built-In Media | Suction Cup, Water-resistant Loudspeaker |
| Compatible Devices | Smartphone |

WARRANTY AND SUPPORT

The Atomi Smart Bluetooth Water Resistant Shower Speaker comes with a **Limited Warranty**. For detailed warranty information, product support, or to inquire about replacement parts, please refer to the official Atomi Smart website or contact their customer service directly. Please retain your proof of purchase for warranty claims. For further assistance, please visit the [Atomi Smart Support Page](#) (*example link, actual link may vary*).



