

Casio MTP-V006D-7B2

Casio MTP-V006D-7B2 Men's Stainless Steel Easy Reader Watch Instruction Manual

Model: MTP-V006D-7B2

1. PRODUCT OVERVIEW

The Casio MTP-V006D-7B2 is a classic men's analog watch featuring a stainless steel case and band, a white dial with easy-to-read numerals, and a day/date display. Designed for everyday wear, it combines functionality with a timeless aesthetic.




Image 1: Front view of the Casio MTP-V006D-7B2 watch, showcasing its white dial and stainless steel bracelet.

Key Features:

- Precise Japan Quartz Movement
- Stainless Steel Case and Band with Fold Over Deployment Clasp
- Mineral Crystal for scratch resistance
- Day/Date Display
- Easy-to-Read Numeral Dial
- Water Resistant up to 30 meters (3 ATM)

2. SETUP AND TIME ADJUSTMENT

Before using your watch, it is important to set the correct time and date. This watch features a single crown for all adjustments.

Setting the Time:

1. Pull the crown out to the **second click position** (farthest out). The second hand will stop.
2. Rotate the crown to move the hour and minute hands to the desired time. Ensure you set the correct

AM/PM by observing the day/date change. If setting the time past midnight, the day/date will advance.

3. Push the crown back in to the **normal position**. The second hand will resume movement.

Setting the Day and Date:

1. Pull the crown out to the **first click position**.
2. Rotate the crown **clockwise** to adjust the day.
3. Rotate the crown **counter-clockwise** to adjust the date.
4. Avoid setting the date between 9:00 PM and 4:00 AM, as this may interfere with the automatic date change mechanism. If you need to set the date during this period, first adjust the time outside this range, set the date, then reset the time.
5. Push the crown back in to the **normal position**.

Note: The day display supports both English and Spanish languages.

3. OPERATING THE WATCH

Once set, the watch operates continuously, displaying the current time, day, and date. No further manual operation is typically required unless the time or date needs adjustment due to a short month or time zone change.

Automatic Day/Date Change:

The day and date indicators will automatically advance around midnight. The date will advance daily, while the day will advance once every 24 hours. For months with fewer than 31 days (February, April, June, September, November), the date will need to be manually adjusted at the beginning of the next month.

4. MAINTENANCE AND CARE

Proper care will ensure the longevity and performance of your Casio watch.

Water Resistance:

This watch is water resistant up to 30 meters (3 ATM). This means it is suitable for daily use and can withstand splashes or brief immersion in water. **It is NOT suitable for swimming, showering, or diving.** Always ensure the crown is fully pushed in to maintain water resistance.

Cleaning:

- Wipe the watch case and band with a soft, dry cloth to remove dirt and moisture.
- For stainless steel bands, a soft brush and mild soapy water can be used, followed by thorough rinsing and drying. Avoid getting water into the watch case.
- Do not use chemical cleaners or abrasive materials, as these can damage the watch's finish.

Battery Replacement:

The watch is powered by one LR41 battery. When the watch stops or the second hand moves erratically, the battery may need replacement. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

5. TROUBLESHOOTING

If you encounter issues with your watch, refer to the following common problems and solutions.

Watch Not Keeping Accurate Time:

- **Battery Depletion:** If the watch is losing time significantly or stops, the battery (LR41) may need replacement.
- **Magnetic Fields:** Exposure to strong magnetic fields can affect the watch's accuracy. Move the watch away from magnetic sources.
- **Impact:** A severe impact may affect the internal mechanism. Professional inspection may be required.

Day/Date Not Changing:

- **Incorrect Time Setting:** Ensure the time is set correctly, especially the AM/PM cycle. The day/date changes around midnight.
- **Manual Adjustment Needed:** For months shorter than 31 days, the date must be manually advanced.

Water Inside Watch:

- **Immediate Action:** If moisture or condensation appears inside the watch, take it to a qualified technician immediately to prevent further damage.
- **Crown Position:** Ensure the crown was fully pushed in before exposure to water.
- **Water Resistance Limits:** Remember the watch is only resistant to splashes, not submersion.

6. SPECIFICATIONS

Casio MTP-V006D-7B2 Watch Specifications

Feature	Detail
Model Number	MTP-V006D-7B2
Movement	Japanese Quartz (Module 1333)
Case Material	Stainless Steel
Band Material	Stainless Steel
Clasp Type	Foldover Clasp
Crystal Type	Mineral Crystal
Case Diameter	38 mm
Case Thickness	9.4 mm
Water Resistance	30 Meters (3 ATM)
Display Type	Analog
Functions	Time (Hour, Minute, Second), Day, Date
Battery Type	1 x LR41 (included)

Feature	Detail
Item Weight	93 Grams (3.28 ounces)

7. WARRANTY AND SUPPORT

Your Casio MTP-V006D-7B2 watch comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including coverage duration and service procedures.

For further assistance, technical support, or warranty claims, please contact Casio customer service or visit the official Casio website. Keep your proof of purchase for warranty validation.

Note: Unauthorized repairs or modifications may void your warranty.