

## Logitech M100

# Logitech M100 Corded Mouse Instruction Manual

Model: M100 (910-005003)

## INTRODUCTION

---

The Logitech M100 Corded Mouse is a reliable and straightforward optical mouse designed for everyday computer use. Its simple plug-and-play functionality and comfortable design make it suitable for various computing environments, including personal computers, laptops, Macs, Chromebooks, and tablets.

## SETUP

---

Setting up your Logitech M100 mouse is a simple process due to its plug-and-play design. No additional software or drivers are typically required for basic functionality.

1. **Unpack the Mouse:** Carefully remove the mouse from its packaging.
2. **Locate a USB Port:** Identify an available USB-A port on your computer (desktop, laptop, Mac, Chromebook, or tablet).
3. **Connect the Mouse:** Insert the USB connector of the mouse cable firmly into the USB port.
4. **System Recognition:** Your operating system should automatically detect and configure the mouse within a few seconds. You can then begin using the mouse immediately.



Image: The Logitech M100 Corded Mouse, showing its black design and attached USB cable, ready for connection.

## Setup Demonstration Video

Your browser does not support the video tag.

Video: This video demonstrates the simple plug-and-play setup of the Logitech M100 mouse, showing it being connected to both a laptop and a desktop computer. It also briefly highlights the mouse's basic functions.

## OPERATING INSTRUCTIONS

---

The Logitech M100 mouse features a standard three-button design with a scroll wheel, providing intuitive control for various tasks.

- **Left-Click Button:** Used for selecting items, opening files, and activating functions.
- **Right-Click Button:** Used to open contextual menus, providing quick access to additional options.
- **Scroll Wheel:** Roll the wheel up or down to navigate through documents and web pages. The scroll wheel can also be pressed down for a middle-click function, often used to open links in new tabs or for specific application functions.

The ambidextrous design ensures comfortable use for both left-handed and right-handed individuals.



## PLUG&PLAY-KOMFORT FÜR LINKS- UND RECHTSHÄNDER GEEIGNET

Image: A hand comfortably gripping the Logitech M100 mouse, illustrating its ergonomic shape for general use.

### Ambidextrous Use Demonstration

Your browser does not support the video tag.

Video: This short video highlights the ambidextrous design of the Logitech M100 mouse, showing how it can be comfortably used by both left and right hands for clicking and scrolling.

### MAINTENANCE

---

To ensure optimal performance and longevity of your Logitech M100 mouse, follow these simple maintenance guidelines:

- **Cleaning:** Regularly wipe the mouse surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Optical Sensor:** Keep the optical sensor on the underside of the mouse clean and free from dust or debris. Use a soft, dry cloth or a cotton swab to gently clean the sensor area if needed.
- **Cable Care:** Avoid sharp bends or excessive pulling on the USB cable to prevent internal damage.



**UNIVERSELL  
KOMPATIBEL**



Image: The underside of the Logitech M100 mouse, displaying the optical sensor and product information label.

## TROUBLESHOOTING

---

If you encounter issues with your Logitech M100 mouse, try the following troubleshooting steps:

- **Mouse Not Responding:**
  - Ensure the USB cable is securely plugged into a working USB port on your computer.
  - Try plugging the mouse into a different USB port.
  - Restart your computer.
- **Erratic Cursor Movement:**
  - Clean the optical sensor on the bottom of the mouse.
  - Ensure you are using the mouse on a suitable surface. Highly reflective or transparent surfaces may interfere with optical tracking. A mouse pad is recommended.
- **Buttons or Scroll Wheel Not Working:**
  - Check for any physical obstructions around the buttons or scroll wheel.
  - Test the mouse on another computer to determine if the issue is with the mouse or the computer's settings.

## SPECIFICATIONS

---

Feature	Detail
---------	--------

Feature	Detail
Brand	Logitech
Model Name	M100 Optical Mouse
Model Number	910-005003
Color	Black
Connectivity Technology	USB
Movement Detection Technology	Optical
Button Quantity	3
Hand Orientation	Ambidextrous
Compatible Devices	Personal Computer, Laptop, Mac, Chromebook, Tablet
Power Source	Corded Electric
Item Weight	90 Grams
Batteries Required	No



## REIBUNGSLOSE UND REAKTIONSSCHNELLE ABTASTUNG

Image: A diagram illustrating the dimensions of the Logitech M100 mouse, including length (112 mm), width (62 mm), and height (38 mm).

### WARRANTY AND SUPPORT

Your Logitech M100 Corded Mouse is covered by a limited warranty. Please refer to the details below:

- **Warranty Period:** 90 days limited warranty.
- **Return Policy:** Within 90 days of purchase, eligible for refund or replacement.

For further assistance, technical support, or to inquire about warranty claims, please visit the official Logitech support website or contact their customer service.