

## Keter B084YVF817

# Keter 165-Gallon Resin Outdoor Deck Box User Manual

Model: B084YVF817

## INTRODUCTION

This user manual provides essential information for the assembly, operation, and maintenance of your Keter 165-Gallon Resin Outdoor Deck Box. Designed for outdoor storage, this durable and weather-resistant unit offers a spacious interior for various items while also serving as additional seating or a workspace.

## SAFETY INFORMATION

- Ensure all parts are securely fastened during assembly to prevent instability.
- Do not allow children to play inside the deck box to prevent entrapment.
- Do not overload the deck box beyond its stated capacity to avoid damage or injury.
- Keep the lid closed when not in use to protect contents from weather and to prevent accidental falls.
- Use caution when opening and closing the hydraulic lid to avoid pinching fingers.

## PARTS LIST

Before beginning assembly, ensure all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Side Panels (2)
- Front Panel (1)
- Back Panel (1)
- Bottom Panel (1)
- Lid (1)
- Hydraulic Arms (2)
- Metal Reinforcement Bars (for lid)
- Fasteners and Screws
- Instruction Manual

## SETUP AND ASSEMBLY

The Keter 165-Gallon Deck Box is designed for easy assembly, often requiring only a Phillips screwdriver. Follow these steps for proper setup:

- Unpack Components:** Carefully remove all parts from the packaging. Verify against the parts list.
- Assemble Base:** Connect the side, front, and back panels to the bottom panel, ensuring all tabs and slots align. Press firmly to secure.
- Attach Lid:** Position the lid onto the assembled base. Secure the hydraulic arms and metal reinforcement bars to the lid and side panels using the provided fasteners. Ensure the hydraulic arms are correctly oriented for smooth opening and closing.
- Final Checks:** Confirm all connections are secure and the lid operates smoothly.



Image: Assembled Keter 165-Gallon Deck Box with key dimensions (62"L x 29"W x 28"H).

## OPERATING INSTRUCTIONS

Using your Keter Deck Box is straightforward:

- Opening the Lid:** Gently lift the lid. The hydraulic arms will assist in opening and holding the lid in an open position.
- Storing Items:** Place outdoor cushions, garden tools, pool accessories, or other items inside the spacious interior.
- Closing the Lid:** Gently pull the lid down. The hydraulic arms will provide a soft-close mechanism. Ensure the lid is fully latched to protect contents.
- Locking (Optional):** The lid features a secure close hydraulic mechanism that is lockable. A padlock (not included) can be used to secure the contents.



*Image: The Keter Deck Box with its lid fully open, revealing a variety of stored outdoor items.*



*Image: A detailed view of the hydraulic arm that supports the lid, ensuring smooth and controlled opening and closing.*

## MAINTENANCE

To ensure the longevity and appearance of your Keter Deck Box, follow these simple maintenance guidelines:

- Cleaning:** Wipe down the exterior with a damp cloth and mild soap as needed. Avoid abrasive cleaners or harsh chemicals that could damage the resin material.
- Weather Protection:** The box is designed to be weather-resistant. However, during extreme weather conditions, consider placing it in a sheltered area or covering it for added protection.
- Inspection:** Periodically check all connections and the hydraulic arms for any signs of wear or damage. Tighten fasteners if necessary.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Lid does not close properly.	Obstruction inside the box; misaligned lid or hinges.	Remove any items blocking the lid. Check hinge alignment and tighten screws if loose.
Water inside the box.	Lid not fully closed; damaged seal; extreme weather.	Ensure lid is securely latched. Inspect seals for damage and replace if necessary. Consider sheltered placement during heavy rain.
Lid is difficult to open/close.	Hydraulic arms are stiff or damaged.	Apply a silicone-based lubricant to the hydraulic arm joints. If damaged, contact customer support for replacement parts.

## SPECIFICATIONS

**Brand:** Keter

**Model:** B084YVF817

**Capacity:** 165 Gallons

**Material:** Polypropylene Resin, Metal

**Color:** Brown Espresso

**Product Dimensions (Assembled):** 62" L x 29" W x 28" H

**Item Weight:** 39.1 Pounds

**Water Resistance Level:** Waterproof

**Opening Mechanism:** Hydraulic

**Special Feature:** Lockable (lock not included)

**UPC:** 731161054631



*Image: The Keter 165-Gallon Resin Outdoor Deck Box in its closed state, showcasing its wood-look texture and brown espresso color.*

## WARRANTY AND SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or visit the official Keter website. Keep your proof of purchase for any warranty claims.

### Contact Information:

**Brand:** Keter

**Website:** [www.keter.com](http://www.keter.com) (Please check the official website for the most current support options and contact details.)

