

- Manuals.plus /
- > Tek Styz /
 - > Tek Styz PRO Stylus + Pen User Manual for Plantronics Voyager 3240

Tek Styz P/N 207360-01

Tek Styz PRO Stylus + Pen User Manual

Model: Plantronics Voyager 3240 Compatible Stylus (P/N 207360-01)

INTRODUCTION

This manual provides detailed instructions for the proper use and care of your Tek Styz PRO Stylus + Pen, designed for compatibility with Plantronics Voyager 3240 Diamond Black Model P/N 207360-01. This high-precision 2-in-1 stylus features both a capacitive touch tip for modern touchscreens and a traditional black ink pen.

PRODUCT OVERVIEW



Figure 1: The Tek Styz PRO Stylus + Pen, showcasing its dual functionality with the capacitive stylus tip at one end and the ballpoint pen at the other. The cap is shown removed from the pen end.



Figure 2: The Tek Styz PRO Stylus + Pen in its closed state, highlighting its compact and portable design. The cap covers the ballpoint pen tip, and the stylus tip is visible at the opposite end.

The Tek Styz PRO Stylus + Pen combines the precision of a stylus for digital interfaces with the practicality of a traditional ink pen. Its design ensures comfortable handling and reliable performance for both capacitive (touch) and resistive (pressure-only) screens.

Key Features:

- **Dual Functionality:** Capacitive stylus for touchscreens and black ink ballpoint pen.
- **High Sensitivity Touch:** Provides accurate and responsive interaction with touch devices.
- **Durable Construction:** Designed for longevity and consistent performance.
- **Compatibility:** Specifically designed to work with Plantronics Voyager 3240 Diamond Black Model P/N 207360-01 and other compatible devices.

SETUP

The Tek Styz PRO Stylus + Pen requires no complex setup or battery installation. It is ready for use directly out of the packaging.

1. **For Stylus Use:** Simply touch the soft, rounded stylus tip to your device's screen. Ensure the screen is clean for optimal responsiveness.
2. **For Pen Use:** Remove the cap from the pen end to expose the ballpoint pen. Replace the cap securely after use to prevent ink drying.

OPERATING INSTRUCTIONS

Using the Stylus Function:

The stylus tip is designed for precise navigation, drawing, and writing on capacitive touchscreens (e.g., smartphones, tablets, touch-enabled laptops). It also functions on resistive screens, which respond to pressure.



Figure 3: Demonstrating the use of the Tek Styz PRO Stylus + Pen on a tablet, illustrating its precision for screen interaction.

- Hold the stylus as you would a regular pen.
- Gently touch or tap the screen with the stylus tip to interact with apps, menus, or to draw/write.
- Avoid applying excessive force to the screen.

Using the Pen Function:

The ballpoint pen provides a smooth writing experience for traditional paper use.

- Remove the cap from the pen end.
- Use the pen for writing on paper.
- Always replace the cap firmly after use to prevent the ink from drying out and to protect the pen tip.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the stylus body and tip with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the stylus in a cool, dry place away from direct sunlight and extreme temperatures. Always cap the pen when not in use.
- **Avoid Drops:** While durable, dropping the stylus on hard surfaces can damage the tips or internal components.

- **Ink Refills:** When the ink runs out, the pen can be refilled with standard D1 size ballpoint pen refills. Refer to the manufacturer's instructions for refill replacement.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stylus not responding on screen.	Screen is dirty or has smudges; stylus tip is worn; device screen protector interference.	Clean your device screen thoroughly. Ensure the stylus tip is intact. Try removing the screen protector temporarily to test.
Pen ink is not flowing smoothly.	Ink has dried out; pen tip is clogged; low ink level.	Try writing on a scrap piece of paper to get the ink flowing. Ensure the cap was replaced properly after last use. Consider replacing the ink refill.
Stylus feels less precise.	Screen calibration issues; stylus tip wear.	Check your device's display settings for touch calibration options. If the tip appears damaged or excessively worn, consider replacing the stylus.

SPECIFICATIONS

- **Product Type:** 2-in-1 Stylus and Ballpoint Pen
- **Stylus Type:** Capacitive (compatible with most touchscreens) and Resistive
- **Ink Color:** Black
- **Ink Refill Type:** Standard D1 size (replaceable)
- **Compatibility:** Plantronics Voyager 3240 Diamond Black Model P/N 207360-01, and other compatible devices.
- **Brand:** Tek Styz
- **Model Number:** P/N 207360-01 (associated with Plantronics Voyager 3240 compatibility)
- **ASIN:** B084YYY8QT
- **UPC:** 746558938050

WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the official Tek Styz website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Manufacturer: Tek Styz

Date First Available: April 6, 2022

© 2024 Tek Styz. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B084YYY8QT>

More documents and user manuals: <https://manuals.plus/>