

[Manuals.plus](#) /

› [Cooler Master](#) /

› Cooler Master Caliber R2 Gaming Chair Instruction Manual

Cooler Master Caliber R2

Cooler Master Caliber R2 Gaming Chair Instruction Manual

INTRODUCTION

This manual provides essential instructions for the assembly, operation, and maintenance of your Cooler Master Caliber R2 Gaming Chair. Designed for comfort and durability, the Caliber R2 features an ergonomic design, premium PU leather, and adjustable components to enhance your gaming or work experience.



The Cooler Master Caliber R2 Gaming Chair in a typical gaming or office environment.

SETUP AND ASSEMBLY

The Cooler Master Caliber R2 Gaming Chair is designed for straightforward assembly. All necessary screws and washers are pre-installed in their respective positions on the chair components to simplify the process. Please follow the steps below for proper setup.

Assembly Steps Overview

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify all components are present against the included parts list.
2. **Attach Casters to Base:** Insert the five multi-directional casters into the metal star base.
3. **Install Gas Lift:** Place the class 4 gas lift into the center hole of the star base.
4. **Assemble Seat and Backrest:** Attach the backrest to the seat base using the pre-installed screws.
5. **Mount Mechanism to Seat:** Secure the tilt mechanism to the underside of the seat.
6. **Connect Seat to Gas Lift:** Place the assembled seat onto the gas lift.
7. **Attach Armrests:** Secure the 2D armrests to the sides of the seat.

8. **Install Pillows:** Attach the ergonomic headrest and lumbar support pillows.

For a visual guide on the assembly process, please refer to the video below:

Video demonstrating the unboxing and assembly of the Cooler Master Caliber R2C Gaming Chair, including how to locate pre-installed screws.

OPERATING THE CHAIR

The Cooler Master Caliber R2 offers multiple adjustment options to customize your seating experience for optimal comfort and support.

Seat Height Adjustment

To adjust the seat height, locate the lever on the right side beneath the seat. Pull the lever upwards while seated to lower the chair, or pull the lever upwards while standing to raise the chair. Release the lever at your desired height.

Armrest Adjustment

The 2D armrests can be adjusted for height and swivel. Use the button on the side of each armrest to raise or lower them. The armrests can also be swiveled left, center, or right to find your preferred position.

**Upgraded
Design**

**10% ↑
More Breathable Material**



**Fully Adjustable
Up & Down**




**Left, Center,
Right Rotation**

Illustration of the adjustable 2D armrests, allowing for height and swivel customization.

Backrest Recline

The backrest can be reclined from 90 degrees (upright for work) to 180 degrees (fully flat for resting). Locate the recline lever on the left side of the seat. Pull the lever up and lean back to recline, or lean forward and pull the lever up to bring the backrest upright. Release the lever to lock it in place.



**180° Completely
Lay Down**



90° Efficient at work



120° Comfortable reading



180° Nap Time!

Visual representation of the chair's recline capabilities, from 90° to 180°.

Headrest and Lumbar Support

The chair includes an ergonomic headrest and lumbar pillow for enhanced comfort and support. These pillows are removable and can be adjusted vertically to suit your preference.

Upgraded Sitting Experience

New Pillow design
Fits Your Neck Just Right



The ergonomic headrest pillow, designed to provide neck support.

Demonstration of the Cooler Master Caliber R2's adjustable features, including headrest, lumbar support, recline, and armrests.

MAINTENANCE

To ensure the longevity and appearance of your Cooler Master Caliber R2 Gaming Chair, regular maintenance is recommended.

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the PU leather.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Caster Care:** Keep the multi-directional casters free of debris to ensure smooth movement across various floor surfaces.

SPECIFICATIONS

Key specifications for the Cooler Master Caliber R2 Gaming Chair:

Feature	Detail
Brand	Cooler Master
Model Name	Caliber R2
Color	Purple
Material	Alloy Steel, PU Leather, Foam
Product Dimensions	22.8"D x 32.3"W x 52.6"H
Item Weight	47.4 pounds
Maximum Weight Recommendation	330 Pounds
Back Style	Queen Anne Back
Special Feature	Adjustable (Reclining Backrest, 2D Armrests, Ergonomic Headrest, Lumbar Pillow)
Reclining Position Count	Multiple (up to 180 degrees)
Furniture base movement	Swivel, Multi-directional Casters



Detailed product dimensions and maximum load capacity of the Caliber R2.

TROUBLESHOOTING

If you encounter any issues with your Cooler Master Caliber R2 Gaming Chair, please refer to the following common solutions:

- **Squeaking Noises:** Check and re-tighten all assembly bolts. Applying a small amount of silicone lubricant to moving parts (e.g., tilt mechanism, casters) may also help.
- **Difficulty Adjusting Height:** Ensure the gas lift lever is fully engaged or disengaged. If the issue persists, the gas lift may need replacement.
- **Unstable Chair:** Verify that the star base is correctly assembled and all casters are securely inserted. Ensure all bolts connecting the seat and backrest are tight.
- **Armrest Movement Issues:** Check the adjustment buttons and mechanisms on the armrests for any obstructions or damage.

If these steps do not resolve your issue, please contact customer support for further assistance.

WARRANTY AND SUPPORT

The Cooler Master Caliber R2 Gaming Chair comes with a **2-year warranty** covering normal wear and tear. For any questions regarding general use, functionality, or warranty claims, please contact Cooler Master Customer Support.

For customer support, please visit the [Cooler Master Store on Amazon](#) or refer to the contact information provided in your product packaging.