

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [FLEXISPOT](#) /

› [FLEXISPOT EN1 One-Piece Standing Desk Instruction Manual](#)

FLEXISPOT EN1

FLEXISPOT EN1 One-Piece Standing Desk Instruction Manual

Model: EN1 (EC1B5528N) | Brand: FLEXISPOT

INTRODUCTION

The FLEXISPOT EN1 One-Piece Standing Desk is designed to enhance your workspace with its electric height adjustment capabilities and robust construction. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your desk, ensuring a comfortable and productive environment.

- **One-Piece Desktop:** Features a seamless, rock-solid desktop for enhanced stability, ideal for multi-monitor setups.
- **1-Inch Thick Desktop:** Dense, durable, and sag-resistant, suitable for heavy equipment and multiple devices.
- **Spacious Design:** A 28-inch deep desktop provides ample space for various work configurations.
- **Electric Height Adjustment:** Smoothly adjust height from 28.1 inches to 45.7 inches with 4 memory presets for sitting or standing positions.

SETUP

The FLEXISPOT EN1 desk is designed for quick and easy assembly. All necessary tools are included. While assembly can be done by one person, two individuals are recommended for ease and safety, especially when handling the heavy components.

Assembly Overview

- The desk features a single, solid desktop for superior stability compared to multi-piece designs.
- Ensure all components are present before beginning assembly.
- Follow the detailed instructions provided in the included assembly guide.

**BOXES MAY SHIP &
ARRIVE SEPARATELY**




Figure 1: Desk components may arrive in separate packages.



Figure 2: Assembled FLEXISPOT EN1 Standing Desk with a complete workstation setup.

OPERATING INSTRUCTIONS

The FLEXISPOT EN1 desk features an intuitive control panel for effortless height adjustment and memory settings.

Control Panel Functions

- **Up/Down Arrows:** Press and hold to manually adjust the desk height.
- **Memory Presets (1, 2, 3, 4):** Save up to four preferred height settings. To save a height, adjust the desk to the desired level, then press and hold a memory button (e.g., '1') until the display flashes or beeps. To recall a saved height, simply press the corresponding memory button.
- The desk's height can be adjusted between 28.1 inches and 45.7 inches.



Figure 3: Programmable Control Panel for height adjustment.

Video Demonstration: Height Adjustment

Video 1: Demonstrates the electric height adjustment and memory presets of the FLEXISPOT EN1 desk.

MAINTENANCE

Proper care ensures the longevity and appearance of your FLEXISPOT EN1 desk.

- Wipe the wooden top with a damp cloth.
- Avoid direct sunlight and heat sources to prevent damage to the desktop.
- Dust and wipe the alloy steel frame with a damp cloth as needed.

TROUBLESHOOTING

If you encounter issues with your desk, refer to the following common solutions:

- **Error Message on Control Panel:** If an error message appears when recalling a saved height, unplug the desk from the power source and then reconnect it. This often resolves temporary electrical glitches.
- **Desk Not Moving:** Ensure all cables are securely connected and the power cord is properly plugged into a working outlet.

- **Uneven Movement:** Check that the desk is placed on a level surface and that no obstructions are impeding the leg movement.

SPECIFICATIONS

Feature	Detail
Brand	FLEXISPOT
Model Name	EN1
Model Number	EC1B5528N
Product Dimensions (D x W x H)	28"D x 55"W x 28"H
Tabletop Thickness	1 Inch
Minimum Height	28.1 Inches
Maximum Height	45.7 Inches (117.6 Centimeters)
Maximum Weight Recommendation	154 Pounds
Item Weight	88 Pounds
Material Type	Alloy Steel (Base), Mahogany (Top)
Color	Mahogany (Top), Black (Frame)
Finish Type	Powder Coated
Is Electric	Yes
Required Assembly	Yes
Recommended People for Assembly	2
Includes All Assembly Tools	Yes


DIMENSIONS



Desktop

Size: 55"-28"

Can hold a variety of monitor and laptop



Desk Frame

Adjustable Height:
28.1"-45.7"

Can support your daily work

Figure 4: Desk Dimensions Overview.

WARRANTY AND SUPPORT

The FLEXISPOT EN1 Standing Desk comes with a Limited Warranty. For specific warranty details, please refer to the documentation included with your product or contact FlexiSpot customer service.

For any questions, technical assistance, or support, please contact FlexiSpot directly. Their customer support team can provide further guidance on assembly, operation, and troubleshooting.