

[Manuals.plus](#) /

› [Fujifilm](#) /

› Fujifilm NP-W235 Rechargeable Li-Ion Battery User Manual

Fujifilm NP-W235

Fujifilm NP-W235 Rechargeable Li-Ion Battery User Manual

INTRODUCTION

This manual provides essential information for the safe and effective use of your Fujifilm NP-W235 Rechargeable Li-Ion Battery. The NP-W235 is a new increased capacity battery designed for use in compatible Fujifilm cameras, including the Fujifilm X-T4 Camera and VG-XT4 Vertical Battery Grip.



Image: The Fujifilm NP-W235 Rechargeable Li-Ion Battery, a black rectangular battery with 'FUJIFILM' branding.

SETUP

1. Initial Charging

Before first use, fully charge the NP-W235 battery. This battery requires an external wall charger (not included with the battery itself) for charging. Connect the battery to a compatible Fujifilm charger and plug the charger into a power outlet. Refer to your charger's instruction manual for specific charging procedures and indicators.

2. Inserting the Battery

Ensure the camera is powered off before inserting or removing the battery. Open the battery compartment cover on your compatible Fujifilm camera or vertical battery grip. Align the battery with the compartment's contacts and insert it firmly until it clicks into place. Close the battery compartment cover securely.

OPERATING

1. Powering On/Off

After inserting a charged battery, power on your camera using its designated power switch. To power off, use the same switch. Always power off the camera before removing the battery.

2. Battery Life

The NP-W235 battery is designed for extended use. Under consistent operation, it can provide approximately 4-5 hours of power. Actual battery life may vary based on camera settings, usage patterns (e.g., video recording, continuous shooting, LCD/EVF usage), and environmental conditions.

3. Compatibility

This battery is specifically designed for Fujifilm cameras. Compatible models include, but are not limited to, the Fujifilm X-T4, GFX100S, and GFX50S II. It is not compatible with cameras from other manufacturers such as Canon or other DSLR systems. Always use genuine Fujifilm batteries for optimal performance and safety.

MAINTENANCE

1. Storage

Store the battery in a cool, dry place away from direct sunlight and extreme temperatures. For long-term storage, it is recommended to charge the battery to approximately 50% capacity. Avoid storing fully charged or completely depleted batteries for extended periods.

2. Cleaning

Keep the battery terminals clean. If they become dirty, wipe them with a dry, soft cloth. Do not use alcohol, solvents, or other harsh chemicals.

3. Disposal

Do not dispose of the battery in household waste. Lithium-ion batteries should be recycled or disposed of according to local regulations. Contact your local waste management authority for information on proper battery recycling.

TROUBLESHOOTING

1. Battery Not Charging

- Ensure the battery is correctly inserted into the charger.
- Verify the charger is properly connected to a working power outlet.
- Check for any visible damage to the battery or charger.
- Try charging a different battery (if available) to determine if the issue is with the battery or the charger.

2. Battery Not Powering Camera

- Confirm the battery is fully charged.
- Ensure the battery is correctly inserted into the camera's battery compartment.
- Check the camera's power switch and settings.
- If possible, try a different charged battery to isolate the problem.

3. Shortened Battery Life

- Review camera settings that consume more power (e.g., continuous video recording, high screen brightness, Wi-Fi/Bluetooth usage).
- Ensure the battery is not old or degraded. Lithium-ion batteries naturally lose capacity over time and charge cycles.
- Operating in extremely cold environments can temporarily reduce battery performance.

SPECIFICATIONS

Product Type	Camera Power Supply
Model Number	NP-W235 (Item model number: 16651409)
Battery Type	Lithium-Ion
Amperage	2200 Milliamps
Product Dimensions	2.1 x 1.5 x 0.9 inches (3.911 cm L x 5.308 cm W x 10.007 cm H)
Item Weight	3.21 ounces (91 Grams)
ASIN	B0851TVR2K
Country Of Origin	China
Date First Available	February 26, 2020
Color	Black
What's in the Box	NP-W235 Battery

WARRANTY AND SUPPORT

For information regarding the product warranty, please refer to the warranty card included with your purchase or visit the official Fujifilm website. For technical support or further assistance, please contact Fujifilm customer service directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0851TVR2K>

More documents and user manuals: <https://manuals.plus/>