

[Manuals.plus](#) /

› [EVACH](#) /

› EVACH K806 Stylus Pen User Manual for Dell 2-in-1 Laptops

EVACH K806

EVACH K806 Stylus Pen User Manual

For Dell 2-in-1 Laptops and Compatible Capacitive Devices

1. INTRODUCTION

The EVACH K806 Stylus Pen is designed to provide a precise and responsive writing and drawing experience on Dell 2-in-1 Laptops and other capacitive touchscreen devices. Featuring a 1.5mm ultra-fine tip and touch-control activation, this stylus aims to enhance your interaction with your device for various tasks.



Image: The EVACH K806 Stylus Pen in white, shown alongside a Dell 2-in-1 laptop, illustrating its use for digital input.

2. KEY FEATURES

- **1.5mm Ultra-Fine Tip:** Provides pinpoint accuracy for writing, drawing, and navigation.
- **Touch-Control Activation:** Simple touch to power on and off, ensuring ease of use.
- **Durable Construction:** Anodized aluminum body with a sensitive copper tip designed for longevity.
- **Long Battery Life:** Up to 8 hours of continuous use on a 60-minute charge, with smart auto-shutdown after 30 minutes of inactivity.
- **Wide Compatibility:** Works with various capacitive touchscreen devices, including Android, iOS, and Windows smartphones, tablets, and notebooks.

Enjoy Amazing Writing & Experience On Multiple Devices

Compatible with any capacitive devices

Works for any capacitive device and
perfect for note-taking or drawing



Image: The EVACH K806 Stylus Pen shown with icons representing compatibility with Android, iOS, and Windows devices, including smartphones, tablet PCs, and notebooks.

3. PACKAGE CONTENTS

- EVACH K806 Stylus Pen (White)
- USB-C Charging Cable

4. SETUP

4.1 Charging the Stylus

1. Connect the provided USB-C charging cable to the charging port on the stylus.
2. Plug the other end of the cable into a standard 5V/0.2A USB power source.
3. A full charge typically takes 60 minutes. The indicator light will change to show charging status (e.g., red for

charging, blue for fully charged, or off).

Important: Do not use fast chargers, as high current can damage the internal chip of the stylus.

4.2 Powering On/Off

- To power on: Gently touch the top of the stylus. The indicator light will illuminate.
- To power off: Gently touch the top of the stylus again. The indicator light will turn off.

The stylus will automatically shut down after 30 minutes of inactivity to conserve battery.

Smart Power Saving

Auto Shutdown after 5 Minutes Idle



Simply touch to
activate & turn off



Type - C Charging Fast & Safe
(USB- C Cable Included)



100 Minutes
Fully Charge



20 Hours
Playing Time



3 Years
Stand-by Time



Image: Diagram illustrating the smart power saving features of the EVACH K806 Stylus Pen, including touch activation, Type-C charging, and battery life indicators.

5. OPERATING INSTRUCTIONS

5.1 General Use

The EVACH K806 Stylus Pen is an active capacitive stylus. Once powered on, it functions like a traditional pen, allowing you to interact directly with your device's touchscreen. No Bluetooth pairing or special drivers are required for basic functionality.

5.2 Writing and Drawing in Applications

For writing or drawing in specific applications (e.g., note-taking apps, drawing software), you may need to adjust the application's input settings. Many applications require you to select a handwriting or drawing mode to enable stylus input. For example, in some note applications, you might need to tap a small pen icon to activate the drawing function.



Silky smooth 1.45mm fine tip
Using the latest sanding and polishing technology
Makes your writing and paintings like water flows

Image: Close-up of the EVACH K806 Stylus Pen tip on a tablet screen, demonstrating the 1.45mm fine point for precise writing and drawing.

Perfect to Drawing and Writing
Durable and Sensitive copper tip
Resistant to wear



Image: The EVACH K806 Stylus Pen being used to draw colorful diagrams on a tablet, highlighting its suitability for creative tasks.

6. MAINTENANCE

- **Charging:** Always use the provided USB-C cable and a compatible 5V/0.2A power adapter. Avoid using high-current fast chargers to prevent damage.
- **Tip Care:** The stylus features a durable copper tip. Avoid applying excessive force or dropping the stylus to prevent damage to the tip or internal components.
- **Cleaning:** Wipe the stylus body with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.

7. TROUBLESHOOTING

Frequently Asked Questions/Issues:

- **Q: Why does the indicator light blink blue?**
A: A blinking blue indicator typically signifies that the battery is low and requires charging.
- **Q: I can navigate screen pages, but I cannot write or draw in applications. What should I do?**

A: Verify the software configuration of the application you are using. If the application supports handwriting or drawing, ensure that the stylus pen drawing/writing mode is enabled within the app's settings.

• **Q: The stylus is not responding.**

A: Ensure the stylus is powered on. If it is, check the battery level and charge if necessary. If the issue persists, try restarting your device.

If you encounter any other issues or have concerns, please refer to the 'Warranty and Support' section for contact information.

8. SPECIFICATIONS

Feature	Specification
Product Type	Active Capacitive Stylus
Model Number	K806
Dimensions (L x W x H)	7.72 x 1.85 x 0.91 inches
Item Weight	1.6 ounces (45.36 grams)
Tip Size	1.5mm Ultra-Fine
Material	Anodized Aluminum Body, Copper Tip
Battery Type	Lithium Polymer (included)
Charging Input	5V/0.2A (USB-C)
Charging Time	Approx. 60 minutes
Continuous Use Time	Approx. 8 hours
Auto-Shutdown	After 30 minutes of inactivity



One-year
limited warranty



Precise Ballpoint tip



Long Standby Battery



No Driver or Bluetooth
Setting Required



Detailed Parameter

Product Type	Ev1204
Size	146*9mm
Weight	13.3g
Color	White

Image: Infographic displaying detailed parameters of the EVACH K806 Stylus Pen, including product type, size, weight, color, and key features like precise tip and long standby battery.

9. WARRANTY AND SUPPORT

The EVACH K806 Stylus Pen comes with a one-year limited warranty. For any questions, concerns, or troubleshooting assistance regarding your product or service, please contact EVACH customer support. We are committed to providing support and resolving any issues you may encounter.

You can typically find contact information on the product packaging or through the retailer where the product was purchased. For purchases made on Amazon, you can contact the seller, Evach Technology, through your order history.

Standard return policies apply, typically allowing for refund or replacement within 30 days of purchase, subject to retailer terms.

© 2024 EVACH. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question