

- Manuals.plus /
- > iMah /
 - > iMah Ni-MH 29600-10 Replacement Battery User Manual for Summer Infant Baby Monitors

iMah 29600-10

iMah Ni-MH 29600-10 Replacement Battery User Manual for Summer Infant Baby Monitors

Model: 29600-10

This manual provides essential information for the safe and effective use of your iMah replacement battery.

1. INTRODUCTION

Thank you for choosing the iMah Ni-MH 29600-10 Replacement Battery. This battery is designed to provide reliable power for compatible Summer Infant Baby Monitors. Please read this manual carefully before installation and use to ensure proper function and safety.

2. PRODUCT OVERVIEW

The iMah 29600-10 is a Ni-MH (Nickel-Metal Hydride) battery pack, specifically engineered as a replacement for various Summer Infant Baby Monitor models. It features a 3.6V output and 800mAh capacity, ensuring extended operation for your device.



Figure 1: iMah Ni-MH AAA 800mAh 3.6V Battery 29600-10. This image displays the battery pack with its specifications clearly labeled.



Figure 2: Close-up view of the iMah battery showing the connector type. The connector has two wires (red and black) leading to a white plastic plug.

3. COMPATIBILITY

This iMah 29600-10 battery is compatible with the following Summer Infant Baby Monitor models:

- Summer Infant Wide View Digital Color Video Monitor: 29000, 29000A, 29000B, 29003, 29003A
- Summer Infant Wide View Handheld Baby Monitor: 29030, 29040
- Summer Infant In View Duo Color Video Monitor: 29500
- Summer Infant In View Digital Color Video Monitor: 28650, 285650A
- Summer Infant Sure Sight 2.0 Digital Color Video Monitor: 29600
- Summer Infant Easy Sight 2.0 Digital Color Video Monitor: 29630

- Summer Glimpse Video Baby Monitor: 29890
- Summer Glimpse Plus Video Baby Monitor with 3.5-inch Color LCD: 36004

Compatible with the listed Summer Infant Monitor Models:



Sure Sight 29030



Clear Sight 29040



Wide View 29000



Wide View 29500



Glimpse 29890



Glimpse 36004

Figure 3: Visual representation of several Summer Infant monitor models compatible with the iMah 29600-10 battery, including Wide View 29000, Sure Sight 29030, Clear Sight 29040, Wide View 29500, Glimpse 29890, and Glimpse 36004.

Important Note on Connector Type:

Please verify the connector type of your existing battery before purchase and installation.

Some monitor models, particularly those from other brands like Motorola (e.g., MBP33S/MBP36/MBP36S), may share similar model numbers but use different connector types depending on their manufacturing year. This iMah 29600-10 battery features a specific square connector type. Ensure it matches your device's requirement.




Figure 4: Detailed view of the square connector type of the iMah 29600-10 battery, highlighting its front and black sides for identification.

4. SAFETY INFORMATION

Observe the following safety precautions to prevent damage to the battery, device, or personal injury:

- Do not disassemble, crush, puncture, or short-circuit the battery.
- Do not expose the battery to high temperatures (above 60°C / 140°F) or direct sunlight.
- Do not dispose of the battery in fire or water.
- Keep the battery away from children.
- Use only with compatible devices as listed.
- This battery is equipped with over-voltage, over-current, over-charge, and short-circuit protection for enhanced safety.

- Dispose of used batteries according to local regulations.

5. INSTALLATION GUIDE

To replace the battery in your compatible Summer Infant Baby Monitor, follow these general steps. Specific steps may vary slightly by monitor model, refer to your monitor's original manual if available.

1. **Power Off Device:** Ensure your baby monitor unit is completely powered off and disconnected from any power source.
2. **Locate Battery Compartment:** Identify and open the battery compartment on your monitor unit. This usually involves removing a screw or sliding a cover.
3. **Remove Old Battery:** Carefully disconnect the old battery's connector from the monitor's port. Gently lift out the old battery.
4. **Insert New Battery:** Align the iMah 29600-10 replacement battery with the compartment. Connect the battery's plug to the monitor's port, ensuring it clicks securely into place. Do not force the connector.
5. **Secure Compartment:** Close the battery compartment cover and secure it with any screws or latches.
6. **Initial Charge:** Connect your monitor to its power adapter and allow the new battery to charge fully before its first use. This may take several hours.

6. OPERATION AND CHARGING

Once installed, the iMah 29600-10 battery operates seamlessly with your Summer Infant Baby Monitor. For optimal performance and battery longevity:

- **First Use:** Fully charge the battery before its initial use.
- **Regular Charging:** Charge the battery when the monitor indicates low power. Avoid completely draining the battery frequently, as this can reduce its overall lifespan.
- **Charging Time:** Charging times will vary depending on the monitor model and the battery's current charge level.
- **Storage:** If storing the monitor for an extended period, ensure the battery is partially charged (around 50%) and store it in a cool, dry place.

7. MAINTENANCE

Proper maintenance can extend the life of your battery:

- Keep the battery and monitor contacts clean and free of debris.
- Avoid extreme temperatures.
- Do not expose the battery to moisture.
- If the battery shows signs of swelling, leakage, or damage, discontinue use immediately and replace it.

8. TROUBLESHOOTING

If you encounter issues with your new iMah battery, consider the following:

- **Battery Not Charging:**
 - Ensure the battery is correctly installed and the connector is firmly seated.
 - Verify that the monitor's power adapter is functioning and properly connected to a power outlet.
 - Check the monitor's charging port for any obstructions or damage.
- **Short Battery Life:**

- Ensure the battery has been fully charged.
- Battery life naturally degrades over time and with usage cycles.
- Environmental factors like extreme cold can temporarily reduce battery performance.

- **Monitor Not Powering On:**

- Confirm the battery is installed correctly and fully charged.
- Try powering the monitor directly with its AC adapter to rule out a monitor issue.

If problems persist, please contact iMahDirect customer support.

9. SPECIFICATIONS

Feature	Specification
Model Number	29600-10
Battery Type	Ni-MH (Nickel-Metal Hydride)
Voltage	3.6V
Capacity	800mAh
Dimensions	1.3 x 0.43 x 1.69 inches
Item Weight	0.81 ounces
Number of Batteries	3 AAA cells (included)
Manufacturer	iMahDirect



Figure 5: The iMah battery showing a manufacturing date (e.g., 2020-3-02). The manufacturing date is printed on the battery, not an expiration date.

10. WARRANTY AND SUPPORT

iMahDirect provides a **24-month warranty** from the date of purchase, covering all quality-related issues. If you experience any problems with your battery within this period, please contact iMahDirect customer support for assistance. For further support or inquiries, please visit the [iMah Store on Amazon](#).

© 2025 iMah. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0852M9JZ8>

More documents and user manuals: **<https://manuals.plus/>**