Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SONGMICS UGKR72WT

SONGMICS Kids' Bookcase UGKR72WT Instruction Manual

Model: UGKR72WT | Brand: SONGMICS

1. Important Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- Always assemble the bookcase on a stable, level surface.
- Do not overload shelves.
- Ensure the bookcase is properly secured to the wall using the anti-tip kit to prevent tipping.
- Keep the bookcase away from heat sources.
- Do not place heavy objects on the top shelf.
- Regularly check all connections and fasteners to ensure they remain tight and secure.

2. Package Contents

Verify that all components are present before beginning assembly.

- 1 x Bookcase (main frame components)
- 1 x Accessory Kit (screws, anti-tip kit, etc.)
- 1 x Instructions (this manual)



Image 2.1: Overview of the SONGMICS Kids' Bookcase, featuring a white frame with blue and gray fabric slings and a space-themed design on the side panels.

3. Specifications

Feature	Detail
Brand	SONGMICS
Model Name	Kids’ Bookcase, Book Organizer
Model Number	UGKR72WT
Dimensions (D x W x H)	11" x 24.6" x 23.6" (62.5 x 28 x 60 cm)
Item Weight	5.5 lbs (2.5 kg)
Material	Engineered Wood, Polyester

Number of Shelves	4
Color	White, Blue, Gray (Space Theme)
Assembly Required	Yes
Special Feature	Lightweight, Anti-Tip Kit Included



Image 3.1: Diagram showing the dimensions of the bookcase: 24.6 inches wide, 11 inches deep, and 23.6 inches high.

4. Assembly Instructions

Follow these steps carefully for proper assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Refer to the included parts list in the accessory kit to identify each component.

3. **Attach Fabric Slings:** Slide the fabric slings onto the designated support bars. Ensure the colored slings are arranged as desired (e.g., blue, gray, white, blue from top to bottom).
4. **Mount Support Bars:** Insert the ends of the support bars into the pre-drilled holes on the side panels. Secure them using the provided screws.
5. **Secure Side Panels:** Ensure all screws are tightened to firmly connect the side panels and support bars.
6. **Install Anti-Tip Kit:** For safety, attach the anti-tip kit to the back of the bookcase and secure it to a wall stud according to the instructions provided in the accessory kit. This is crucial to prevent accidental tipping.



Image 4.1: Illustration showing the insertion of support bars into the side panel during assembly.



Image 4.2: The anti-tip kit securely fastened to the top rear of the bookcase and anchored to a wall, demonstrating proper safety installation.

5. Operating Instructions

The SONGMICS Kids' Bookcase is designed for easy access and organization of children's books.

- **Book Placement:** Place books with their covers facing forward in the fabric slings for easy identification by children.
- **Capacity:** The four tiers allow for a good number of books to be displayed. Avoid overfilling the slings to prevent damage to the fabric or the books.
- **Accessibility:** The height of the bookcase is designed to be accessible for young children, encouraging independent selection and return of books.



Image 5.1: A hand reaching for a book from one of the fabric slings, illustrating the ease of access for children.

6. Maintenance and Care

Proper care will extend the life of your bookcase.

- **Cleaning:** Wipe the wooden parts with a dry cloth. For the fabric slings, clean with a damp cloth and air dry. Do not wash the fabric parts with water in a machine.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Re-tighten if necessary.
- **Avoid Moisture:** Keep the bookcase in a dry environment to prevent damage to the engineered wood.



Image 6.1: Detailed view of the durable polyester fabric slings and the smooth, rounded edges of the bookcase, emphasizing child-friendly design and material quality.

7. Troubleshooting

Common issues and their solutions.

- **Bookcase feels wobbly:** Ensure all screws are fully tightened. Verify the bookcase is on a level surface. If installed, check the anti-tip kit for secure attachment to the wall.
- **Books falling out:** Ensure books are placed correctly within the fabric slings. Avoid overfilling. The extra bottom bar is designed to prevent books from leaning too far forward.
- **Difficulty assembling:** Review the assembly instructions carefully. Ensure all parts are correctly oriented before tightening screws. Do not force components together.

8. Warranty and Support

For warranty information or product support, please contact SONGMICS customer service. Refer to your purchase documentation for specific warranty terms and contact details.

You can also visit the official SONGMICS website for additional resources and support.

Manufacturer: SONGMICS

© 2026 SONGMICS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0852X15HC

More documents and user manuals: **https://manuals.plus/**