

## OneDer V3

# OneDer V3 Portable Bluetooth Speaker User Manual

Model: V3

## INTRODUCTION

Thank you for purchasing the OneDer V3 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it thoroughly before use to ensure optimal performance and longevity of your device.



Image: The OneDer V3 Portable Bluetooth Speaker, red in color, shown alongside a smartphone playing music, illustrating its primary function as a portable audio device.

## PACKAGE CONTENTS

Verify that all items are present in your package:

- OneDer V3 Portable Bluetooth Speaker
- USB Charging Cable
- AUX Cable
- User Manual



## El Paquete Incluye

1	Bocina Bluetooth	2	Caja	3	Cable USB de Carga
4	Manual	5	Cable AUX		

Image: An exploded view of the OneDer V3 speaker package, clearly showing the speaker, its retail box, a USB charging cable, an AUX cable, and the user manual.

## PRODUCT OVERVIEW

The OneDer V3 speaker features a robust design with advanced audio technology for an immersive listening experience.

# Bocina Bluetooth Inalámbrico Portátil

Sonido Estéreo Envolvente de 360° HiFi



**360° Stereo HiFi Sound:** Experience rich, immersive audio from all directions.



## Tecnología Avanzada

Doble Diafragma Subwoofer  
Se reduce la distorsión para tener  
el sonido más natural y suave

## Reducción de Ruido

Corrija el ruido del entorno para crear  
una calidad de sonido HiFi de alta  
definición

**Advanced Audio Technology:** Features a dual diaphragm subwoofer for natural sound and noise reduction for high-definition audio.

## Moda & Elegante

Material de tela de calidad con un procesamiento delicado para llegar un tacto más cómodo y resistente al polvo.



**Durable and Elegant Design:** Crafted with quality fabric material for a comfortable touch and dust resistance.



## Diseño Compacto & Puerto Escondidos

Todos los puertos y botones son diseñados para tener la mejor protección y su modelo perfecto visual.

**Compact Design with Hidden Ports:** All ports and buttons are discreetly designed for protection and a clean visual aesthetic.

### CONTROLS AND PORTS

Familiarize yourself with the speaker's controls and connection ports:

# Botones & Puertos




Image: A detailed diagram showing the location and function of each button and port on the OneDer V3 speaker. These include the DC 5V charging port, USB port, TF card slot, AUX input, Volume -/Previous, Play/Pause, Mode/Next, Volume +/Next, and Power ON/OFF buttons.

- **DC 5V Port:** For charging the speaker.
- **USB Port:** For playing music from a USB flash drive.
- **TF Card Slot:** For playing music from a TF (MicroSD) card.
- **AUX Port:** For connecting external audio devices via a 3.5mm audio cable.
- **Volume - / Previous:** Short press for previous track, long press to decrease volume.
- **Play / Pause:** Press to play or pause music.
- **Mode / Next:** Short press to change modes (Bluetooth, USB, TF, AUX), long press for next track.
- **Volume + / Next:** Short press for next track, long press to increase volume.
- **ON / OFF:** Power button to turn the speaker on or off.

## Charging the Speaker

Before first use, fully charge the speaker. Connect the supplied USB charging cable to the DC 5V port on the speaker and the other end to a USB power adapter (not included) or a computer's USB port. The charging indicator light will illuminate during charging and turn off when fully charged.

## Powering On/Off

Press and hold the **ON/OFF** button to turn the speaker on or off.

## OPERATING INSTRUCTIONS

### Bluetooth Mode (Wireless Connection)

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. Enable Bluetooth on your smartphone, tablet, or laptop.
3. Search for available devices and select "OneDer V3" (or similar name) from the list.
4. Once paired, the speaker will emit a confirmation tone, and the LED light will stop flashing.
5. You can now play audio from your device through the speaker.

**Llamadas Manos Libres & Bluetooth 4.2**

Con tecnología integrada de cancelación de ruido y eco para llamadas más cristalinas y claras

Hola amiguito

Cómo va?

Bien, vamos a cenar?

Dale, nos vemos.

OneDer V16  
00:10

Recorder

Rechazar

Mensaje

Conectar

Image: The OneDer V3 speaker shown next to a smartphone displaying an incoming call, illustrating its hands-free calling capability via Bluetooth 4.2.

## Hands-Free Calling

When connected via Bluetooth, the speaker supports hands-free calling:

- **Answer Call:** Press the **Play/Pause** button once.
- **End Call:** Press the **Play/Pause** button once during a call.
- **Reject Call:** Press and hold the **Play/Pause** button.

## USB/TF Card Mode

Insert a USB flash drive or TF (MicroSD) card into the corresponding port. The speaker will automatically detect the storage device and begin playing audio files. Use the **Mode** button to switch between input sources if needed.

## AUX Mode (Wired Connection)

Connect one end of the 3.5mm AUX cable to the speaker's AUX port and the other end to the audio output of your device. The speaker will automatically switch to AUX mode. If not, press the **Mode** button to select AUX input.

## Volume Control

Long press the **Volume +** button to increase volume. Long press the **Volume -** button to decrease volume.

## Track Navigation

Short press the **Volume +** button for the next track. Short press the **Volume -** button for the previous track.

## MAINTENANCE

- Keep the speaker away from water, moisture, and extreme temperatures.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid dropping or subjecting the speaker to strong impacts.
- When not in use for extended periods, store the speaker in a cool, dry place and charge it periodically to maintain battery health.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Bluetooth not enabled on device; speaker not in pairing mode; too far from device.	Ensure Bluetooth is on. Restart speaker to enter pairing mode. Move speaker closer to device (within 10 meters).
No sound.	Volume too low; incorrect mode selected; audio cable not connected properly.	Increase volume on speaker and connected device. Press <b>Mode</b> button to select correct input. Reconnect audio cable securely.

Problem	Possible Cause	Solution
Poor sound quality.	Low battery; interference; device too far.	Charge speaker. Move away from other electronic devices. Move speaker closer to connected device.

## SPECIFICATIONS

- Brand:** OneDer
- Model:** V3 Portable Bluetooth Speaker
- Bluetooth Version:** 4.2
- Speaker Output Power:** 5 Watts
- Power Source:** Battery
- Battery Life:** Approximately 6 hours
- Connectivity:** Bluetooth, AUX, USB, TF Card
- Audio Output Mode:** Stereo
- Special Features:** Hands-free calling, 360° HiFi Stereo Sound, Noise Reduction, Dual Diaphragm Subwoofer
- Compatible Devices:** Smartphones, Tablets, Laptops
- Dimensions (Package):** 16.6 x 12.6 x 12 cm
- Weight (Package):** 730 g

## WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official OneDer website. Keep your proof of purchase for warranty claims.

© 2023 OneDer. All rights reserved.

## Related Documents - V3

	<a href="#"><u>iWorld Bluetooth Audio Car Kit Instruction Manual</u></a> Instruction manual for the iWorld Bluetooth Audio Car Kit, detailing features, specifications, charging, and operation for wireless music streaming and hands-free calls.
	<a href="#"><u>Oneder Drive V2 Guitar Pedal - User Manual and Specifications</u></a> Detailed information on the Oneder Drive V2 guitar pedal, including controls, settings, and warranty information. Learn about its unique tone, character, and features.

   V3 User Manual	<p><a href="#"><b>Fosi Audio V3 User Manual: High-Performance Stereo Amplifier Guide</b></a></p> <p>Explore the Fosi Audio V3, a high-performance stereo audio power amplifier featuring the Texas Instruments TPA3255 chip. This user manual covers product overview, specifications, setup, troubleshooting, and warranty information.</p>
   V3 Návod k obsluze	<p><a href="#"><b>Fosi Audio V3 Stereo Amplifier User Manual</b></a></p> <p>Comprehensive user manual for the Fosi Audio V3 stereo amplifier, detailing its features, specifications, quick installation guide, and troubleshooting tips. Learn about its TPA3255 chip, 600W output, and HiFi audio capabilities.</p>
   V3 User Manual	<p><a href="#"><b>Fosi Audio V3 Stereo Power Amplifier User Manual</b></a></p> <p>Detailed user manual for the Fosi Audio V3 high-performance stereo power amplifier. Learn about its features, specifications, setup, troubleshooting, and warranty. Features Texas Instruments TPA3255 chip for up to 600W output.</p>
   V3 User Manual	<p><a href="#"><b>Fosi Audio V3 User Manual: High-Performance Stereo Amplifier</b></a></p> <p>Detailed user manual for the Fosi Audio V3 stereo amplifier, featuring the Texas Instruments TPA3255 chip. Learn about product overview, specifications, setup, troubleshooting, and warranty information.</p>