

[Manuals.plus](#) /

› [ZdalaMit](#) /

› ZdalaMit Remote Control Instruction Manual for Vizio Soundbar Systems

ZdalaMit a66a5177-9e18-4190-9607-bb24503e05bc

ZdalaMit Replacement Remote Control Instruction Manual

For Vizio Soundbar Systems: sb3251n-e0, SB3651n-H6, SB3621ns-H8, SB3651n-H46, SB3651ns-H6

1. PRODUCT OVERVIEW

This manual provides instructions for the ZdalaMit replacement remote control, designed for various Vizio Soundbar systems. This remote offers direct functionality without the need for programming or pairing.



Image: The ZdalaMit replacement remote control positioned alongside a Vizio soundbar and television, illustrating its intended use environment.

2. SETUP AND BATTERY INSTALLATION

2.1 Battery Requirements

- The remote control requires two (2) 1.5V AAA alkaline batteries.
- Batteries are not included with the remote control.

2.2 Installing Batteries

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: The rear view of the ZdalaMit remote control with the battery compartment open, illustrating the correct orientation for AAA battery insertion.

2.3 Initial Use

No programming or pairing is required for this replacement remote control. Once new batteries are installed, the remote is ready for immediate use with compatible Vizio Soundbar systems.

3. OPERATING THE REMOTE CONTROL

The remote control features standard buttons for controlling your Vizio Soundbar system. Ensure there is a clear line of sight between the remote control and the soundbar's infrared receiver.



Image: A clear front view of the ZdalaMit remote control, displaying all functional buttons and the LCD display area.

3.1 Button Functions

- **Power** (): Turns the soundbar on or off.
- **Input**: Cycles through available audio input sources (Aux, Digital, Optical, HDMI IN, HDMI-ARC, Bluetooth, USB).
- **Menu**: Accesses the soundbar's menu settings.
- **Volume Up (+) / Down (-)**: Adjusts the soundbar's volume level.
- **Mute** (): Mutes or unmutes the soundbar's audio output.

- **Navigation Arrows (▲ ▼ ◀▶):** Used for navigating menus and adjusting settings.
- **Play/Pause (⏮):** Controls media playback.
- **Skip Forward (⏭) / Skip Backward (⏮):** Skips tracks or chapters during media playback.

4. MAINTENANCE

4.1 Battery Replacement

Replace batteries when the remote's response becomes inconsistent or stops working. Always replace both AAA batteries simultaneously with new ones to ensure optimal performance. Refer to Section 2.2 for battery installation steps.

4.2 Cleaning


To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

5. TROUBLESHOOTING

- **Remote not responding:**
 - Ensure new AAA batteries are correctly installed.
 - Check for any obstructions between the remote control and the soundbar's infrared receiver.
 - Confirm the remote is pointed directly at the soundbar.
 - Replace batteries if they are old or depleted.
- **Display is dim or not visible:**
 - The remote's display may appear dim under bright ambient lighting conditions. Try using it in a less brightly lit environment.
 - Ensure batteries are fresh and fully charged. Low battery power can affect display brightness.

6. SPECIFICATIONS





5.5 inch

1.5 inch

Image: The ZdalaMit remote control displayed with its approximate dimensions: 5.5 inches in length and 1.5 inches in width.

Feature	Detail
Brand	ZdalaMit
Model Number	a66a5177-9e18-4190-9607-bb24503e05bc
Connectivity Technology	Infrared
Compatible Devices	Vizio Soundbar Systems
Battery Type	AAA

Number of Batteries Required	2
Maximum Range	33 Feet (approx. 10 meters)
Button Quantity	15
Item Weight	40 Grams
Item Dimensions (L x W x H)	5.56" x 1.59" x 0.55"

7. WARRANTY AND SUPPORT

7.1 Warranty Information

This ZdalaMit remote control comes with a 1-year warranty from the manufacturer.

7.2 Customer Support

For any queries, issues, or warranty claims, please contact the seller or manufacturer directly through your purchase platform. Provide your order details for efficient assistance.