

[manuals.plus](#) /

› [ZEBRONICS](#) /

› [Zebronics Zeb-Paradise Bluetooth Wired Over-Ear Headphones User Manual](#)

ZEBRONICS ZEB-PARADISE

Zebronics Zeb-Paradise Bluetooth Wired Over-Ear Headphones User Manual

Model: ZEB-PARADISE

1. INTRODUCTION

The Zebronics Zeb-Paradise is a versatile over-ear headphone designed for both wireless Bluetooth and wired audio connections. It features an ergonomic design with soft earcups for extended comfort. This headphone includes a built-in microphone for communication, offers approximately 11 hours of playback time, and supports voice assistant functionality for Android and iOS devices. Integrated controls allow for volume adjustment, media playback management, and call handling. Additionally, it includes a built-in FM Radio and supports Micro SD card playback.



Figure 1: Zebronics Zeb-Paradise Over-Ear Headphones, front view.

2. PRODUCT OVERVIEW

2.1 Key Features

- Wireless Bluetooth connectivity
- Wired AUX input capability
- Micro SD card support for audio playback
- Integrated FM Radio function
- Soft and comfortable earcups
- Adjustable headband for a customized fit

- Media and volume controls
- Call function with built-in microphone
- Built-in rechargeable battery
- Voice assistant support for Android/iOS

2.2 Controls and Ports



Figure 2: Diagram illustrating the controls and ports on the Zebronics Zeb-Paradise headphones.

- **Power On/Off Button:** Used to power the headphones on or off.
- **Previous/Volume- Button:** Short press for previous track, long press to decrease volume.
- **Pause/Play Button:** Short press to play or pause audio, answer/end calls. Long press to activate voice assistant.
- **Next/Volume+ Button:** Short press for next track, long press to increase volume.
- **Microphone (Mic):** For hands-free calling.
- **AUX IN Port:** For wired audio connection using a 3.5mm audio cable.
- **Micro SD Card Slot:** For playing audio files directly from a Micro SD card.
- **Charging Port:** For connecting the charging cable.

3. SETUP

3.1 Charging the Headphones

1. Connect the charging cable (included) to the charging port on the headphones.
2. Connect the other end of the charging cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The LED indicator will illuminate during charging and turn off once fully charged.
4. Allow approximately 2-3 hours for a full charge.

3.2 Bluetooth Pairing

1. Ensure the headphones are fully charged.
2. Press and hold the Power On/Off button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your mobile device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for available Bluetooth devices.
5. Select "ZEB-PARADISE" from the list of devices.
6. Once paired, the LED indicator will flash blue slowly.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- To power on, press and hold the Power On/Off button until the LED indicator lights up.
- To power off, press and hold the Power On/Off button until the LED indicator turns off.

4.2 Bluetooth Mode

- After successful pairing, the headphones will automatically connect to the last paired device when powered on.
- Use the Previous/Volume- and Next/Volume+ buttons for track navigation and volume control.
- Use the Pause/Play button to play or pause audio.

4.3 Wired (AUX) Mode

- Connect one end of a 3.5mm audio cable (not included) to the AUX IN port on the headphones.
- Connect the other end to the audio output of your device.
- In wired mode, controls on the headphones may be limited; use your connected device for full control.

4.4 Micro SD Card Playback

- Insert a Micro SD card with audio files into the Micro SD card slot.
- The headphones will automatically switch to Micro SD mode and begin playing audio.
- Use the Previous/Volume- and Next/Volume+ buttons for track navigation and volume control.
- Use the Pause/Play button to play or pause audio.

4.5 FM Radio

- To enter FM mode, press the Mode button (if available, or cycle through modes using the Play/Pause button if it has multiple functions).
- Press the Pause/Play button once to auto-scan and save available FM channels.
- Use the Previous/Volume- and Next/Volume+ buttons to switch between saved channels.

4.6 Call Function

- **Answering/Ending Calls:** Press the Pause/Play button once to answer an incoming call or end an ongoing call.
- **Rejecting Calls:** Press and hold the Pause/Play button to reject an incoming call.
- **Redialing:** Double-press the Pause/Play button to redial the last number.

4.7 Voice Assistant

- Ensure your headphones are connected to a smartphone with an active voice assistant (e.g., Google Assistant, Siri).
- Press and hold the Pause/Play button for approximately 2 seconds to activate the voice assistant.

5. MAINTENANCE

- Clean the headphones with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Store the headphones in a cool, dry place when not in use.
- Do not attempt to disassemble or modify the headphones, as this will void the warranty and may cause damage.
- Keep the charging port and AUX port free from dust and debris.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on	Low battery	Charge the headphones fully.
No sound	Volume too low; Not paired; Incorrect mode; Loose cable	Increase volume; Ensure proper Bluetooth pairing; Switch to correct mode (BT, AUX, SD, FM); Check AUX cable connection.
Cannot pair via Bluetooth	Headphones not in pairing mode; Device Bluetooth off; Too far from device	Ensure headphones are flashing red/blue; Turn on device Bluetooth; Move headphones closer to device (within 10 meters).
Poor FM reception	Weak signal; Interference	Move to an area with better signal; Re-scan channels.

7. SPECIFICATIONS

Feature	Detail
Brand	ZEBRONICS
Model Name	ZebParadise
Headphones Form Factor	Over Ear
Connector Type	Wireless / Wired
Microphone Format	Built-In

Feature	Detail
Material	Plastic
Maximum Operating Distance	10 Metres
Product Dimensions (LxWxH)	8.7 x 19 x 21.2 cm
Item Weight	158 g
Battery Life (Approx.)	11 hours (as per product description)

8. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official Zebronics website. For technical support or service inquiries, please contact Zebronics customer service through their official channels.

What's in the Box:

- Zebronics Zeb-Paradise Headphones
- Charging Cable

© 2025 ZEBRONICS. All rights reserved.

Related Documents - ZEB-PARADISE

	<p><u>Zebronics ZEB-PARADISE Wireless Headphone User Manual</u> User manual for the Zebronics ZEB-PARADISE wireless Bluetooth headphones, detailing features, specifications, pairing instructions, controls, and LED indicators.</p>
	<p><u>Zebronics ZEB-PARADISE Wireless Headphone User Manual</u> User manual for the Zebronics ZEB-PARADISE wireless BT headphones. Features include Micro SD, AUX, FM Radio, Dual Pairing, and voice assistant support. Includes specifications, package contents, and operating instructions.</p>



[Zebronics ZEB-PARADISE PLUS Wireless Headphone User Manual - ZEB-WHP 8](#)

User manual for the Zebronics ZEB-PARADISE PLUS Wireless Headphone (Model: ZEB-WHP 8). This guide covers features like Bluetooth v5.4, ENC, Dual Pairing, Gaming Mode, and AUX connectivity. It includes detailed specifications, button controls, operation instructions, LED indications, and package contents.



[Zebronics ZEB-PARADISE NEO R Wireless Headphone User Manual](#)

User manual for the Zebronics ZEB-PARADISE NEO R Wireless Headphone, covering features, specifications, button controls, Bluetooth pairing, AUX mode, gaming mode, voice assistant, and LED indications.



[Zebronics ZEB-BOOM Wireless Headphone User Manual](#)

Comprehensive user manual for the Zebronics ZEB-BOOM Wireless Headphone (Model ZEB-WHP2), covering features, specifications, button functions, connectivity, and LED indicators.



[Zebronics ZEB-Delight Pro Mini Soundbar User Manual - Features, Specifications, and Operation Guide](#)

This user manual provides comprehensive details for the Zebronics ZEB-Delight Pro Mini Soundbar. It covers product features, technical specifications, package contents, button descriptions, and step-by-step instructions for various modes including Bluetooth, USB, mSD, AUX, and FM Radio. Learn how to charge the device, use call functions, and set up TWS mode.



[Zebronics ZEB-PARADISE Wireless Headphone User Manual](#)

User manual for the Zebronics ZEB-PARADISE wireless Bluetooth headphones, detailing features, specifications, pairing instructions, controls, and LED indicators.
lang:en score:40 filesize: 1.01 M page_count: 7 document date: 2024-03-02



[Zebronics ZEB-PARADISE NEO R Wireless Headphone User Manual](#)

User manual for the Zebronics ZEB-PARADISE NEO R Wireless Headphone, covering features, specifications, button controls, Bluetooth pairing, AUX mode, gaming mode, voice assistant, and LED indications.

lang:en score:29 filesize: 8.09 M page_count: 6 document date: 2025-07-19



[Zebronics ZEB-PARADISE Wireless Headphone User Manual](#)

User manual for the Zebronics ZEB-PARADISE wireless BT headphones. Features include Micro SD, AUX, FM Radio, Dual Pairing, and voice assistant support.

Includes specifications, package contents, and operating instructions.

lang:en score:26 filesize: 1.5 M page_count: 7 document date: 2021-11-27