nania Nania Siège Auto Isofix Eno Pivotant 360° Groupe 0+/1/2/3 (0-36Kg)

nania Migo Nino Child Car Seat Instruction Manual

Model: Nania Siège Auto Isofix Eno Pivotant 360° Groupe 0+/1/2/3 (0-36Kg)

1. Introduction

This manual provides comprehensive instructions for the safe installation, operation, and maintenance of your nania Migo Nino Child Car Seat. Designed for children from birth up to approximately 12 years (40-150 cm, Group 0+/1/2/3), this car seat features a 360° rotatable base, ISOFIX attachments, and enhanced side protection for optimal safety and convenience.
Please read this manual thoroughly before first use and keep it for future reference. Proper installation and use are crucial for your child's safety.

2. Safety Information

Your child's safety is paramount. Adhere to all warnings and instructions to minimize risks.

- Always ensure the car seat is correctly installed and secured according to the instructions provided in this manual.
- Never leave your child unattended in the car seat.
- Ensure the harness is properly adjusted and snug against your child's body, with no slack.
- Do not use the car seat if it has been involved in an accident, even if there is no visible damage. Internal damage may compromise its safety.
- Only use accessories and replacement parts approved by nania.
- The car seat only rotates 360 degrees in the rearward-facing position to facilitate child installation. Do not attempt to rotate it while driving or with the child in the forward-facing position.
- Regularly inspect the car seat for any signs of wear, damage, or loose components.

3. Product Overview

The nania Migo Nino car seat is designed to adapt to your child's growth, offering safety and comfort from birth to approximately 12 years.



Image: Overview of the nania Migo Nino Child Car Seat, highlighting its 360-degree rotation capability.



Image: Front view of the car seat, showcasing the adjustable headrest and 5-point harness system.

4. Setup and Installation

The nania Migo Nino car seat can be installed using either the ISOFIX system with Top Tether or the vehicle's 3-point safety belt.

4.1. ISOFIX Installation with Top Tether

This method provides a secure and rigid connection to your vehicle's ISOFIX anchor points.

1. Locate the ISOFIX anchor points in your vehicle. These are usually found between the seat back and seat cushion.

2. Extend the ISOFIX connectors from the car seat base by pressing the release buttons.
3. Align the ISOFIX connectors with the vehicle's anchor points and push firmly until you hear a "click" sound and the indicators turn green.
4. Push the car seat firmly against the vehicle's seat back to ensure a tight fit.
5. Locate the Top Tether strap at the back of the car seat.
6. Attach the Top Tether hook to the designated Top Tether anchor point in your vehicle (usually on the back of the seat or in the boot).
7. Tighten the Top Tether strap until the indicator on the strap turns green, ensuring there is no slack.



Image: Illustration detailing the ISOFIX system and Top Tether connection points for secure installation.

4.2. Seat Belt Installation

This method uses the vehicle's 3-point safety belt to secure the car seat.

1. Place the car seat on the vehicle seat.
2. Route the vehicle's 3-point safety belt through the designated belt guides on the car seat. Refer to the labels on the car seat for correct routing based on forward or rearward facing installation.
3. Buckle the vehicle's safety belt.
4. Pull the shoulder section of the belt to remove any slack, ensuring the car seat is tightly secured and does not move more than 1 inch (2.5 cm) from side to side or front to back at the belt path.

5. Operating Instructions

5.1. Child Positioning by Weight/Age Group

The car seat adapts to different stages of your child's growth:

- **Rearward Facing Position (0-18 kg):** For infants and toddlers from birth up to 18 kg. This position offers maximum protection for the child's head and neck.
- **Forward Facing Position with Harness (9-18 kg):** For toddlers from 9 kg up to 18 kg.
- **Forward Facing Position without Harness (15-36 kg):** For older children from 15 kg up to 36 kg (approx. 12 years). The vehicle's 3-point safety belt is used to secure the child and the car seat.

ENO 360°

0+/1/2/3

0 - 3 6 k g



Dos à la route 0-18kg
Rearward facing position 0-18kg



Face à la route avec harnais 9-18kg
Forward facing position with harness 9-18kg



Face à la route sans harnais 15-36kg
Forward facing position
without harness 15-36kg

Image: Visual guide for different seating configurations: rearward-facing (0-18kg), forward-facing with harness (9-18kg), and forward-facing without harness (15-36kg).



Image: Side-by-side comparison of the car seat in rearward-facing (0-18kg) and forward-facing (9-36kg) positions.

5.2. 360° Rotation Feature

The car seat features a 360° rotation for ease of access when placing or removing your child. This feature is primarily designed for use when the seat is in the rearward-facing position (0-18 kg).

1. Ensure the vehicle is stationary and safe to operate the rotation mechanism.
2. Locate the rotation release lever, typically at the front of the base.
3. Pull the lever and rotate the seat to the desired position (e.g., facing the car door for easy access).
4. Once the child is secured or removed, rotate the seat back to the correct driving position (rearward or forward facing) until it clicks securely into place.



Image: Side view of the car seat demonstrating its recline function for child comfort.

5.3. Harness Adjustment

The 5-point harness system must be adjusted to fit your child snugly.

- **Shoulder Strap Height:** The shoulder straps should be at or just below your child's shoulders when rearward-facing, and at or just above their shoulders when forward-facing. Adjust the headrest and harness height simultaneously.
- **Harness Tightness:** Pull the harness adjustment strap until the harness is snug against your child's body. You should not be able to pinch any slack in the harness straps at the child's collarbone.
- **Buckle:** Ensure the buckle is fully engaged.

5.4. Recline Positions

The car seat offers multiple recline positions for your child's comfort, especially during sleep.

- Locate the recline adjustment lever, usually at the front or side of the seat base.
- Press the lever and adjust the seat to the desired recline angle.
- Ensure the seat locks securely into the chosen recline position.

6. Maintenance and Care

Regular cleaning and maintenance will prolong the life of your car seat.

- **Fabric Covers:** The comfort cover and reducers are removable for cleaning. Refer to the care label on the fabric for specific washing instructions. Typically, machine wash on a gentle cycle with mild detergent and air dry. Do not

tumble dry or iron.

- **Plastic Parts:** Wipe plastic parts with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.
- **Harness System:** Clean the harness straps with a damp cloth. Do not immerse the buckle or harness straps in water, as this can weaken the webbing.
- **Storage:** When not in use, store the car seat in a cool, dry place away from direct sunlight.

7. Troubleshooting

Problem	Possible Cause	Solution
Car seat feels loose after installation.	ISOFIX connectors not fully engaged, Top Tether not tight, or seat belt not tightened sufficiently.	Ensure ISOFIX indicators are green. Tighten Top Tether until indicator is green. Pull vehicle seat belt firmly to remove slack.
Harness straps are difficult to tighten or loosen.	Harness may be twisted or adjustment mechanism is obstructed.	Check that harness straps are not twisted. Ensure no fabric or debris is blocking the adjustment mechanism.
Seat does not rotate smoothly.	Rotation lock engaged, or debris in the rotation mechanism.	Ensure the rotation release lever is fully pulled. Check for any obstructions around the base. The 360° rotation is primarily for rearward-facing position.
Child seems uncomfortable.	Harness too tight/loose, recline angle incorrect, or infant inserts still in use for an older child.	Adjust harness for snug fit. Adjust recline position. Remove infant reducers as child grows.

8. Specifications

Feature	Detail
Brand	nania
Model	Nania Siège Auto Isofix Eno Pivotant 360° Groupe 0+/1/2/3 (0-36Kg)
Product Dimensions	54 x 49 x 57 cm
Item Weight	9.7 kg
Age Range (Description)	Birth to Approx. 12 Years (40-150 cm)
Weight Group	Group 0+/1/2/3 (0-36 kg)
Installation Type	ISOFIX with Top Tether, or Vehicle 3-Point Seat Belt
Harness Type	5-Point Harness (removable for older children)
Special Features	360° Rotatable, Adjustable Headrest, Reclining Positions, Side Protectors, Removable Reducers
Material	Plastic structure, 100% Polyester cover
Approval Standard	ECE R44/04



Image: Technical drawing illustrating the dimensions (height, width, depth) and weight of the car seat.

9. Warranty and Support

For warranty information, product support, or to purchase replacement parts, please contact nania customer service or visit the official nania website. Keep your proof of purchase for warranty claims.

Manufacturer: TEAM TEX

Brand Store: Visit the nania Store on Amazon

© 2024 nania. All rights reserved. Information subject to change without notice.