

[Manuals.plus](#) /

› [Tefal](#) /

› Tefal Turkish Coffee Machine CM820826 User Manual

Tefal CM820826

Tefal Turkish Coffee Machine CM820826 User Manual

Model: CM820826

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your Tefal Turkish Coffee Machine. Keep this manual for future reference.

- Always ensure the appliance is connected to a grounded power outlet.
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children.
- Do not operate the appliance if the cord or plug is damaged. Contact authorized service for repair.
- Avoid touching hot surfaces. Use handles or knobs.
- The smart sensor system is designed to prevent overflow, but always monitor the brewing process.
- Unplug the appliance from the outlet when not in use and before cleaning.

2. PRODUCT OVERVIEW

The Tefal CM820826 is a Turkish coffee machine designed for ease of use and perfect results, featuring a 4-cup capacity and smart overflow prevention.



Components:

- Main Unit
- Coffee Pot (designed for easy pouring)
- Measuring Spoon (7g - 8g capacity)
- Touch Control Panel with Light and Sound Alarm

3. SETUP AND FIRST USE

3.1 Unpacking

1. Carefully remove all packaging materials from the appliance.
2. Check for any damage. If damaged, do not use and contact customer support.

3.2 Initial Cleaning

1. Wash the coffee pot and measuring spoon with warm, soapy water. Rinse thoroughly and dry.
2. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.

3.3 Placement

- Place the coffee machine on a stable, flat, heat-resistant surface.
- Ensure adequate ventilation around the appliance.
- Plug the power cord into a suitable electrical outlet.

4. OPERATING INSTRUCTIONS

Follow these steps to brew delicious Turkish coffee:



1. **Add Water:** Fill the coffee pot with cold water. The machine has a 4-cup capacity. Do not exceed the maximum fill line inside the pot.
2. **Add Coffee:** Use the provided measuring spoon to add finely ground Turkish coffee. For a standard brew, use one level spoon (7g) per cup. For a stronger brew or more foam, you may use a slightly heaped spoon (8g) per cup.
3. **Add Sugar (Optional):** Add sugar to taste directly into the pot with the coffee and water. Stir gently.
4. **Place Pot:** Carefully place the coffee pot into the main unit, ensuring it is seated correctly.
5. **Select Brew Function:** The machine offers two brewing functions. Press the appropriate button on the touch panel for your desired brew. One button is typically for a standard brew, and the other may be for a foamy or stronger brew.
6. **Start Brewing:** The machine will begin the brewing process. A light indicator will illuminate, and an audible signal will sound when brewing starts.
7. **Monitor and Serve:** The smart sensor system will detect when the coffee is ready and prevent overflow. A light and sound alarm will indicate completion. Carefully remove the coffee pot and serve immediately into small Turkish coffee cups.

Note: For best results, do not re-brew coffee grounds. Always use fresh water and coffee for each preparation.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your coffee machine.

5.1 Daily Cleaning

1. **Unplug:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Coffee Pot:** Wash the coffee pot and measuring spoon with warm, soapy water after each use. Rinse thoroughly and dry.
3. **Main Unit:** Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or scourers. Never immerse the main unit in water.

5.2 Descaling

Depending on water hardness, descaling may be required periodically (e.g., every 3-6 months) to remove mineral buildup.

- Use a descaling solution suitable for coffee machines, following the manufacturer's instructions.
- Alternatively, a mixture of white vinegar and water (1:2 ratio) can be used.
- Run a descaling cycle, then rinse the pot thoroughly by brewing several cycles with clean water only.

6. TROUBLESHOOTING

If you encounter issues with your coffee machine, refer to the table below before contacting customer service.

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outage; faulty outlet.	Check power cord connection; check circuit breaker; try a different outlet.
Coffee does not brew.	Coffee pot not correctly placed; insufficient water.	Ensure coffee pot is securely seated; add water to the pot.

Problem	Possible Cause	Solution
Coffee overflows.	Too much water/coffee; sensor dirty.	Do not exceed max fill line; clean the sensor area (refer to maintenance).
Coffee is not hot enough.	Machine needs descaling.	Perform a descaling procedure.

7. SPECIFICATIONS

Feature	Detail
Brand	Tefal
Model Number	CM820826
Color	Black
Capacity	4 Cups
Material	Stainless Steel
Special Features	Programmable, Smart Sensor for Overflow Prevention, Light and Sound Alarm
Coffee Maker Type	Turkish Coffee Machine
Specific Uses	Turkish Coffee Preparation
Item Weight	3.16 kg (6.97 pounds)
Shipping Dimensions	30.7 x 24.9 x 21.5 cm
Exterior Finish	Matte

8. WARRANTY AND SUPPORT

8.1 Product Warranty

This Tefal Turkish Coffee Machine CM820826 comes with a minimum two-year warranty from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use conditions.

8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact Tefal customer service. Refer to the product packaging or the official Tefal website for contact details specific to your region.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0853K14WQ>

More documents and user manuals: **<https://manuals.plus/>**