

[Manuals.plus](#) /

> [Midea](#) /

> Midea AC12019ARB Air Purifier Fan User Manual

## Midea AC12019ARB

# Midea AC12019ARB Air Purifier Fan User Manual

Model: AC12019ARB

Brand: Midea

## 1. INTRODUCTION

---

Thank you for choosing the Midea AC12019ARB Air Purifier Fan. This multifunctional appliance is designed to provide a refreshing environment in your home or office by combining the functions of a fan, air purifier, and humidifier. It features a wide-angle oscillation, multiple wind modes, precise humidity control, and a programmable timer for your convenience.

To ensure safe and optimal operation, please read this manual thoroughly before using the appliance and retain it for future reference.

## 2. SAFETY INFORMATION

---

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before using the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors. This appliance is for indoor use only.
- Do not allow the power cord to hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always place the appliance on a firm, flat, level surface.
- Do not block air openings. Ensure proper ventilation.
- Use only as described in this manual.
- Keep out of reach of children.

## 3. PRODUCT OVERVIEW

---

The Midea AC12019ARB is a sleek, tower-design appliance that integrates multiple functions for enhanced air quality and comfort. It features an intuitive LED display and comes with a remote control for convenient operation.





Figure 3.1: Midea AC12019ARB Air Purifier Fan (Main Unit)

### 3.1. Control Panel and LED Display

The top of the unit features an LED display that shows current settings such as humidity level, fan speed, and active mode. Touch-sensitive buttons allow for direct control of the unit's functions.



Figure 3.2: Close-up of the LED Display and Control Panel

## 3.2. Remote Control

A remote control is included for convenient operation from a distance. Ensure batteries are inserted correctly (batteries not included).

## 4. SETUP

---

### 4.1. Unpacking

1. Carefully remove the appliance from its packaging.
2. Remove all packing materials, including any protective films or tapes.
3. Check for any damage during transit. If the unit is damaged, do not use it and contact customer support.

### 4.2. Placement

Place the appliance on a stable, flat, and level surface. Ensure there is adequate space around the unit for proper air circulation (at least 20 cm from walls or furniture).

### 4.3. Filling the Water Tank (Humidifier Function)

The unit features a 7-liter water tank for its humidification function. It has waterless protection and an alarm to indicate low water levels.

1. Locate the water tank at the bottom of the unit.
2. Carefully pull out the water tank.
3. Fill the tank with clean, cool tap water. Do not exceed the maximum fill line.
4. Slide the water tank back into the unit until it clicks into place.
5. Ensure the tank is securely seated to prevent leaks.

## 5. OPERATING INSTRUCTIONS

---

The Midea AC12019ARB offers various modes and settings for customized comfort. All functions can be controlled via the control panel or the remote control.



Figure 5.1: Key Features and Functions

### 5.1. Power On/Off

- Press the **Power** button on the control panel or remote to turn the unit on or off.

## 5.2. Wind Modes

The unit offers three distinct wind modes:

- **Normal Wind:** Provides a steady airflow with 4 adjustable speed levels.
- **Natural Wind:** Simulates a natural breeze by varying fan speed.
- **Tranquil Wind:** Operates at a lower, quieter speed for minimal disturbance.

Press the **Mode** button to cycle through the available wind modes.

## 5.3. Fan Speed

In Normal Wind mode, you can adjust the fan speed:

- Press the **Speed** button to select from 4 levels of airflow intensity.

## 5.4. Oscillation

Activate the oscillation function for wide-angle air distribution (60°):

- Press the **Oscillation** button to start or stop the unit's rotation.

## 5.5. Humidity Control (Humidifier Function)

The unit provides accurate humidity control with high and low speeds (max 800ml/h):

- Press the **Humidity** button to activate or adjust the humidification level.
- The unit will automatically stop humidifying if the water tank is empty (waterless protection).

## 5.6. Timer

Set the unit to automatically turn off after a specified period:

- Press the **Timer** button repeatedly to set the desired operating time, up to 10 hours.

# 6. MAINTENANCE

---

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Midea AC12019ARB.

## 6.1. Cleaning the Exterior

- Always unplug the appliance before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth.
- Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.

## 6.2. Cleaning the Water Tank

To prevent mineral buildup and maintain hygiene, clean the water tank regularly:

1. Unplug the unit and remove the water tank.
2. Empty any remaining water.
3. Clean the inside of the tank with a soft brush or cloth and mild detergent. Rinse thoroughly with clean water.
4. For mineral deposits, use a solution of white vinegar and water. Let it soak for 20-30 minutes, then scrub and rinse.
5. Allow the tank to air dry completely before reinserting it into the unit.

## 6.3. Filter Maintenance

The unit is equipped with a high-density filter for air purification. Refer to the product's specific filter cleaning or replacement instructions, usually found near the filter compartment. Regularly check the filter for dust accumulation and

clean or replace as recommended to maintain air purification efficiency.

## 7. TROUBLESHOOTING

If you encounter issues with your Midea AC12019ARB, please refer to the following common problems and solutions before contacting customer support.

| Problem                        | Possible Cause                                       | Solution                                                                         |
|--------------------------------|------------------------------------------------------|----------------------------------------------------------------------------------|
| Unit does not turn on.         | No power supply; Power cord not properly plugged in. | Check if the power cord is securely plugged into a working outlet.               |
| No air flow or weak air flow.  | Air inlet/outlet blocked; Fan speed set too low.     | Ensure air inlets and outlets are clear. Increase fan speed.                     |
| Humidifier not producing mist. | Water tank empty; Water tank not properly seated.    | Refill the water tank. Ensure the water tank is correctly inserted.              |
| Unusual noise.                 | Unit not on a level surface; Foreign object inside.  | Place the unit on a flat, stable surface. Unplug and check for any obstructions. |

If the problem persists after trying these solutions, please contact Midea customer support.

## 8. SPECIFICATIONS

Technical specifications for the Midea AC12019ARB Air Purifier Fan:

| Feature                    | Specification          |
|----------------------------|------------------------|
| Brand                      | Midea                  |
| Model Name                 | Ventilatore AC12019ARB |
| Color                      | Black, White           |
| Product Dimensions (LxWxH) | 40.3 x 34.9 x 112.6 cm |
| Item Weight                | 13.8 Kilograms         |
| Water Tank Capacity        | 7 Liters               |
| Wattage                    | 65 Watts               |
| Voltage                    | 240 Volts              |
| Special Feature            | High-density filter    |

## 9. WARRANTY AND SUPPORT

Midea products are manufactured to the highest quality standards. For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official Midea website. Keep your proof of purchase for any warranty claims.

For further assistance, please contact Midea customer service.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B08542C9QT>

More documents and user manuals: <https://manuals.plus/>