

COMLIFE HF340

COMLIFE Portable Neck Fan User Manual

Model: HF340

INTRODUCTION

Thank you for choosing the COMLIFE Portable Neck Fan. This hands-free, wearable personal fan is designed to provide powerful and quiet cooling wherever you go. Its flexible design and long-lasting battery make it ideal for various activities, from home and office use to outdoor travel.

Please read this manual carefully before using the product to ensure proper operation and maintenance.

PACKAGE CONTENTS

- (1) COMLIFE Portable Neck Fan
- (1) USB Charging Cable
- (1) User Manual



Image: The COMLIFE Portable Neck Fan in black, showcasing its flexible neckband and dual fan heads.

SETUP

1. Charging the Fan

Before first use, fully charge the fan. The built-in 2600mAh rechargeable battery supports 1.5-5.5 hours of working time depending on the speed level.

- Connect the provided USB charging cable to the charging port on the fan (located on the main neckband section).
- Connect the other end of the USB cable to a compatible USB power source (e.g., laptop, wall charger, power bank).
- The indicator lights will show the charging status. Once fully charged, the lights will indicate a full battery.

EASY TO CHARGE



Image: Illustration showing various charging methods for the COMLIFE Neck Fan, including laptop, car charger, wall charger, and power bank.

2. Wearing the Fan

The COMLIFE Neck Fan is designed for hands-free use. Simply place the neckband around your neck. The flexible arms allow for 360-degree adjustment of the fan heads to direct airflow precisely where you need it.

360° Degree High Flexibility



Image: A hand demonstrating the 360-degree flexibility of the fan head, allowing for free adjustment to achieve optimal cooling.

OPERATING INSTRUCTIONS

Power On/Off and Speed Adjustment

The fan features a single button for control:

- **Long Press:** Press and hold the button to turn the fan ON or OFF.
- **Short Press:** Once the fan is on, short press the button to cycle through the 3 available wind speed modes.

The fan offers three speed options to suit your cooling needs, with a maximum speed of 5.1 m/s.

Size



Image: Diagram illustrating the fan's dimensions, the location of the ON/OFF and speed adjustment button, indicator lights, and charging port.

Usage Scenarios

The COMLIFE Portable Neck Fan is versatile and can be used in various situations:

- **Wearable:** Ideal for outdoor activities like hiking, camping, attending concerts, or simply walking.
- **Desk Fan:** Can be placed on a table or desk for personal cooling in an office or home environment.
- **Travel:** Lightweight and portable, easily carried in a suitcase or backpack.



Image: A collage showing the COMLIFE Neck Fan being used in various settings, including outdoors at the beach, during woodworking, and in an office environment.

MAINTENANCE

Cleaning

To maintain optimal performance, periodically clean the fan blades and grilles. Use a soft, dry cloth to wipe away dust. Do not use liquid cleaners or immerse the fan in water.

Storage

When not in use, store the fan in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the fan is fully charged before long-term storage to preserve battery life.

Important Precaution for Long Hair Users

For individuals with long hair, it is recommended to tie your hair up to prevent it from being stirred into the fan blades during operation. The fan is designed to minimize this risk, but taking this precaution ensures safe and uninterrupted use.



Image: A person wearing the neck fan, with text indicating that hair would not easily be caught by the fan due to its blade design, but advising to tie up long hair as a precaution.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on or charge.	Low battery; improper charging connection; product defect.	Ensure the fan is fully charged using the provided USB cable and a working power source. Check the charging port for debris. If the issue persists, contact customer support.
Weak airflow.	Low battery; fan speed set too low; obstructed fan blades.	Charge the fan. Increase the fan speed by short pressing the button. Ensure nothing is blocking the fan grilles or blades.
Unusual noise during operation.	Obstruction in fan blades; internal issue.	Turn off the fan and check for any foreign objects caught in the blades. If no obstruction is found and the noise persists, discontinue use and contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	COMLIFE
Model Name	HF340
Color	Black
Power Source	Battery Powered
Battery Capacity	2600mAh (Lithium Polymer)
Working Time	1.5-5.5 hours (depending on speed)
Number of Power Levels	3
Max Wind Speed	5.1m/s
Noise Level	2E+1 dB (approx. 20 dB)
Product Dimensions	9.6"D x 63.6"W x 97.2"H
Item Weight	6.9 ounces (0.43 Pounds)
Control Method	Push Button / Touch
Blade Material	Plastic
Voltage	5 Volts
Wattage	2 watts
Certification	UL

WARRANTY AND SUPPORT

COMLIFE products are manufactured to high-quality standards. For any questions, concerns, or issues regarding your COMLIFE Portable Neck Fan, please contact COMLIFE USA customer support. Please retain your proof of purchase for warranty claims.

For further assistance, please visit the official COMLIFE website or contact their customer service directly.