Sunnyglade CP

Sunnyglade 10x13Ft Cantilever Patio Umbrella Instruction Manual

Model: CP

1. Introduction

Thank you for choosing the Sunnyglade 10x13Ft Cantilever Patio Umbrella. This manual provides essential information for the safe assembly, operation, and maintenance of your new patio umbrella. Please read these instructions carefully before use and retain them for future reference.

This cantilever umbrella is designed to provide ample shade for your outdoor living space, featuring a durable aluminum frame and a weather-resistant polyester canopy. Its adjustable tilt and 360-degree rotation capabilities allow for optimal shade positioning throughout the day.

2. Safety Information

- Always ensure the umbrella base is adequately weighted. This umbrella cannot stand alone and requires a heavy base (not included) to prevent tipping.
- Close the umbrella canopy during windy conditions, heavy rain, or when not in use to prevent damage to the umbrella and potential injury.
- Do not attempt to use the umbrella in extreme weather conditions.
- Keep children and pets away from the umbrella during opening, closing, and adjustment operations.
- Ensure all parts are securely fastened before and during use. Regularly check for loose connections.
- Avoid placing the umbrella near open flames or heat sources.

3. Parts List

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.



This image displays the various components of the cantilever patio umbrella, including the canopy, main pole, crank mechanism, and cross base, illustrating how they fit together during assembly.

- Umbrella Canopy (250/gsm polyester fabric with PA coating)
- Main Pole (Heavy aluminum)
- 8 Aluminum Ribs
- Crank Handle
- Cross Base (Welded metal, powder coated)
- Foot Pedal (for rotation)
- Assembly Hardware (bolts, washers, tools)

4. Setup Instructions

Assembly of this patio umbrella is designed to be straightforward. All necessary tools are included. It is recommended to have two people for certain steps due to the size and weight of the components.

4.1. Base Preparation


1. Place the cross base on a flat, stable surface where you intend to position the umbrella.
2. **Important:** The umbrella base is NOT INCLUDED and this outdoor umbrella cannot stand alone. You must secure the cross base with appropriate weights (e.g., sandbags, pavers, or a dedicated umbrella base filled with water/sand). Ensure the base is sufficiently heavy to prevent the umbrella from tipping over, especially when open.

4.2. Main Pole Assembly

1. Attach the main pole to the secured cross base using the provided hardware. Ensure all bolts are tightened firmly.
2. Verify the pole is vertical and stable before proceeding.

4.3. Canopy Attachment

1. Carefully attach the umbrella canopy assembly to the main pole. This step may require two people due to the size and weight of the canopy.
2. Secure the canopy to the pole using the designated locking mechanisms or bolts.
3. The four corners of the canopy are designed with long zippers for easy installation and to help secure the canopy in place.



This image illustrates the assembled umbrella, highlighting key features such as the innovative zipper design on the canopy, the sturdy construction, and the mechanism for adjusting the sunshade direction and angle.

5. Operating Instructions

Your Sunnyglade Cantilever Patio Umbrella offers several features for convenient shade adjustment.

5.1. Opening and Closing the Canopy

1. To open the canopy, rotate the crank handle clockwise until the canopy is fully extended.

2. To close the canopy, rotate the crank handle counter-clockwise until the canopy is fully retracted.

5.2. 360-Degree Rotation


1. To rotate the umbrella, step on the foot pedal located at the base of the main pole.
2. While holding the pedal down, gently twist the main pole to rotate the umbrella to your desired position.
3. Release the foot pedal to lock the umbrella in place.



This image demonstrates the 360-degree rotation capability of the umbrella, allowing users to easily adjust the shade direction by stepping on the foot pedal and rotating the main pole.

5.3. 4-Level Tilt Adjustment

1. The umbrella features a 4-level adjustable tilt operation system.
2. Locate the tilt adjustment handle on the main pole.
3. Adjust the handle to change the angle of the canopy, providing maximum shade from the sun at different times of the day.



This image illustrates the four adjustable height levels of the umbrella, allowing the user to modify the canopy's height to resist sunlight from various angles.

5.4. Official Product Video: Operation Overview

Your browser does not support the video tag.

This video provides a visual overview of the Sunnyglade Cantilever Offset Patio Umbrella, demonstrating its key operational features such as opening, closing, rotation, and tilt adjustments.

6. Maintenance

Proper maintenance will extend the life and appearance of your Sunnyglade patio umbrella.

- **Cleaning:** Wipe the canopy and frame with a damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly.
- **Drying:** Ensure the canopy is completely dry before closing and storing to prevent mildew and fabric degradation.

- **Storage:** When not in use for extended periods, or during off-season, store the umbrella in a dry, protected area. Using an umbrella cover is recommended.
- **Wind Protection:** Always close the canopy when windy conditions are expected or present.
- **Fabric Care:** The canopy is made of 250/gsm polyester fabric with PA coating, offering fade resistance, UV protection, and waterproofing. While durable, prolonged exposure to harsh elements can affect its lifespan.

7. Troubleshooting


If you encounter issues with your umbrella, refer to the following common solutions:

Problem	Possible Cause	Solution
Umbrella tips over easily	Insufficient base weight	Ensure the cross base is adequately weighted with heavy pavers, sandbags, or a filled water/sand base. Refer to base manufacturer recommendations for minimum weight.
Crank mechanism is stiff or not working	Mechanism dirty or damaged; fabric obstruction	Clean the crank mechanism. Check for any fabric caught in the gears. Do not force the crank. If damaged, contact customer support.
Canopy does not open/close smoothly	Ribs or fabric obstructed; mechanism issue	Inspect the ribs and canopy fabric for any obstructions. Ensure the crank mechanism is operating freely.
Umbrella does not rotate	Foot pedal not fully depressed; mechanism jammed	Ensure the foot pedal is fully depressed when attempting to rotate. Check for debris around the rotation mechanism at the base.
Canopy fabric appears faded or damaged	Prolonged sun exposure; improper storage	While the fabric is UV-resistant, extreme conditions can cause wear. Ensure proper storage and use an umbrella cover when not in use.

8. Specifications

Detailed specifications for your Sunnyglade Cantilever Patio Umbrella:

- **Brand:** Sunnyglade
- **Model Number:** CP
- **UPC:** 747356582445
- **Size:** 10 x 13 ft (Rectangular)
- **Canopy Material:** 250/gsm polyester fabric with PA coating
- **Frame Material:** Aluminum (Main Pole, Ribs, Handle)
- **Special Features:** Fade Resistant, UV Resistant, Waterproof, 360° Rotation, 4-Level Tilt
- **Opening Mechanism:** Manual Crank
- **Indoor/Outdoor Usage:** Outdoor
- **Product Care:** Wipe with damp cloth, ensure dry before storing
- **Included Components:** Foldable Stand, User Manual



This image provides a visual representation of the umbrella's dimensions, including the 10ft width, 13ft length, and 8.8ft height, along with the base measurements.

9. Warranty and Support

For warranty information or customer support regarding your Sunnyglade Cantilever Patio Umbrella, please contact the manufacturer directly. Refer to your purchase documentation or the Sunnyglade official website for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question