

[Manuals.plus](#) /

› [Sunnyglade](#) /

› Sunnyglade 10x13ft Cantilever Patio Umbrella Instruction Manual

Sunnyglade CP

Sunnyglade 10x13ft Cantilever Patio Umbrella Instruction Manual

Model: CP

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions and safety warnings before assembling, operating, or maintaining this product. Failure to follow these instructions may result in injury or property damage.

- **Umbrella Base Not Included:** This umbrella requires a weighted base (not included) to prevent tipping. Ensure the base is adequately filled with sand or water for stability.
- **Wind Conditions:** Always close the umbrella canopy during windy conditions or when not in use to prevent damage or injury.
- **Assembly:** Assembly may require two people due to the size and weight of components.
- **Clearance:** Ensure sufficient clearance around the umbrella for full rotation and tilting without obstruction.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly.

- Umbrella Canopy (1)
- Main Aluminum Pole (1)
- Cantilever Arm (1)
- Cross Base (1)
- Crank Handle Assembly (1)
- Hardware Pack (bolts, washers, nuts) (1)
- User Manual (1)

SETUP AND ASSEMBLY

Follow these steps for proper assembly. Two people are recommended for certain steps.

1. **Prepare the Base:** Place the cross base in the desired location. This umbrella requires a separate weighted base (e.g., sand/water filled weights) to be placed on the cross base for stability. Ensure the base is stable and level.
2. **Attach Main Pole:** Secure the main aluminum pole to the cross base using the provided hardware. Ensure all bolts are tightened securely.

3. **Install Cantilever Arm:** Attach the cantilever arm to the main pole. This step may require assistance to align and secure properly.
4. **Mount Umbrella Canopy:** Carefully lift and attach the umbrella canopy to the cantilever arm. The canopy features an innovative zipper design at the four corners for easy installation.
5. **Crank Handle Assembly:** Ensure the crank handle is securely attached and functions smoothly for opening and closing the canopy.



Figure 1: Key features and components of the Sunnyglade Cantilever Patio Umbrella.

OPERATING INSTRUCTIONS


This umbrella offers versatile adjustments for optimal shade.

1. **Opening the Canopy:** Use the crank handle to smoothly open the umbrella canopy. Continue cranking until the canopy is fully extended and taut.
2. **Closing the Canopy:** Turn the crank handle in the opposite direction to retract the canopy. Once fully closed, secure it with the integrated strap to prevent it from unfurling in the wind.
3. **360° Rotation:** To rotate the umbrella, step on the foot pedal located at the base of the main pole. While holding the pedal down,

gently twist the main pole to rotate the umbrella to the desired position. Release the pedal to lock it in place.

4. **Adjustable Tilt:** The umbrella features a 4-level adjustable tilt system. Use the handle on the cantilever arm to adjust the angle of the canopy, allowing you to block the sun at different times of the day.

• The height of the umbrella can be adjusted freely to resist sunlight from different angles



4 Adjustable Heights

Figure 2: The umbrella offers 4 adjustable height levels for varied shade coverage.




Figure 3: The base allows for 360-degree rotation of the umbrella.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the features and operation of the Sunnyglade Cantilever Offset Patio Umbrella.

MAINTENANCE AND CARE

Proper maintenance will extend the life of your umbrella.

- **Cleaning the Canopy:** Clean the polyester canopy with mild soap and water. Rinse thoroughly and allow to air dry completely before closing or storing. Do not use harsh chemicals or abrasive cleaners.
- **Frame Care:** The aluminum frame is powder-coated for rust and corrosion resistance. Wipe down with a damp cloth as needed.
- **Storage:** When not in use for extended periods, or during severe weather, close the umbrella and cover it with a protective cover (sold separately). Store in a dry, sheltered area during off-season.
- **Inspection:** Periodically check all bolts and connections to ensure they are tight.



Figure 4: The canopy features a multifunctional vent design for improved airflow.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Umbrella tips over easily.	Insufficiently weighted base.	Ensure the cross base is adequately weighted with sand or water-filled base weights (sold separately). This umbrella cannot stand alone without proper weighting.
Crank mechanism is stiff or not working.	Dirt/debris in mechanism, lack of lubrication, or damaged parts.	Clean the crank mechanism. Apply a silicone-based lubricant if needed. If damaged, contact customer support for replacement parts.
Canopy does not open or close smoothly.	Obstruction, tangled fabric, or mechanism issue.	Check for any obstructions or tangled fabric. Ensure the crank mechanism is operating correctly.
Umbrella sways excessively in light wind.	Base not heavy enough or loose connections.	Increase the weight on the base. Check and tighten all assembly bolts. Always close the umbrella in windy conditions.

SPECIFICATIONS

Model: CP

Brand: Sunnyglade

Canopy Size: 10 x 13 ft (Rectangular)

Canopy Material: 250/gsm Polyester with PA Coating

Frame Material: Aluminum (Pole, Shaft, Ribs)

Ribs: 8 Aluminum Ribs

Color: Red

Special Features: UV Resistant, Waterproof, Fade Resistant, 360° Rotation, 4-Level Tilt System, Innovative Zipper Design

Opening Mechanism: Manual Crank Lift

Usage: Outdoor (Patio, Garden, Deck, Poolside)

Dimensions (W x H): 120"W x 112.56"H (approx. 10 ft W x 9.38 ft H)



Figure 5: Approximate dimensions of the Sunnyglade 10x13ft Cantilever Patio Umbrella.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Sunnyglade customer service. Refer to your purchase documentation for specific warranty terms and contact details.

Manufacturer: Sunnyglade

UPC: 747356582438

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question