

[Manuals.plus](#) /

› [OPPO](#) /

› OPPO OBMC02 Wireless Bluetooth Outdoor Speaker User Manual

## OPPO OBMC02

# OPPO OBMC02 Wireless Bluetooth Outdoor Speaker User Manual

Model: OBMC02

## INTRODUCTION

Thank you for choosing the OPPO OBMC02 Wireless Bluetooth Outdoor Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product and retain it for future reference.

## IMPORTANT SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- While the speaker is waterproof, do not submerge it in water for extended periods. Ensure the charging port cover is securely closed before exposure to water.
- Use only the provided charging cable or a certified equivalent.
- Do not attempt to disassemble, repair, or modify the speaker. This will void the warranty and may cause damage or injury.
- Keep the speaker away from medical devices and strong magnetic fields.
- Clean the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.

## PACKAGE CONTENTS

---

Please check the box for the following items:

- OPPO Wireless Speaker
- Charging cable
- User Manual

## PRODUCT OVERVIEW

---

The OPPO OBMC02 is a compact and portable Bluetooth speaker designed for outdoor use, featuring robust sound and a durable, waterproof design.



Top view showing the speaker grille and subtle OPPO branding. This perspective highlights the speaker's square form factor

and the texture of the speaker mesh.



Angled view highlighting the control buttons on the top panel and the speaker's compact design. This view provides a better understanding of the speaker's depth and the placement of its physical controls.

## Controls and Indicators

- **Power Button:** Press and hold to turn the speaker on or off.
- **Volume Up (+):** Press to increase volume.
- **Volume Down (-):** Press to decrease volume.
- **Play/Pause Button:** Press to play or pause music. Also used for call management.
- **Bluetooth Pairing Button:** Press and hold to enter pairing mode.
- **LED Indicator:** Shows power status, charging status, and Bluetooth connection status.

## INITIAL SETUP

## Charging the Speaker

1. Locate the charging port on the speaker.
2. Connect the provided charging cable to the speaker's charging port.
3. Connect the other end of the charging cable to a USB power adapter (not included) or a computer's USB port.
4. The LED indicator will illuminate to show charging status. A full charge takes approximately 2-3 hours.
5. Once fully charged, disconnect the charging cable and ensure the port cover is securely closed.

## Pairing with a Bluetooth Device

1. Ensure the speaker is charged and turned off.
2. Press and hold the Power button to turn on the speaker. The LED indicator will flash, indicating it is in pairing mode.
3. On your Bluetooth-enabled device (smartphone, tablet, etc.), go to the Bluetooth settings.
4. Search for available devices. You should see "OPPO OBMC02" in the list.
5. Select "OPPO OBMC02" to connect.
6. Once successfully paired, the LED indicator will stop flashing and remain solid. You will hear an audible confirmation.

## OPERATING INSTRUCTIONS

### Power On/Off

- **To Power On:** Press and hold the Power button for 2-3 seconds.
- **To Power Off:** Press and hold the Power button for 2-3 seconds.

### Music Playback

- **Play/Pause:** Press the Play/Pause button once.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.

### Call Management

- **Answer Call:** Press the Play/Pause button once.
- **End Call:** Press the Play/Pause button once during a call.
- **Reject Call:** Press and hold the Play/Pause button for 2 seconds.

### Bluetooth Reconnection

The speaker will automatically attempt to reconnect to the last paired device when powered on. If reconnection fails, ensure Bluetooth is enabled on your device and the speaker is within range.

## CARE AND MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** To preserve battery life, fully charge the speaker before first use and at least once every three months if not used regularly. Avoid fully discharging the battery frequently.
- **Water Resistance:** Always ensure the charging port cover is firmly sealed to maintain the speaker's waterproof capabilities.

## TROUBLESHOOTING

| Problem                            | Solution                                                                                                                                                                           |
|------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Speaker does not turn on.          | Ensure the speaker is fully charged. Connect it to a power source and try again.                                                                                                   |
| Cannot pair with Bluetooth device. | Ensure the speaker is in pairing mode (LED flashing). Turn off and on Bluetooth on your device. Move closer to the speaker. Forget previous pairings on your device and try again. |
| No sound or low volume.            | Increase volume on both the speaker and your connected device. Ensure the speaker is properly paired.                                                                              |
| Sound distortion.                  | Reduce the volume on your device or the speaker. Move the speaker closer to your device to avoid interference.                                                                     |
| Speaker not charging.              | Check the charging cable and adapter for damage. Ensure the cable is securely connected to both the speaker and the power source. Try a different charging cable or adapter.       |

## TECHNICAL SPECIFICATIONS

| Feature                    | Specification           |
|----------------------------|-------------------------|
| Model Name                 | OPPO Wireless Speaker   |
| Model Number               | OBMC02                  |
| Speaker Type               | Outdoor                 |
| Connectivity Technology    | Bluetooth 5.0, Wireless |
| Battery Life               | Up to 8 Hours           |
| Battery Capacity           | 750 mAh Lithium-Ion     |
| Control Method             | Touch                   |
| Water Resistance Level     | Waterproof              |
| Item Weight                | 160 Grams               |
| Product Dimensions (LxWxH) | 10 x 6.8 x 8.5 cm       |
| Compatible Devices         | Smartphone, Tablet      |

## WARRANTY AND CUSTOMER SUPPORT

Your OPPO OBMC02 Wireless Bluetooth Outdoor Speaker comes with a **1-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

For technical support, warranty claims, or any inquiries regarding your product, please contact OPPO customer service through their official website or authorized service centers. Refer to the OPPO official website for the most up-to-date contact information and support resources.