BABY born 827987

BABY born Weather Wardrobe Instruction Manual

Brand: **BABY born** | Model: **827987**

Introduction

The BABY born Weather Wardrobe is a delightful accessory designed for 43 cm dolls, enhancing creative play and fostering empathy. This interactive wardrobe features a unique weather station, ample storage for doll clothes, a removable mirror, and a secret compartment, providing endless imaginative possibilities for children aged 3 years and up.

This manual provides essential information on the product's features, assembly, operation, and maintenance to ensure a safe and enjoyable play experience.

Safety Information

WARNING:

- Not suitable for children under 36 months due to small parts. Choking hazard.
- Adult supervision is recommended during play.
- Do not mix different types of batteries or new and used batteries.
- Ensure batteries are inserted with correct polarity.

Package Contents

Please ensure all the following components are present in the package:

- BABY born Weather Wardrobe unit
- Removable mirror
- Secret duck-shaped key
- Sticker sheet for decoration



Image: The complete BABY born Weather Wardrobe set, including the wardrobe, its packaging, and the sticker sheet.

Setup and Assembly

The BABY born Weather Wardrobe requires minimal assembly. Follow these steps to set up your wardrobe:

1. Carefully remove all components from the packaging.
2. Ensure the wardrobe unit is placed on a stable, flat surface.
3. **Battery Installation:** The weather station requires 3 x AAA batteries (not included). Locate the battery compartment on the top of the wardrobe, typically under a screw-secured cover. Use a small Phillips head screwdriver to open the compartment, insert the batteries according to the polarity markings (+/-), and secure the cover.
4. Attach the removable mirror to the side of the wardrobe as indicated.



Image: The fully assembled BABY born Weather Wardrobe, ready for play.

Operating Instructions

Weather Station Function

The integrated weather station helps BABY born decide what to wear. To operate:

- Press the pink button located on the roof of the wardrobe.
- The duck inside the weather station will rotate, and a melody will play.
- The duck will stop at one of the four seasons (winter, spring, summer, autumn), indicating the suggested weather.
- A thermometer next to the duck displays the temperature for each season.



Image: A detailed view of the weather station on the wardrobe's roof, showing the rotating duck and thermometer.

Storage Features

The wardrobe offers various storage options for BABY born's outfits and accessories:

- **Main Compartment:** Open the double doors to reveal a spacious area for hanging doll clothes.
- **Drawers:** Two pull-out drawers are available for smaller items like shoes or accessories.



Image: The wardrobe with its doors open, showcasing the hanging space and drawers for doll clothes and accessories.

Removable Mirror and Secret Compartment

The wardrobe includes a functional mirror and a hidden storage area:

- The mirror on the side of the wardrobe can be pulled out for BABY born to check her outfit.
- Behind the mirror, there is a secret compartment. This compartment can only be opened using the special duck-shaped key.



Image: The wardrobe with its side mirror extended, revealing the secret compartment behind it.

Decoration

Personalize your BABY born Weather Wardrobe using the included sticker sheet. Apply the stickers to the wardrobe's surfaces to add a unique touch.



Image: The wardrobe adorned with colorful stickers from the included sheet, showcasing customization options.

Maintenance

- **Cleaning:** Wipe the wardrobe surfaces with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- **Battery Care:** Remove batteries if the product is not going to be used for an extended period. Dispose of used batteries responsibly according to local regulations.
- **Storage:** Store the wardrobe in a cool, dry place away from direct sunlight when not in use.

Troubleshooting

Problem	Possible Cause	Solution
Weather station not working / no sound.	Batteries are dead, incorrectly inserted, or missing.	Check battery polarity, replace with fresh AAA batteries.
Stickers do not adhere well.	Surface may be dusty or textured.	Ensure the surface is clean and dry before applying. Some surfaces may have a texture that affects adhesion.
Mirror is difficult to pull out.	Minor friction or misalignment.	Gently pull the mirror straight out. Avoid forcing it.

Specifications

- **Product Dimensions (L x W x H):** 35 x 20.5 x 52 cm (13.8 x 8.1 x 20.5 inches)
- **Weight:** 2.88 kg (6.35 lbs)
- **Recommended Age:** 36 months - 8 years
- **Educational Value:** Understanding weather conditions and appropriate clothing choices
- **Language:** English
- **Manufacturer Reference:** 827987
- **Batteries:** Requires 3 x AAA batteries (not included)
- **Main Material:** Plastic
- **Color:** Pink

Warranty and Support

BABY born products are manufactured to high-quality standards. For any questions, concerns, or support needs regarding your Weather Wardrobe, please contact the manufacturer's customer service. Please retain your proof of purchase for warranty claims.

Contact information can typically be found on the product packaging or the official BABY born website.