Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Baby Born 828366

BABY born 828366 Bath Bathtub Instruction Manual

Model: 828366
Brand: Baby Born

Introduction

This manual provides instructions for the safe and proper use of your BABY born 828366 Bath Bathtub. Please read all instructions carefully before assembly and use.
The BABY born Bath Bathtub offers interactive bath time fun for your doll, featuring light and sound effects, and a functional shower head.

Safety Information

- Keep away from naked flame.
- Adult supervision is recommended during play.
- Ensure all battery compartments are securely closed.
- Do not immerse the entire unit in water beyond the bathtub basin.

Package Contents

Verify that all items are present:

- BABY born Bath Bathtub
- Rubber Ducky

Setup

Battery Installation

The BABY born Bath Bathtub requires 4 x AA batteries (not included) for light and sound effects and the functional shower.

1. Locate the battery compartment on the underside of the bathtub.

2. Using a screwdriver, open the battery compartment cover.
3. Insert 4 new AA batteries, ensuring correct polarity (+/-).
4. Securely close the battery compartment cover with the screwdriver.

Note: *Always use new batteries of the same type. Do not mix old and new batteries or different types of batteries.*

Initial Assembly

The bathtub comes largely pre-assembled. Ensure the shower head is securely attached to the heart-shaped support.



Image: The BABY born Bath Bathtub with its pink basin, white base, and yellow duck feet. A small rubber ducky toy is placed next to it. The shower head is attached to a pink heart-shaped support at one end of the tub.

Operating Instructions

Filling the Bathtub

Fill the bathtub with clean water up to a suitable level for your BABY born doll. Do not overfill.

Activating Lights and Sounds

Press the button located on the side of the bathtub. This will activate the four duck lights and play a cheerful duck melody.



Image: A BABY born doll sitting in the pink bathtub, which is filled with bubbles. The duck-shaped lights on the side of the tub are

illuminated, and the shower head is positioned above the doll.

Using the Shower Head

The shower head provides real water flow. To operate, ensure the bathtub is filled with water and the pump mechanism is submerged. Press the button on the shower head to activate the water flow.
The hose can be pulled out slightly to position the shower head over the doll for a shower.



Image: A BABY born doll, dressed in a pink robe, standing next to the pink bathtub. The shower head is extended and positioned as if ready for use. A small rubber ducky is on the floor.

Playing with the Rubber Ducky

The included rubber ducky is a fun accessory for water play within the bathtub.



Image: A close-up view of the small yellow rubber ducky toy, sitting on a blue and pink base, designed for floating in water.

Maintenance

Cleaning

After each use, empty the bathtub and rinse it with clean water. Wipe down all surfaces with a soft, damp cloth. Do not use abrasive cleaners.
Ensure the shower head and hose are free of any blockages.

Draining Water

To drain water, simply tip the bathtub over a sink or drain. Ensure all water is removed to prevent mold or mildew.

Battery Care

Remove batteries if the product will not be used for an extended period.
Dispose of used batteries responsibly according to local regulations.

Troubleshooting

Lights and Sound Not Working

- Check if batteries are correctly installed with the correct polarity.
- Replace with new AA batteries.
- Ensure the battery compartment cover is securely closed.

Shower Head Not Pumping Water

- Ensure the bathtub contains sufficient water for the pump to operate.
- Check if the pump intake (located at the bottom of the shower unit) is submerged and not blocked.
- Verify batteries are fresh and correctly installed.
- Ensure the button on the shower head is fully pressed.

Specifications

Feature	Detail
Model Number	828366
Product Dimensions	10.08 x 15.83 x 10.55 inches
Item Weight	3.32 pounds
Batteries Required	4 x AA (not included)
Recommended Age	12 months - 3 years
Manufacturer	BABY born
Release Date	August 28, 2021

Warranty and Support

For warranty information or customer support, please refer to the manufacturer's official website or contact your retailer. Specific warranty details are not included in this manual.

© 2023 Baby Born. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B085555HJ6

More documents and user manuals: **https://manuals.plus/**