

[Manuals.plus](#) /

› [Ninja](#) /

› Ninja BN701 Professional Plus Blender User Manual

Ninja BN701

Ninja BN701 Professional Plus Blender User Manual

Model: BN701 | Brand: Ninja

INTRODUCTION

The Ninja Professional Plus Blender with Auto-iQ features a modern design and a powerful 1400 peak watt motor. It is engineered to provide perfectly crushed ice for smoothies, frozen drinks, and ice cream. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your Ninja BN701 Professional Plus Blender.

NINJA PROFESSIONAL PLUS BLENDER WITH AUTO-IQ BN701

NINJA®

PROFESSIONAL PLUS

BLENDER

- ✓ 1400 Peak-Watt Motor
- ✓ 72 oz.* Total Crushing® Pitcher
- ✓ 3 Auto-iQ® Programs
4 Manual Speeds
- ✓ 30 Inspiration Recipe
Guide Included



Overview of the Ninja Professional Plus Blender BN701, highlighting its 1400-Peak-Watt Motor, 72 oz. Total Crushing Pitcher, 3 Auto-iQ Programs, 4 Manual Speeds, and included 30 Inspiration Recipe Guide.



Included 30-recipe book to inspire you.

The blender comes with a 30-recipe book to inspire various culinary creations.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- To protect against electrical shock, do not immerse the motor base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.

- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always operate the blender with the lid in place.
- Blades are sharp. Handle with care.
- Do not blend hot liquids.

GETTING STARTED: WHAT'S INCLUDED

Your Ninja Professional Plus Blender BN701 package includes the following components:

- 1400-Peak-Watt Motor Base
- 72-oz. Total Crushing Pitcher (64 oz. max liquid capacity)
- Stacked Blade Assembly
- Pitcher Lid with spout
- Recipe Inspiration Guide
- Instruction Booklet & Quick Start Guide

Get to know this Ninja[®] Professional Plus Blender



An exploded view illustrating the main components: Motor base, 72 oz. Pitcher, Total Crushing Blade, and Pitcher Lid.

Ninja® Professional Plus Blender includes:



Stacked Blade (for use with Pitcher)

Blend fruits and dairy for delicious sippable smoothies, and crush ice to snow for resort-style frozen drinks.

The Stacked Blade Assembly, designed for efficient blending and crushing.

SETUP

Before first use, wash all parts that will come into contact with food in warm, soapy water. Rinse and dry thoroughly. The pitcher and blade assembly are dishwasher safe (top rack only).

1. Place the motor base on a clean, dry, level surface. Ensure the suction cups on the bottom of the base adhere to the counter for stability.
2. Carefully place the Total Crushing Pitcher onto the motor base, aligning the pitcher's handle with the right side of the motor base. Rotate the pitcher clockwise until it clicks into place.
3. Hold the Stacked Blade Assembly by the top of the shaft and carefully place it onto the drive gear inside the pitcher. Ensure it is seated properly.
4. Add your ingredients to the pitcher. Do not exceed the MAX FILL line for liquids or the MAX LIQUID CAPACITY line for solid ingredients.
5. Place the lid on the pitcher, aligning the arrow on the lid with the arrow on the pitcher handle. Press down firmly until the lid clicks into place. The blender will not operate unless the lid is securely locked.

6. Plug the power cord into an electrical outlet.

OPERATING INSTRUCTIONS

The Ninja BN701 features Auto-iQ Technology with preset programs and manual speed controls for versatile blending.

Intelligent preset programs at the push of a button:



The control panel features Auto-iQ programs and manual speed settings.

Auto-iQ Programs

Auto-iQ programs combine unique timed pulsing, blending, and pausing patterns that do the work for you. Simply select the desired program and let the blender do the rest.

- **SMOOTHIE:** Ideal for blending fresh or frozen fruits and liquids into smooth, drinkable consistency.
- **ICE CRUSH:** Specifically designed to crush ice into snow in seconds for frozen drinks and desserts.
- **ICE CREAM:** Creates creamy frozen treats from frozen fruits and dairy.



BLEND FROZEN DRINKS

Use the 72 oz.* Total Crushing® Pitcher for large batches of delicious smoothies.

*64 oz. max liquid capacity

The 72 oz. Total Crushing Pitcher is suitable for making large batches of delicious smoothies and frozen drinks.



Smoothies, frozen drinks, and treats

With Auto-iQ®, you can make fruit smoothies, resort-style frozen drinks, and ice cream at the touch of a button.

With Auto-iQ, you can easily prepare fruit smoothies, frozen drinks, and ice cream.



TOTAL CRUSHING[®]

Turns ice to snow

The Total Crushing feature effectively turns ice into snow for various recipes.

Manual Speeds

For manual control, select from the following speeds:

- **LOW:** For light mixing and thin batters.
- **MED:** For thicker mixtures and general blending.
- **HIGH:** For maximum speed and tough ingredients.
- **PULSE:** For controlled chopping and processing. Press and hold for short bursts.

To stop blending, press the currently active program button or the power button.

CARE & MAINTENANCE

Proper care and maintenance will ensure the longevity of your Ninja blender.

Cleaning

- **Dishwasher Safe:** The BPA-free pitcher and stacked blade assembly are easy to clean and dishwasher safe on the top rack.
- **Hand-Washing:** Wash the pitcher, lid, and blade assembly in warm, soapy water. Use a dishwashing utensil with a handle to avoid direct contact with the blades. Rinse thoroughly and air dry.
- **Motor Base:** Wipe the motor base with a clean, damp cloth. Do not immerse the motor base in water or any other liquid.



EASY TO CLEAN

All attachments are BPA free
and Dishwasher safe.

All attachments are BPA-free and dishwasher safe for easy cleaning.

Storage

Store the blender upright with the pitcher assembled on the motor base, or store components separately in a safe place where they won't be damaged.

TROUBLESHOOTING

If you encounter issues with your blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Power cord not plugged in; Pitcher or lid not properly assembled.	Ensure power cord is securely plugged into outlet. Verify pitcher is rotated clockwise until it clicks and lid is pressed down until it clicks.
Ingredients are not blending smoothly.	Too many ingredients; Not enough liquid; Ingredients are too large.	Reduce ingredient quantity. Add more liquid. Cut large ingredients into smaller pieces. Use the PULSE function for tough ingredients.
Motor stops during operation.	Overheating due to overload.	Unplug the unit and allow it to cool for at least 15 minutes. Remove some ingredients if overloaded.
Loud noise or burning smell.	Motor strain or foreign object.	Unplug immediately. Check for any foreign objects. If smell persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Ninja
Model Number	BN701
Power	1400 Peak Watts
Capacity	72 Fluid Ounces (64 oz. max liquid capacity)
Product Dimensions	6.75"D x 9"W x 17.5"H
Number of Speeds	4 (Low, Med, High, Pulse) + 3 Auto-iQ Programs
Blade Material	Stainless Steel
Material Type Free	BPA Free
Voltage	120 Volts
Item Weight	8.1 pounds
Country of Origin	China

WARRANTY & SUPPORT

Your Ninja BN701 Professional Plus Blender comes with a limited warranty. For specific details regarding the warranty period and coverage, please refer to the warranty information provided in the original packaging or contact Ninja customer support. For further assistance, product registration, or to download a digital copy of this manual, please visit the official Ninja website or refer to the contact information provided in your Quick Start Guide. A PDF version of the user manual is also available online:[Download User Manual \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question