

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Chicco](#) /
- › [Chicco GoFit Plus Backless Booster Car Seat Instruction Manual](#)

## Chicco GoFit Plus

# Chicco GoFit Plus Backless Booster Car Seat Instruction Manual

Model: GoFit Plus | Brand: Chicco

## INTRODUCTION

The Chicco GoFit Plus Backless Booster seat is engineered for comfort and safety, designed for children who meet specific age, weight, and height requirements. This booster seat provides essential support and proper vehicle seat belt positioning for older children, ensuring a secure and convenient travel experience.

Key features include a contoured ErgoBoost seat with double foam padding for comfort, LATCH attachments for stability, and an innovative quick-release design for easy removal. It also incorporates integrated lap belt guides and a shoulder belt clip to ensure correct seat belt fit. For added convenience, the booster seat is designed with easy-care, machine-washable fabrics and dishwasher-safe cup holders.

## SETUP AND INSTALLATION

Proper installation is crucial for your child's safety. The GoFit Plus Backless Booster is equipped with LATCH connectors for secure attachment to your vehicle's LATCH system. Always refer to your vehicle's owner's manual for specific LATCH anchor locations and weight limits.

### LATCH Attachment and Quick-Release

The booster seat features LATCH attachments to stabilize the seat when unoccupied and during child entry/exit. To install, extend the LATCH connectors and attach them to your vehicle's lower anchors. To remove, simply pull the quick-release handle located at the front of the booster seat for one-hand detachment.



Image: A hand demonstrates pulling the quick-release latch, allowing the booster seat to easily detach from the vehicle's LATCH anchors.

### **Belt Positioning**

Ensure the vehicle's lap belt is positioned low across your child's thighs, touching the top of the booster seat's lap belt guides. The shoulder belt should rest snugly across the center of your child's shoulder and chest, using the included shoulder belt clip if necessary to achieve proper fit.



Image: The shoulder belt clip is shown in use, guiding the vehicle's seat belt across a child's shoulder for optimal safety and fit.

### **Installation Video Overview**

Your browser does not support the video tag.

Video: This video provides an overview of the Chicco GoFit Plus booster seat, including initial thoughts and a demonstration of the installation process using the LATCH system.

## **OPERATING INSTRUCTIONS**

---

The GoFit Plus is designed for ease of use and child comfort. Ensure your child meets the minimum requirements of 4 years old, 40-110 lbs, and 44-57 inches tall before using this booster seat.

### **Comfort and Portability**

The contoured ErgoBoost seat with double foam padding offers superior comfort for long rides. A built-in carry handle allows for easy transfer between vehicles, making it an ideal travel booster seat.



Image: The booster seat is shown being carried by its integrated handle, highlighting its convenient portability for moving between cars.

## Cup Holders

Two soft-sided CupFolders are integrated into the design. They can easily flex and fold out of the way to save space, which is particularly useful when installing multiple car seats in a row.




Image: A visual comparison of the cup holders, demonstrating their ability to extend for use and fold inward for space-saving.

## MAINTENANCE

Keeping your GoFit Plus clean is simple, thanks to its easy-care design. Regular cleaning helps maintain hygiene and extends the life of the booster seat.

### Cleaning Instructions

- **Seat Pad and Armrest Covers:** All fabrics, including the pop-out armrest covers, are removable and machine-washable. Use cold water on a delicate cycle with mild detergent. Do not use bleach. Hang to dry.
- **Cup Holders:** The soft-sided CupFolders are easy to remove and are dishwasher safe for convenient cleaning.
- **Foam Insert:** The foam insert may be hand rinsed and hung to dry.
- **Plastic/Metal Components:** Wipe clean with a damp cloth and mild soap. Do not use abrasive cleaners.



Image: A hand detaches the armrest cover, illustrating the ease of removing fabric components for washing.

## SPECIFICATIONS

Below are the detailed specifications for the Chicco GoFit Plus Backless Booster Car Seat:

Feature	Detail
Minimum Weight Recommendation	40 Pounds
Maximum Weight Recommendation	110 Pounds
Minimum Height Recommendation	38 Inches
Maximum Height Recommended	57 Inches
Age Range Description	Toddler (typically 4+ years old)
Installation Type	LATCH

Feature	Detail
Orientation	Forward Facing
Harness Type	3-Point (uses vehicle's seat belt)
Item Dimensions (D x W x H)	15"D x 17"W x 8.5"H
Item Weight	5.5 Pounds
Material Type	Metal, Plastic, Polyester
Color	Vivaci/Pink
UPC	049796611649
Manufacturer	Artsana USA, Inc.



Image: Visual representation of the booster seat's dimensions for easy reference.

## WARRANTY AND SUPPORT

The Chicco GoFit Plus Backless Booster Car Seat comes with a manufacturer's warranty to ensure your peace of mind.

### Manufacturer Warranty

This product is covered by a **1-year limited warranty** from the manufacturer, Artsana USA, Inc. For detailed information regarding warranty coverage, claims, or product support, please refer to the warranty documentation included with your product or visit the official Chicco website.

### Additional Product Overview

Your browser does not support the video tag.

Video: A general overview of the Chicco GoFit Plus backless booster car seat, highlighting its features and benefits for parents

and children.