

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [CoComelon](#) /
- › [CoComelon Musical JJ Plush Doll Instruction Manual](#)

CoComelon CMW0016

CoComelon Musical JJ Plush Doll Instruction Manual

Model: CMW0016

PRODUCT OVERVIEW

The CoComelon Musical JJ Plush Doll is a soft, interactive toy designed to bring the popular CoComelon nursery rhymes to life. This plush doll, inspired by the character JJ, is dressed in his signature bedtime onesie and holds a small teddy bear pillow plush. It features sound capabilities, playing song clips and phrases when activated.





Image: Front view of the CoComelon Musical JJ Plush Doll, showcasing its design and included teddy bear.

SAFETY INFORMATION

This product is intended for children aged 18 months and up. Please ensure adult supervision during play. No specific safety warnings are applicable beyond general toy safety guidelines.

SETUP

Battery Installation

The CoComelon Musical JJ Plush Doll requires 3 AAA batteries. These batteries are included for demonstration purposes. For continued use, it is recommended to replace them with fresh batteries.

1. Locate the battery compartment on the back of the doll. It is typically secured with a small screw.
2. Using a Phillips head screwdriver, carefully unscrew the battery compartment cover.
3. Insert 3 new AAA batteries, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.



Image: The doll in its packaging, showing the "Try Me!" tag on its tummy, indicating the activation point for sounds.

OPERATING INSTRUCTIONS

The CoComelon Musical JJ Plush Doll is designed for simple, interactive play.

Activating Sounds and Phrases

- To hear JJ sing clips of the "Yes Yes Bedtime Song" and "Lullaby Song," or say fun bedtime phrases like "Sleep Tight" and "Nighty Night," gently squeeze the doll's tummy.
- The doll will play a different sound or phrase with each squeeze.



Image: A hand demonstrating how to press the doll's tummy to activate its sounds and phrases.

MAINTENANCE

Cleaning the Doll

To maintain the quality and cleanliness of your CoComelon Musical JJ Plush Doll:

- Spot clean only with a damp cloth and mild soap.
- Do not submerge the doll in water, as this may damage the electronic components.
- Allow the doll to air dry completely before further use.

Battery Care

- Remove batteries if the doll will not be used for an extended period to prevent leakage.
- Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Doll does not make sounds.	<ul style="list-style-type: none">• Batteries are low or depleted.• Batteries are inserted incorrectly.• Battery compartment cover is not fully secured.	<ul style="list-style-type: none">• Replace with fresh AAA batteries.• Check battery polarity (+/-).• Ensure battery compartment cover is screwed on tightly.
Sounds are distorted or faint.	<ul style="list-style-type: none">• Batteries are low.	<ul style="list-style-type: none">• Replace with fresh AAA batteries.

SPECIFICATIONS

Feature	Detail
Model Number	CMW0016
Product Dimensions	7 x 6.25 x 12 inches
Item Weight	15.8 ounces
Recommended Age	18 months and up
Batteries Required	3 x AAA (included for demo)
Manufacturer	Jazwares, LLC
Release Date	August 1, 2020



Image: Diagram showing the approximate dimensions of the CoComelon Musical JJ Plush Doll.

WARRANTY AND SUPPORT

Specific warranty information for the CoComelon Musical JJ Plush Doll is not provided in this manual. For warranty details or product support, please refer to the manufacturer's official website or contact their customer service directly. The manufacturer is Jazwares, LLC.

For additional information or to explore more CoComelon products, you may visit the official CoComelon store:

[CoComelon Store on Amazon](#).

ADDITIONAL INFORMATION

The CoComelon Musical JJ Plush Doll is designed to be a portable and cuddly companion for your child, allowing them to take their favorite CoComelon friend wherever they go.




Image: A child embracing the JJ doll, demonstrating its portability and suitability for young users.



Image: The doll being cuddled by a child in bed, highlighting its role as a bedtime friend.





© 2024 CoComelon. All rights reserved. Manufactured by Jazwares, LLC.

Related Documents - CMW0016



[CoComelon Go! Go! Smart Wheels Instruction Manual - Battery, Features, and Troubleshooting](#)

Official instruction manual for CoComelon Go! Go! Smart Wheels vehicles. Learn about battery installation, product features, care, and troubleshooting. Includes FCC compliance information.

	<p>CoComelon 6V Interactive Tractor User Manual</p> <p>This user manual provides safety instructions, assembly guide, external charging information, controls and functions, maintenance tips, and care instructions for the CoComelon 6V Interactive Tractor.</p>
	<p>CoComelon Big Roll Bingo: Complete Game Instructions</p> <p>Learn how to play CoComelon Big Roll Bingo with these complete instructions. This fun game for children aged 4+ involves rolling dice, matching animals, and being the first to get five in a row.</p>
	<p>VTech CoComelon Go! Go! Smart Wheels Treehouse Track Set Instruction Manual</p> <p>Instruction manual for the VTech CoComelon Go! Go! Smart Wheels Treehouse Track Set, featuring JJ's Off-Road Vehicle. Includes assembly, features, activities, care, and troubleshooting.</p>
	<p>CoComelon Go! Go! Smart Wheels Grocery Store Track Set Instruction Manual</p> <p>Official instruction manual for the CoComelon Go! Go! Smart Wheels Grocery Store Track Set by VTech. Learn how to assemble, install batteries, and play with the toy.</p>