ZdalaMit SB2020n-G6

ZdalaMit Replacement Remote Control Instruction Manual

For Vizio Sound Bar 20" 2.0 Soundbar System Model SB2020n-G6

1. Introduction

This instruction manual provides detailed guidance for the use and maintenance of your ZdalaMit replacement remote control. This remote is specifically designed to be compatible with the Vizio Sound Bar 20" 2.0 Soundbar System, model SB2020n-G6. It offers direct functionality without the need for complex programming or pairing.

2. Setup: Battery Installation

To begin using your replacement remote control, you will need to install two AAA alkaline batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.

Once batteries are installed, the remote is ready for immediate use with your compatible Vizio Sound Bar SB2020n-G6. No programming or pairing is required.



Image 1: Front view of the ZdalaMit replacement remote control, showing all buttons.

3. Operating Instructions: Button Functions

Familiarize yourself with the functions of each button on your replacement remote control. Refer to Image 1 for the button layout.

- **Power**: Turns the sound bar on or off.
- **Input**: Cycles through available audio input sources (e.g., Optical, RCA, USB).
- **Bluetooth**: Activates Bluetooth pairing mode or switches to the Bluetooth input.
- **Volume Up (+)**: Increases the sound bar's volume.
- **Volume Down (-)**: Decreases the sound bar's volume.
- **Play/Pause**: Plays or pauses audio playback.
- **Skip Forward**: Skips to the next track or chapter.
- **Skip Backward**: Skips to the previous track or chapter.
- **Mute**: Mutes or unmutes the sound.
- **TVOL (TV Volume)**: Synchronizes the sound bar's volume with your TV's volume (if supported by your TV and connection type).
- **VRT:X**: Activates or deactivates the DTS Virtual:X virtual surround sound feature.
- **BASS**: Adjusts the bass level.
- **EQ (Equalizer)**: Cycles through preset equalizer modes (e.g., Movie, Music, Dialog).
- **TREB (Treble)**: Adjusts the treble level.




Image 2: The replacement remote control in a typical home theater setup, demonstrating its intended use with a sound bar and television.

4. Maintenance

- **Cleaning**: Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement**: Replace batteries when the remote's responsiveness decreases. Always replace both batteries at the same time with new 1.5V AAA alkaline batteries. Do not mix old and new batteries or different types of batteries.

- **Storage**: If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- **Environmental Conditions**: Avoid exposing the remote to extreme temperatures, direct sunlight, or high humidity.

5. Troubleshooting

Problem	Solution
Remote control is not responding.	• Ensure batteries are inserted correctly with the correct polarity (+/-). • Replace old batteries with new 1.5V AAA alkaline batteries. • Ensure there are no obstructions between the remote and the sound bar's infrared receiver. • Confirm the remote is pointed directly at the sound bar.
Remote control does not require programming.	This remote is pre-programmed for the Vizio Sound Bar SB2020n-G6 and does not require any manual programming or pairing steps. Simply install batteries and use.
Specific buttons are not working.	• Check if the batteries are low and replace them. • Ensure the sound bar is powered on and functioning correctly. • Some functions (e.g., TVOL) may require specific sound bar or TV settings to be enabled.

6. Specifications

- **Model Number**: SB2020n-G6
- **Brand**: ZdalaMit
- **Compatibility**: Vizio Sound Bar 20" 2.0 Soundbar System SB2020n-G6
- **Power Supply**: 2 x 1.5V AAA Alkaline Batteries (not included)
- **Special Feature**: Pre-programmed, no pairing required
- **Color**: Black
- **Product Dimensions**: 4.8 x 1.2 x 0.4 inches (approximately)
- **Item Weight**: 1.4 ounces (approximately)
- **Max Number of Supported Devices**: 1



Image 3: Visual representation of the remote control. Product dimensions are approximately 4.8 inches (length) x 1.2 inches (width) x 0.4 inches (thickness).

7. Support and Contact Information

For any questions, concerns, or assistance regarding your ZdalaMit replacement remote control, please contact the seller or manufacturer through the platform where the product was purchased. Please refer to your purchase documentation for specific contact details.

This product is designed for straightforward operation and typically does not require extensive technical support beyond battery installation and basic troubleshooting.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question