



[Manuals.plus](#) /

› [Simple Houseware](#) /

› Simple Houseware Standing Coat and Hat Hanger Organizer Rack (Model BO-09A-W) - User Manual

Simple Houseware BO-09A-W

Simple Houseware Standing Coat and Hat Hanger Organizer Rack (Model BO-09A-W) - User Manual

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Simple Houseware Standing Coat and Hat Hanger Organizer Rack. Designed for functionality and durability, this 12-hook rack offers ample storage while maintaining stability. Please read this manual thoroughly to ensure proper setup and long-lasting use of your product.

Key features include:

- 12 Hooks for coats, hats, scarves, and handbags.
- Stable and solid four-leg base to prevent tipping.
- Adjustable glides for leveling on uneven floors.
- Durable metal construction with a white finish.
- Easy assembly with minimal effort.

PRODUCT COMPONENTS

Before beginning assembly, ensure all components are present and undamaged. While specific component names may vary slightly, typical parts for this standing coat rack include:

- Base Legs (4 sections forming a cross-base)
- Main Pole Segments (typically 2-3 sections that connect to form the vertical stand)
- Hook Sections (upper and lower sections with multiple hooks)
- Assembly Hardware (screws, washers, and an Allen wrench, if required)
- Adjustable Glides (pre-attached to base legs or included for installation)

If any parts are missing or damaged, please contact Simple Houseware customer support for assistance.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Simple Houseware Standing Coat and Hat Hanger is designed to be straightforward and requires minimal effort. Follow these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all components listed in the 'Product Components' section are present.
2. **Assemble the Base:** Connect the four base legs to the bottom pole segment, forming a stable cross-shaped base. Secure them tightly using the provided screws and Allen wrench.
3. **Connect Pole Segments:** Attach the main pole segments together, ensuring they are securely fastened. The pole typically consists of two or three sections that screw or snap into place.
4. **Attach Hook Sections:** Slide or screw the hook sections onto the main pole. Ensure all hooks are facing outwards and are firmly attached.
5. **Secure Top Hooks:** Attach the top hook assembly to the uppermost pole segment.
6. **Final Tightening:** Once all parts are assembled, double-check and tighten all screws to ensure maximum stability.
7. **Adjust Glides:** Place the assembled coat rack in its desired location. If the floor is uneven, adjust the glides at the bottom of the base legs by twisting them until the rack is level and stable.

For visual reference, observe the product dimensions and structure:




Image: Product dimensions, showing a height of 72 inches and a base width of 15.3 inches.

The Simple Houseware Standing Coat and Hat Hanger is designed for convenient storage of various items. To ensure optimal performance and stability:

- **Hanging Items:** Utilize the 12 hooks to hang coats, jackets, hats, scarves, handbags, and other accessories. The hooks are distributed at different levels for versatile storage.
- **Weight Distribution:** Distribute items evenly around the rack to maintain balance. Avoid hanging all heavy items on one side, as this may cause the rack to become unstable and tip over. The maximum recommended weight capacity is 35 pounds.
- **Floor Stability:** Ensure the adjustable glides on the base are properly set to keep the rack level on any surface. This is crucial for preventing wobbling and accidental tipping.

The rack is suitable for various environments, including entryways, bedrooms, and offices, providing accessible storage.



Image: The coat rack positioned in an entryway, demonstrating its use for hanging coats and accessories.

MAINTENANCE

To keep your Simple Houseware Standing Coat and Hat Hanger in excellent condition, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the metal surfaces with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Tighten Connections:** Periodically check all screws and connections. Tighten them as needed to ensure the rack remains sturdy and stable.
- **Inspect Glides:** Ensure the adjustable glides on the base are intact and functioning correctly to protect your floors and maintain stability.
- **Avoid Overloading:** Do not exceed the maximum weight capacity of 35 pounds to prevent structural damage or tipping.

TROUBLESHOOTING

If you encounter any issues with your coat rack, refer to the following common troubleshooting tips:

- **Rack is Wobbly/Unstable:**
 - Ensure all assembly screws are tightened securely.
 - Adjust the glides on the base legs to level the rack on uneven surfaces.
 - Verify that items are distributed evenly across all hooks to balance the weight.
- **Hooks Feel Loose:**
 - Re-tighten the screws connecting the hook sections to the main pole.
- **Scratches on Floor:**
 - Ensure the adjustable glides are properly installed and are not worn down. Replace if necessary.

If problems persist, please contact customer support.

SPECIFICATIONS

Brand	Simple Houseware
Model Number	BO-09A-W
Color	White
Material	Metal
Product Dimensions (D x W x H)	15.3" x 15.3" x 72"
Number of Hooks	12
Load Capacity	35 Pounds
Installation Type	Free Standing
Special Feature	Portable
Assembly Required	Yes

WARRANTY AND SUPPORT

For warranty information or customer support regarding your Simple Houseware Standing Coat and Hat Hanger Organizer Rack, please refer to the product packaging or contact Simple Houseware directly through their official website or customer service channels. Keep your purchase receipt for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question