

[Manuals.plus](#) /

› [UPBRIGHT](#) /

› UpBright 15V AC/DC Adapter Instruction Manual for Singsation SPKA30 Series

UPBRIGHT SPKA30 Power Supply

UpBright 15V AC/DC Adapter Instruction Manual

Model: SPKA30 Power Supply

Brand: UPBRIGHT

1. INTRODUCTION

This manual provides instructions for the safe and effective use of your UpBright 15V AC/DC Adapter. This adapter is designed to power compatible devices such as the Singsation SPKA30, SPKA30R, SPKA30Q Karaoke System Machine, and 808 Audio Classic Bluetooth Speaker.

Please read this manual thoroughly before use and retain it for future reference.

2. SAFETY INFORMATION

- Ensure the adapter's voltage and current ratings match your device's requirements.
- Do not expose the adapter to water or excessive moisture.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open or repair the adapter. Refer to qualified personnel for service.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.

3. PRODUCT OVERVIEW

The UpBright 15V AC/DC Adapter is a power supply unit designed to convert alternating current (AC) from a wall outlet to direct current (DC) required by your electronic device. It features a standard US plug and a barrel connector for device compatibility.



Image 1: UpBright 15V AC/DC Adapter. This image shows the black power adapter with a standard US two-prong plug on one end and a coiled cable leading to a barrel connector on the other end. The adapter body has the UpBright logo and specifications printed on it.



Image 2: UpBright 15V AC/DC Adapter with barrel connector detail. This image is similar to Image 1 but includes an inset circle highlighting the barrel connector tip, showing its cylindrical shape and central pin.

4. SETUP

1. **Verify Compatibility:** Before connecting, ensure your device (e.g., Singsation SPKA30, SPKA30R, SPKA30Q Karaoke System or 808 Audio Bluetooth Speaker) requires a 15V DC power input with a 1A current rating and has a compatible barrel connector. Refer to your device's manual for specific power requirements.
2. **Connect to Device:** Insert the barrel connector end of the UpBright adapter firmly into the DC input port of your electronic device.
3. **Connect to Power Outlet:** Plug the AC prongs of the adapter into a standard 100-240VAC 50/60Hz wall power outlet.
4. **Power On Device:** Once connected, you can power on your device according to its own operating instructions.

UpBright AC Adapter Power Supply Compatible with:



Image 3: UpBright AC Adapter compatible with Singsation Karaoke System. This image displays the UpBright adapter alongside a Singsation karaoke system and its packaging, illustrating the intended use of the adapter with the karaoke machine.

5. OPERATING INSTRUCTIONS

The UpBright AC/DC adapter functions as a power source for your compatible electronic devices. Once properly connected, it continuously supplies the necessary power. There are no user-adjustable settings on the adapter itself.

- **Continuous Power:** The adapter provides stable 15V DC power to your device as long as it is plugged into a live AC outlet and connected to the device.
- **Disconnection:** To disconnect power, first turn off your electronic device, then unplug the adapter from the wall outlet, and finally disconnect the barrel connector from your device.

6. MAINTENANCE

- **Cleaning:** Disconnect the adapter from both the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior of the adapter. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and its cable for any signs of damage, such as frayed wires, bent prongs, or cracks in the casing. If damage is observed, discontinue use immediately.

7. TROUBLESHOOTING

Troubleshooting Guide

Problem	Possible Cause	Solution
Device not powering on.	• Adapter not properly plugged in. • Wall outlet is not active. • Adapter or device malfunction. • Incorrect adapter for the device.	• Ensure both ends of the adapter are securely connected. • Test the wall outlet with another device. • Try a different compatible adapter if available, or contact support. • Verify the adapter's specifications match your device's requirements.
Adapter feels unusually hot.	• Overload or short circuit. • Poor ventilation.	• Disconnect immediately. Ensure the device is compatible and not drawing excessive power. • Ensure the adapter is in an open area with adequate airflow.
Intermittent power to device.	• Loose connection. • Damaged cable or connector.	• Check all connections for tightness. • Inspect the cable and connector for visible damage. Discontinue use if damaged.

8. SPECIFICATIONS


- **Input Voltage:** 100-240VAC, 50/60Hz
- **Output Voltage:** 15V DC
- **Output Current:** 1A (1000mA)
- **Connector Type:** Barrel Connector
- **Protection Features:** Over Voltage Protection (OVP), Over Current Protection (OCP), Short Circuit Protection (SCP)
- **Product Dimensions:** 3 x 3 x 1 inches
- **Item Weight:** 3.52 ounces (0.1 Kilograms)
- **Manufacturer:** UpBright
- **Compatible Models:** Singsation SPKA30, SPKA30R, SPKA30Q Karaoke System, 808 Audio Classic Bluetooth Speaker

9. WARRANTY AND SUPPORT

This UpBright product comes with a limited warranty. Please refer to the warranty certificate included with your purchase for specific terms and conditions.

- **Warranty Period:** 30 Days Refund, 24 Months Exchange.
- **Contact Support:** For technical assistance or warranty claims, please contact UpBright customer service. Refer to the contact information provided with your product packaging or visit the official UpBright website.

Come With A Suitable Outlet Adapter (Only One) to Fit
Your Country/Area For International Order



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UPBRIGHT® LIMITED WARRANTY




Image 4: UpBright Limited Warranty Certificate. This image shows a document titled "LIMITED WARRANTY CERTIFICATE" along with a "PRODUCT WARRANTY" seal, indicating the product's warranty coverage.

© 2023 UPBRIGHT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08574NMKV>

More documents and user manuals: <https://manuals.plus/>