

magigift B08577SWTR

Magigift Dog Cookie Cutter Set Instruction Manual

INTRODUCTION

Thank you for choosing the Magigift Dog Cookie Cutter Set. This set is designed to help you create fun and unique shapes for various culinary and crafting projects. Made from durable stainless steel with protective plastic covers, these cutters are versatile and easy to use. Please read this manual carefully to ensure proper use and care of your new cookie cutters.

PRODUCT OVERVIEW

The Magigift Dog Cookie Cutter Set includes 8 pieces, featuring two primary designs: dog bone and dog paw print. Each design comes in multiple sizes to accommodate various needs.

- **Material:** Food-grade 430 stainless steel with plastic protective covers.
- **Shapes:** Assorted dog bone and dog paw print designs.
- **Quantity:** 8 pieces in total.
- **Features:** Rolled edges for safe handling, rust-resistant construction.



Image 1: The Magigift Dog Cookie Cutter Set, displaying the different sizes and shapes of the bone and paw print cutters, along with their approximate dimensions.



Image 2: The complete set of Magigift dog cookie cutters, including bone and paw shapes, displayed on a kitchen surface alongside baking ingredients like flour and eggs, ready for use.

SETUP AND FIRST USE

1. **Unpack:** Carefully remove all cookie cutters from their packaging.
2. **Clean:** Before first use, wash all cookie cutters thoroughly with warm, soapy water. Rinse well and dry immediately to prevent water spots or rust.
3. **Inspect:** Check each cutter for any manufacturing defects or damage.

OPERATING INSTRUCTIONS

These cookie cutters are versatile tools for various applications:

- **For Dough:** Place the cutter firmly onto rolled-out cookie dough, fondant, or pastry. Press down evenly to cut through the material. The plastic top edge provides a comfortable grip and protects your hands.

- **For Sandwiches & Fruits:** Use the cutters to create fun shapes from bread slices, cheese, or soft fruits and vegetables. This is ideal for children's lunches or decorative platters.
- **Crafts:** The cutters can also be used with craft clays, play-doh, or other moldable materials for creative projects.



Image 3: A hand demonstrating the use of a Magigift paw print cookie cutter, pressing it firmly into rolled-out dough on a wooden surface.



Image 4: Magigift cookie cutters in use, cutting decorative shapes from slices of kiwi, cucumber, and carrot, demonstrating their versatility beyond dough.



Image 5: Creative use of Magigift cookie cutters to shape sandwiches into dog bone and paw print designs, with small vegetable cutouts as decoration.

CARE AND MAINTENANCE

To ensure the longevity and hygiene of your Magigift cookie cutters, follow these care instructions:

- **Cleaning:** Hand wash only with warm, soapy water after each use.
- **Drying:** Dry the cutters immediately and thoroughly with a soft cloth to prevent water spots and rust.
- **Storage:** Store in a dry place to maintain their condition.

Note: While the product features mention "Dishwasher safe", the official product care instructions specify "Hand Wash Only" to best preserve the product's quality and finish.

TROUBLESHOOTING

Magigift cookie cutters are simple tools and typically do not require troubleshooting. However, if you encounter any issues:

- **Difficulty Cutting:** Ensure your dough or material is rolled to an appropriate thickness and consistency. For sticky dough, lightly flour the cutter before use.
- **Material Sticking:** If material sticks inside the cutter, gently tap the cutter on a surface or use a small brush to dislodge it.

SPECIFICATIONS

Feature	Detail
Brand	magigift
Model Number (ASIN)	B08577SWTR
Material	Stainless Steel, Plastic, Polyvinyl Chloride (PVC)
Shapes Included	Bone, Dog Paw
Number of Items	8
Special Features	Durable, Rolled Edges
Product Care Instructions	Hand Wash Only
Item Weight	0.19 Kilograms
GTIN/UPC	746210989727

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Magigift Dog Cookie Cutter Set, please contact the manufacturer directly through their official channels or the retailer from whom you purchased the product. Specific warranty details may vary by retailer or region.
Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question